



Honeywell International Inc.
21111 N. 19th Avenue
Phoenix, Arizona 85027-2708
U.S.A.
CAGE: 55939
<https://aerospace.honeywell.com/>
Go to [Contact Us](#)

Installation and Operation Manual

KX 200 NAV/COM Transceiver

Part Number

CAGE

89000002-120

55939

Legal Notice

Export Control

These items are controlled by the U.S. government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations.
Export Classification: EAR (7E994)

34-24-61

Page T-1

Initial 23 Jan 2025

Revised 13 Aug 2025

Publication Number D202411004595, Revision 1



INSTALLATION AND OPERATION MANUAL

89000002-120

Proprietary Information**HONEYWELL - CONFIDENTIAL**

COPYRIGHT BY HONEYWELL INTERNATIONAL INC. ("HONEYWELL"). ALL RIGHTS RESERVED. THIS DOCUMENT AND ALL INFORMATION CONTAINED HEREIN ARE THE CONFIDENTIAL AND PROPRIETARY INFORMATION OF HONEYWELL AND CONTAIN HONEYWELL TRADE SECRETS. NEITHER THIS DOCUMENT NOR THE INFORMATION CONTAINED HEREIN MAY, IN WHOLE OR IN PART, BE USED, DUPLICATED, OR DISCLOSED FOR ANY PURPOSE WITHOUT PRIOR WRITTEN PERMISSION OF HONEYWELL.

PLEASE REVIEW THE TERMS OF THIS AGREEMENT CAREFULLY BEFORE USING THIS DOCUMENT, AS BY USING IT, YOU ACKNOWLEDGE THAT YOU HAVE REVIEWED THIS AGREEMENT AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS.

HONEYWELL MATERIALS LICENSE AGREEMENT

This document and the information contained herein ("the Materials") are the proprietary data of Honeywell. These Materials are provided for the exclusive use of Honeywell-authorized Service Centers; Honeywell-authorized repair facilities; owners of a Honeywell aerospace product that is the subject of these Materials ("Honeywell Product") that have entered into a written agreement with Honeywell relating to the repair or maintenance of Honeywell Product; and direct recipients of Materials from Honeywell via

<https://aerospace.honeywell.com/en/learn/about-us/about-myaerospace> that own a Honeywell Product. The terms and conditions of this Honeywell Materials License Agreement ("License Agreement") govern your use of these Materials, except to the extent that any terms and conditions of another applicable agreement with Honeywell regarding the maintenance or repair of a Honeywell Product and that is the subject of the Materials conflict with the terms and conditions of this License Agreement, in which case the terms and conditions of the other agreement will govern. The terms of this License Agreement supersede any other Material License Agreement previously provided with the Materials, regardless of what form the Materials were provided, including without limitation when received in hard copy, downloaded via the MyAerospace portal or CD-ROM. However, this License Agreement will govern in the event of a conflict between these terms and conditions and those of a purchase order or acknowledgement. Your access or use of the Materials represents your acceptance of the terms of this License Agreement.

1. License Grant - If you are a party to an applicable written agreement with Honeywell relating to the repair or maintenance of the subject Honeywell Product, subject to your compliance with the terms and conditions of this License Agreement, Honeywell hereby grants you, and you accept, a limited, personal, non-transferrable, non-exclusive license to use these Materials only in accordance with that agreement.

If you are a direct recipient of these Materials from Honeywell's MyAerospace Technical Publication website and are not a party to an agreement related to the maintenance or repair of the subject Honeywell Product, subject to your compliance with the terms and conditions of this License Agreement, Honeywell hereby grants you, and you accept, a limited, personal, non-transferrable, non-exclusive license to use a single copy of these Materials to maintain or repair only the subject Honeywell Product installed or intended to be installed on the aircraft you own and/or operate and only at the facility to which these Materials have been shipped ("the Licensed Facility"). Transfer of the Materials to another facility owned by you is permitted only if the original Licensed Facility retains no copies of the Materials, the transferee accepts all of your obligations and liabilities under this License Agreement, and you provide prior written notice to Honeywell with the name and address of the transferee. You agree not to use these Materials for commercial purposes.

2. Restrictions on Use - You may not sell, rent, lease, or (except as authorized under any applicable airworthiness authority regulation) lend the Materials to anyone for any purpose. You may not use the Materials to reverse engineer any Honeywell product, hardware or software, and may not decompile or disassemble software provided under this License Agreement, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not create derivative works or modify the Materials in any way. You



INSTALLATION AND OPERATION MANUAL

89000002-120

agree that Materials shall only be used for the purpose of the rights granted herein. The Material furnished hereunder may be subject to U.S. export regulations. You will adhere to all U.S. export regulations as published and released from time to time by the U.S. Government. You may not design or manufacture a Honeywell part or detail of a Honeywell part, to create a repair for a Honeywell part, design or manufacture any part that is similar or identical to a Honeywell part, compare a Honeywell part or design of a Honeywell part to another part design, or apply for FAA PMA or other domestic or foreign governmental approval to manufacture or repair a Honeywell part. Honeywell International Inc. and its affiliates comply fully with all applicable export control laws and regulations of the United States and of all countries where it conducts business. In order to satisfy US export control laws, you confirm that you are not an entity that meets the definition of a military end user in China, Russia, or Venezuela ("Military End User") or sells items that support or contribute to a Military End Use by a Military End User. Military End User includes any entity that is part of the national armed services (army, navy, marine, air force, or coast guard), as well as the national guard and national police, government intelligence or reconnaissance organizations, or any person or entity whose actions or functions are intended to support "military end uses." "Military End Uses" includes use of an item to support or contribute to the operation, installation, maintenance, repair, overhaul, refurbishing, development, or production of military items. In addition, you will not divert or in any way utilize or sell Honeywell products, materials, technology, or technical data to any entity that is a Chinese, Russian, or Venezuelan Military End User or for Military End Uses, as stated above. You shall immediately notify Honeywell and cease all activities associated with the transaction in question if it knows or has a reasonable suspicion that the products, materials, technical data, plans, or specifications may be exported, reexported, or transferred in support of a prohibited Military End Use or to a Military End User. Failure to comply with this provision is a material breach of your order and agreement with Honeywell and Honeywell is entitled to immediately seek all remedies available under law and in equity (including without limitation, termination), without any liability to Honeywell.

3. Rights In Materials - Honeywell retains all rights in these Materials and in any copies thereof that are not expressly granted to you, including all rights in patents, copyrights, trademarks, and trade secrets. The Materials are licensed and not sold under this License Agreement. No license to use any Honeywell trademarks or patents is granted under this License Agreement.

4. Changes - Honeywell reserves the right to change the terms and conditions of this License Agreement at any time, including the right to change or impose charges for continued use of the Materials. Honeywell may add, delete or otherwise modify any portion of the Materials ("Updated Materials") at any time. You agree to stop using outdated Materials upon issuance of any Updated Materials.

5. Confidentiality - You acknowledge that these Materials contain information that is confidential and proprietary to Honeywell. You agree to take all reasonable efforts to maintain the confidentiality of these Materials.

6. Assignment and Transfer - This License Agreement may be assigned to a service center approved and formally designated as a service center by Honeywell, provided, however, that you retain no copies of the Materials in whole or in part. However, the recipient of any such assignment or transfer must assume all of your obligations and liabilities under this License Agreement. No assignment or transfer shall relieve any party of any obligation that such party then has hereunder. Otherwise, neither this License Agreement nor any rights, licenses or privileges granted under this License Agreement, nor any of its duties or obligations hereunder, nor any interest or proceeds in and to the Materials shall be assignable or transferable (in insolvency proceedings, by merger, by operation of law, by purchase, by change of control or otherwise) by you without Honeywell's written consent.

7. Copies of Materials - Unless you have the express written permission of Honeywell, you may not make or permit making of copies, digital or printed, of the Materials. You agree to return the Materials and any such copies thereof to Honeywell upon the request of Honeywell.

8. Term - This License Agreement is effective until terminated as set forth herein. This License Agreement will terminate immediately, without notice from Honeywell, if you fail to comply with any provision of this License Agreement or will terminate simultaneously with the termination or expiration of your applicable agreement with Honeywell relating to the repair or maintenance of the subject Honeywell Product. Upon termination of this License



INSTALLATION AND OPERATION MANUAL

89000002-120

Agreement, you will return these Materials to Honeywell without retaining any copies, in whole or in part, and will have one of your authorized officers certify that all Materials have been returned with no copies retained.

9. Audit Rights - Honeywell, through its authorized representatives, with no less than thirty (30) calendar days notice from Honeywell, has the right during normal business hours during the term of this License Agreement and for three (3) years thereafter to visit you and have access to the inside and outside of your facility for the purpose of inspecting, observing and evaluating your compliance under this License Agreement.

10. Remedies - Honeywell reserves the right to pursue all available remedies and damages resulting from a breach of this License Agreement.

11. Limitation of Liability - Honeywell makes no representations or warranties regarding the use or sufficiency of the Materials. THERE ARE NO OTHER WARRANTIES, WHETHER WRITTEN OR ORAL, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO (i) WARRANTIES ARISING FROM COURSE OF PERFORMANCE, DEALING, USAGE, OR TRADE, WHICH ARE HEREBY EXPRESSLY DISCLAIMED, OR (ii) WARRANTIES AGAINST INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS OF THIRD PARTIES, EVEN IF HONEYWELL HAS BEEN ADVISED OF ANY SUCH INFRINGEMENT. IN NO EVENT WILL HONEYWELL BE LIABLE FOR ANY INCIDENTAL DAMAGES, CONSEQUENTIAL DAMAGES, SPECIAL DAMAGES, INDIRECT DAMAGES, LOSS OF PROFITS, LOSS OF REVENUES, OR LOSS OF USE, EVEN IF INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. TO THE EXTENT PERMITTED BY APPLICABLE LAW, THESE LIMITATIONS AND EXCLUSIONS WILL APPLY REGARDLESS OF WHETHER LIABILITY ARISES FROM BREACH OF CONTRACT, WARRANTY, INDEMNITY, TORT (INCLUDING BUT NOT LIMITED TO NEGLIGENCE), BY OPERATION OF LAW, OR OTHERWISE.

12. Controlling Law - This License Agreement shall be governed and construed in accordance with the laws of the State of New York without regard to the conflict of laws provisions thereof.

13. Severability - In the event any provision of this License Agreement is determined to be illegal, invalid, or unenforceable, the validity and enforceability of the remaining provisions of this License Agreement will not be affected and, in lieu of such illegal, invalid, or unenforceable provision, there will be added as part of this License Agreement one or more provisions as similar in terms as may be legal, valid and enforceable under controlling law.

14. Integration and Modification - This License Agreement sets forth the entire agreement and understanding between the parties on the subject matter of the License Agreement and merges all prior discussions and negotiations among them.

Safety Advisory

WARNING: BEFORE THE MATERIALS CALLED OUT IN THIS PUBLICATION ARE USED, KNOW THE HANDLING, STORAGE AND DISPOSAL PRECAUTIONS RECOMMENDED BY THE MANUFACTURER OR SUPPLIER. FAILURE TO OBEY THE MANUFACTURERS' OR SUPPLIERS' RECOMMENDATIONS CAN RESULT IN PERSONAL INJURY OR DISEASE.

This publication describes physical and chemical processes which can make it necessary to use chemicals, solvents, paints, and other commercially available materials. The user of this publication must get the Safety Data Sheets (OSHA Hazard Communication Standard (HCS) 29 CFR 1910.1200(g) or equivalent) from the manufacturers or suppliers of the materials to be used. The user must know the manufacturer/ supplier data and obey the procedures, recommendations, warnings and cautions set forth for the safe use, handling, storage, and disposal of the materials.

Warranty/Liability Advisory

WARNING: HONEYWELL ASSUMES NO RESPONSIBILITY FOR ANY HONEYWELL EQUIPMENT WHICH IS NOT MAINTAINED AND/OR REPAIRED IN ACCORDANCE WITH HONEYWELL'S PUBLISHED INSTRUCTIONS AND/OR HONEYWELL'S FAA/ODA REPAIR AUTHORIZATION. NEITHER DOES HONEYWELL ASSUME



INSTALLATION AND OPERATION MANUAL

89000002-120

RESPONSIBILITY FOR SPECIAL TOOLS AND TEST EQUIPMENT FABRICATED BY COMPANIES OTHER THAN HONEYWELL.

WARNING: INCORRECTLY REPAIRED COMPONENTS CAN AFFECT AIRWORTHINESS OR DECREASE THE LIFE OF THE COMPONENTS. INCORRECTLY FABRICATED SPECIAL TOOLING OR TEST EQUIPMENT CAN RESULT IN DAMAGE TO THE PRODUCT COMPONENTS OR GIVE UNSATISFACTORY RESULTS.



INSTALLATION AND OPERATION MANUAL
89000002-120

Copyright - Notice

Copyright 2025 Honeywell International Inc. All rights reserved.

Honeywell is a registered trademark of Honeywell International Inc.

All other marks are owned by their respective companies.

Preface

Note to KX 200 NAV/COM Radio Customers:

Thank you for the purchase of the Honeywell General Aviation (GA) Next-Generation KX 200 NAV/COM Radio.

General Aviation's newest and most advanced NAV/COM radio is pilot-friendly by design. That's because we consulted pilots at every phase of a development process that started with a blank CAD screen and ended with the creation of a groundbreaking new radio for the 2020s and beyond.

The KX 200 is an easy direct replacement with the same footprint as your current KX 155 radio. But that is where the similarity ends. The KX 200 features:

- High-resolution color LCD
- 50-channel memory presets
- 25kh or 8.33kh channel spacing
- Full featured digital NAV/COM with VOR, LOC, ILS, and glide slope
- Compatible with existing indicators and installed equipment
- Compatible with 14- and 28-volt systems
- Possibility to expand capabilities with future Honeywell Anthem™ cockpit connectivity
- Two-year warranty.



INSTALLATION AND OPERATION MANUAL
89000002-120

TRANSMITTAL INFORMATION

TO HOLDERS OF KX 200 NAV/COM TRANSCEIVER IOM ATA No. 34-24-61 ISSUED FOR USE IN SUPPORT OF THE FOLLOWING:

Table TI-1 shows the applicable components.

Table TI-1. Applicable Components

Component PN	Nomenclature
89000002-120	KX 200 NAV/COM Transceiver

Revision History

Table TI-2 shows the revision history of this IOM.

Table TI-2. Revision History

Revision Number	Revision Date
0	23 Jan 2025
1	13 Aug 2025

The table of highlights tells users what has changed as a result of the revision. The table consists of three columns.

The Task/Page column identifies the blocks of changed information, such as a task, subtask, graphic, or parts list, and the page on which that block starts. The block of information often includes the MTOSS code. Revision marks, when provided, identify the location of the change within the block.

The Description of Change column tells about the change or changes within each block. The description of change is often preceded by a paragraph or figure reference that applies to the block of information.

The Effectivity column tells the user the part number(s) to which the block of information applies. The default value for this column is "All." "All" means that the block applies to all parts.

Table of Highlights

Task/Page	Description of Change	Effectivity
TRANSMITTAL INFORMATION	Global Change: Changed the content and format to agree with the Honeywell processes in effect at the time of the release of this revision.	All
TRANSMITTAL INFORMATION	Global Change: The editorial changes and data that were moved or reformatted are not identified with revision bars.	All
INTRODUCTION (Page INTRO-9)	Table INTRO-2. Added the SIL D202504004738 details in the table.	All
GENERAL DESCRIPTION (Page 1-1)	Paragraph 1.B. Step (3)(b). Deleted the wording "most recent" from the procedural step.	All

EFFECTIVITY

ALL

34-24-61

Page TI-1
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table of Highlights (Cont)

Task/Page	Description of Change	Effectivity
GENERAL DESCRIPTION (Page 1-1)	Paragraph 1.B. Step (3)(d). Updated the step to "Squelch function".	All
GENERAL DESCRIPTION (Page 1-1)	Paragraph 1.B. Step (3)(e). Updated the step to "The intercom function is for voice communication between aircraft crew (pilot and copilot) and passengers".	All
GENERAL DESCRIPTION (Page 1-9)	Paragraph 1.F. Step (5)(a).1b. Updated the frequency range from "328.6 - 335.4 MHz" to "329.15 - 335.00 MHz".	All
GENERAL DESCRIPTION (Page 1-10)	Paragraph 1.G. Added the CAUTION to install the device on an aircraft in the procedural step.	All
GENERAL DESCRIPTION (Page 1-15)	Paragraph 1.J. Step (3)(a). Updated the frequency range from "328.6 - 335.4 MHz" to "329.15 - 335.00 MHz" for Receiver Data (NAV).	All
GENERAL DESCRIPTION (Page 1-16)	Paragraph 1.J. Step (3)(b). Updated the frequency range from "328.6 - 335.4 MHz" to "329.15 - 335.00 MHz" for Antennas (NAV).	All
GENERAL DESCRIPTION (Page 1-18)	Paragraph 1.J. Step (8). Added the step to show certifications.	All
GENERAL DESCRIPTION (Page 1-18)	Paragraph 1.J. Step (9)(a).2. Updated the NOTE to " This device complies with Part 87 of the FCC rules. The antenna(s) used for this transmitter must be fixed-mounted on outdoor permanent structures."	All
INSTALLATION (Page 2-1)	Paragraph 1.B. Step (1). Updated the CAUTION to " The packaging material is inflammable, by burning, toxic fumes can develop".	All
INSTALLATION (Page 2-1)	Paragraph 1.B. Step (2). Updated the step to " Keep the packaging material and use it in the case of a return shipment. Improper or faulty packaging can lead to transport damages".	All
INSTALLATION (Page 2-1)	Paragraph 1.B. Step (3). Updated the step on transportation of device.	All
INSTALLATION (Page 2-3)	Figure 2-1. Updated the BendixKing part numbers from 89000002-120 to 89000002-120, 89000002-121 to 89000002-121 and 89000002-122 to 89000002-122 in the illustration.	All
INSTALLATION (Page 2-4)	Paragraph 1.E. Step (1). Updated the step to "The installation of the components into an aircraft must always comply to the applicable regulations".	All
INSTALLATION (Page 2-9)	Paragraph 1.E. Step (4)(a).8a. Added the CAUTION to installing the retrofit adapter in this step.	All
INSTALLATION (Page 2-11)	Paragraph 1.E. Step (4)(a).9a. Updated the step to removing guide pins.	All

EFFECTIVITY

ALL

34-24-61

Page TI-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table of Highlights (Cont)

Task/Page	Description of Change	Effectivity
INSTALLATION (Page 2-12)	Figure 2-4. Added the figure to show removing guide pins.	All
INSTALLATION (Page 2-13)	Figure 2-5. Added the figure to show guide pins removed.	All
INSTALLATION (Page 2-14)	Figure 2-6. Added the figure to show M3x5 screws installed.	All
INSTALLATION (Page 2-15)	Paragraph 1.E. Step (4)(a). <u>9b</u> . Updated the step to reposition NAV and GS coaxes.	All
INSTALLATION (Page 2-16)	Figure 2-7. Added the figure to show reposition NAV and GS coax.	All
INSTALLATION (Page 2-17)	Paragraph 1.E. Step (4)(a). <u>9c</u> . Updated the step to reposition COM coax.	All
INSTALLATION (Page 2-18)	Figure 2-8. Added the figure to show reposition COM coax.	All
INSTALLATION (Page 2-19)	Paragraph 1.E. Step (4)(a). <u>9d</u> . Updated the step to install retrofit adapter.	All
INSTALLATION (Page 2-20)	Figure 2-9. Added the figure to show install retrofit adapter.	All
INSTALLATION (Page 2-21)	Paragraph 1.E. Step (4)(a). <u>9e</u> . Added the step to secure SMA connectors to NAV and GS antenna connectors.	All
INSTALLATION (Page 2-22)	Figure 2-10. Added the figure to show secure SMA connectors to NAV and GS antenna connectors.	All
INSTALLATION (Page 2-23)	Paragraph 1.E. Step (4)(a). <u>9f</u> . Added the step to connect and lock the COM antenna connector.	All
INSTALLATION (Page 2-24)	Figure 2-11. Added the figure to show connect and lock the COM antenna connector.	All

EFFECTIVITY

ALL

34-24-61

Page TI-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY —————
ALL

34-24-61

RECORD OF REVISIONS

[illegible]

34-24-61

Page RR-1
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY _____
ALL

34-24-61

Page RR-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

RECORD OF TEMPORARY REVISIONS

Instructions on each page of a temporary revision tell you where to put the pages in your manual. Remove the temporary revision pages only when discard instructions are given. For each temporary revision, put the applicable data in the record columns on this page.

Definition of Status column: A TR may be active, incorporated, or deleted. "Active" is entered by the holder of the manual. "Incorporated" means,a TR has been incorporated into the manual and includes the revision number of the manual when the TR was incorporated. "Deleted" means a TR has been replaced by another TR, a TR number will not be issued, or a TR has been deleted.

Temporary Revision Number	Status	Page Number	Issue Date	Date Put In Manual	By	Date Removed From Manual	By

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY —————
ALL

34-24-61

Page RTR-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

SERVICE BULLETIN LIST

Refer to Table INTRO-2 for other applicable service information documents not listed in the Service Bulletin List.

Service Bulletin/ Revision Number	Title	Modification	Date Put in Manual
--------------------------------------	-------	--------------	-----------------------

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY —————
ALL

34-24-61

Page SBL-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

LIST OF EFFECTIVE PAGES

Subheading and Page	Date	Subheading and Page	Date
Title		INTRO-5	13 Aug 2025
T-1	13 Aug 2025	INTRO-6	13 Aug 2025
T-2	13 Aug 2025	INTRO-7	13 Aug 2025
T-3	13 Aug 2025	INTRO-8	13 Aug 2025
T-4	13 Aug 2025	INTRO-9	* 13 Aug 2025
T-5	13 Aug 2025	INTRO-10	13 Aug 2025
T-6	13 Aug 2025	Section 1	
Transmittal Information		GENERAL DESCRIPTION	
TI-1	13 Aug 2025	1-1	* 13 Aug 2025
TI-2	13 Aug 2025	1-2	13 Aug 2025
TI-3	13 Aug 2025	1-3	13 Aug 2025
TI-4	13 Aug 2025	1-4	13 Aug 2025
Record of Revisions		1-5	13 Aug 2025
RR-1	13 Aug 2025	1-6	13 Aug 2025
RR-2	13 Aug 2025	1-7	13 Aug 2025
Record of Temporary Revisions		1-8	13 Aug 2025
RTR-1	13 Aug 2025	1-9	* 13 Aug 2025
RTR-2	13 Aug 2025	1-10	* 13 Aug 2025
Service Bulletin List		1-11	13 Aug 2025
SBL-1	13 Aug 2025	1-12	13 Aug 2025
SBL-2	13 Aug 2025	1-13	13 Aug 2025
List of Effective Pages		1-14	13 Aug 2025
LEP-1	13 Aug 2025	1-15	* 13 Aug 2025
LEP-2	13 Aug 2025	1-16	* 13 Aug 2025
LEP-3	13 Aug 2025	1-17	13 Aug 2025
LEP-4	13 Aug 2025	1-18	* 13 Aug 2025
Table of Contents		Section 2	
TC-1	13 Aug 2025	INSTALLATION	
TC-2	13 Aug 2025	2-1	* 13 Aug 2025
TC-3	13 Aug 2025	2-2	13 Aug 2025
TC-4	13 Aug 2025	2-3	* 13 Aug 2025
TC-5	13 Aug 2025	2-4	* 13 Aug 2025
TC-6	13 Aug 2025	2-5	13 Aug 2025
TC-7	13 Aug 2025	2-6	13 Aug 2025
TC-8	13 Aug 2025	2-7	13 Aug 2025
Introduction		2-8	13 Aug 2025
INTRO-1	13 Aug 2025	2-9	* 13 Aug 2025
INTRO-2	13 Aug 2025	2-10	13 Aug 2025
INTRO-3	13 Aug 2025	2-11	* 13 Aug 2025
INTRO-4	13 Aug 2025	2-12	* 13 Aug 2025
		2-13	* 13 Aug 2025
		2-14	* 13 Aug 2025
		2-15	* 13 Aug 2025

* Indicates a changed or added page.

F Indicates a foldout page.

EFFECTIVITY

ALL

34-24-61

Page LEP-1
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

LIST OF EFFECTIVE PAGES (Cont)

Subheading and Page	Date	Subheading and Page	Date
2-16	* 13 Aug 2025	2-60	13 Aug 2025
2-17	* 13 Aug 2025	2-61	13 Aug 2025
2-18	* 13 Aug 2025	2-62	13 Aug 2025
2-19	* 13 Aug 2025	2-63	13 Aug 2025
2-20	* 13 Aug 2025	2-64	13 Aug 2025
2-21	* 13 Aug 2025	2-65	13 Aug 2025
2-22	* 13 Aug 2025	2-66	13 Aug 2025
2-23	* 13 Aug 2025	2-67	13 Aug 2025
2-24	* 13 Aug 2025	2-68	13 Aug 2025
2-25	13 Aug 2025	2-69	13 Aug 2025
2-26	13 Aug 2025	2-70	13 Aug 2025
2-27	13 Aug 2025	2-71	13 Aug 2025
2-28	13 Aug 2025	2-72	13 Aug 2025
2-29	13 Aug 2025	2-73	13 Aug 2025
2-30	13 Aug 2025	2-74	13 Aug 2025
2-31	13 Aug 2025	2-75	13 Aug 2025
2-32	13 Aug 2025	2-76	13 Aug 2025
2-33	13 Aug 2025	2-77	13 Aug 2025
2-34	13 Aug 2025	2-78	13 Aug 2025
2-35	13 Aug 2025	2-79	13 Aug 2025
2-36	13 Aug 2025	2-80	13 Aug 2025
2-37	13 Aug 2025	2-81	13 Aug 2025
2-38	13 Aug 2025	2-82	13 Aug 2025
2-39	13 Aug 2025	2-83	13 Aug 2025
2-40	13 Aug 2025	2-84	13 Aug 2025
2-41	13 Aug 2025	2-85	13 Aug 2025
2-42	13 Aug 2025	2-86	13 Aug 2025
2-43	13 Aug 2025	2-87	13 Aug 2025
2-44	13 Aug 2025	2-88	13 Aug 2025
2-45	13 Aug 2025	2-89	13 Aug 2025
2-46	13 Aug 2025	2-90	13 Aug 2025
2-47	13 Aug 2025	2-91	13 Aug 2025
2-48	13 Aug 2025	2-92	13 Aug 2025
2-49	13 Aug 2025	2-93	13 Aug 2025
2-50	13 Aug 2025	2-94	13 Aug 2025
2-51	13 Aug 2025	2-95	13 Aug 2025
2-52	13 Aug 2025	2-96	13 Aug 2025
2-53	13 Aug 2025	2-97	13 Aug 2025
2-54	13 Aug 2025	2-98	13 Aug 2025
2-55	13 Aug 2025	2-99	13 Aug 2025
2-56	13 Aug 2025	2-100	13 Aug 2025
2-57	13 Aug 2025	2-101	13 Aug 2025
2-58	13 Aug 2025	2-102	13 Aug 2025
2-59	13 Aug 2025	2-103	13 Aug 2025

* Indicates a changed or added page.

F Indicates a foldout page.

EFFECTIVITY

ALL

34-24-61

Page LEP-2

13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

LIST OF EFFECTIVE PAGES (Cont)

Subheading and Page	Date	Subheading and Page	Date
2-104	13 Aug 2025	3-19	13 Aug 2025
2-105	13 Aug 2025	3-20	13 Aug 2025
2-106	13 Aug 2025	3-21	13 Aug 2025
2-107	13 Aug 2025	3-22	13 Aug 2025
2-108	13 Aug 2025	3-23	13 Aug 2025
2-109	13 Aug 2025	3-24	13 Aug 2025
2-110	13 Aug 2025	3-25	13 Aug 2025
2-111	13 Aug 2025	3-26	13 Aug 2025
2-112	13 Aug 2025	3-27	13 Aug 2025
2-113	13 Aug 2025	3-28	13 Aug 2025
2-114	13 Aug 2025	3-29	13 Aug 2025
2-115	13 Aug 2025	3-30	13 Aug 2025
2-116	13 Aug 2025	3-31	13 Aug 2025
2-117	13 Aug 2025	3-32	13 Aug 2025
2-118	13 Aug 2025	3-33	13 Aug 2025
2-119	13 Aug 2025	3-34	13 Aug 2025
2-120	13 Aug 2025	3-35	13 Aug 2025
2-121	13 Aug 2025	3-36	13 Aug 2025
2-122	13 Aug 2025	3-37	13 Aug 2025
2-123	13 Aug 2025	3-38	13 Aug 2025
2-124	13 Aug 2025	3-39	13 Aug 2025
2-125	13 Aug 2025	3-40	13 Aug 2025
2-126	13 Aug 2025	3-41	13 Aug 2025
Section 3		3-42	13 Aug 2025
OPERATION		3-43	13 Aug 2025
3-1	13 Aug 2025	3-44	13 Aug 2025
3-2	13 Aug 2025	3-45	13 Aug 2025
3-3	13 Aug 2025	3-46	13 Aug 2025
3-4	13 Aug 2025	3-47	13 Aug 2025
3-5	13 Aug 2025	3-48	13 Aug 2025
3-6	13 Aug 2025	3-49	13 Aug 2025
3-7	13 Aug 2025	3-50	13 Aug 2025
3-8	13 Aug 2025	3-51	13 Aug 2025
3-9	13 Aug 2025	3-52	13 Aug 2025
3-10	13 Aug 2025	3-53	13 Aug 2025
3-11	13 Aug 2025	3-54	13 Aug 2025
3-12	13 Aug 2025	3-55	13 Aug 2025
3-13	13 Aug 2025	3-56	13 Aug 2025
3-14	13 Aug 2025	3-57	13 Aug 2025
3-15	13 Aug 2025	3-58	13 Aug 2025
3-16	13 Aug 2025	3-59	13 Aug 2025
3-17	13 Aug 2025	3-60	13 Aug 2025
3-18	13 Aug 2025	3-61	13 Aug 2025
		3-62	13 Aug 2025

* Indicates a changed or added page.

F Indicates a foldout page.

EFFECTIVITY

ALL

34-24-61Page LEP-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

LIST OF EFFECTIVE PAGES (Cont)

Subheading and Page	Date	Subheading and Page	Date
3-63	13 Aug 2025		
3-64	13 Aug 2025		
3-65	13 Aug 2025		
3-66	13 Aug 2025		
3-67	13 Aug 2025		
3-68	13 Aug 2025		
3-69	13 Aug 2025		
3-70	13 Aug 2025		
3-71	13 Aug 2025		
3-72	13 Aug 2025		
3-73	13 Aug 2025		
3-74	13 Aug 2025		
3-75	13 Aug 2025		
3-76	13 Aug 2025		
3-77	13 Aug 2025		
3-78	13 Aug 2025		
3-79	13 Aug 2025		
3-80	13 Aug 2025		
3-81	13 Aug 2025		
3-82	13 Aug 2025		
3-83	13 Aug 2025		
3-84	13 Aug 2025		
3-85	13 Aug 2025		
3-86	13 Aug 2025		
3-87	13 Aug 2025		
3-88	13 Aug 2025		
3-89	13 Aug 2025		
3-90	13 Aug 2025		
3-91	13 Aug 2025		
3-92	13 Aug 2025		
3-93	13 Aug 2025		
3-94	13 Aug 2025		
3-95	13 Aug 2025		
3-96	13 Aug 2025		
3-97	13 Aug 2025		
3-98	13 Aug 2025		
3-99	13 Aug 2025		
3-100	13 Aug 2025		
3-101	13 Aug 2025		
3-102	13 Aug 2025		
3-103	13 Aug 2025		
3-104	13 Aug 2025		

* Indicates a changed or added page.
F Indicates a foldout page.

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS
LIST OF SECTIONS

Title	Page
INTRODUCTION	INTRO-1
1. How to Use This Manual	INTRO-1
A. General	INTRO-1
B. Symbols	INTRO-1
C. Disposal	INTRO-5
D. Warranty Conditions	INTRO-5
E. Conditions of Utilization	INTRO-5
F. Additional Conditions of Utilization	INTRO-6
G. Non-Warranty Clause	INTRO-6
2. Customer Support	INTRO-6
A. Honeywell Aerospace Contact Team	INTRO-6
B. Warranty Registration, Technical Support and Sales Support	INTRO-6
3. Acronyms and Abbreviations	INTRO-6
A. General	INTRO-6
4. Service Information Documents	INTRO-9
A. Applicable Service Information Documents	INTRO-9
SECTION 1	
GENERAL DESCRIPTION	1-1
A. General	1-1
B. Purpose of Equipment	1-1
C. General Notices	1-2
D. Variants Overview	1-2
E. Associated Devices	1-5
F. Scope of Functionality	1-5
G. Safety-Conscious Utilization	1-10
H. Cleaning and Disinfection of Devices	1-11
I. Restriction for Use	1-11
J. Technical Data	1-18
SECTION 2	
INSTALLATION	2-1
A. General	2-1
B. Packaging, Transport, Storage	2-1
C. Device Assignment	2-1

EFFECTIVITY

ALL

34-24-61

Page TC-1
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)
LIST OF SECTIONS (Cont)

Title	Page
D. Default Configuration	2-4
E. Installation Requirements	2-4
F. Dimensions	2-26
G. Connector Pin Assignments - KX 200	2-32
H. Connector Pin Assignments - KX 200 with Retrofit Adapter	2-37
I. Antenna Connectors	2-40
J. Grounding Bolt	2-41
K. Aircraft Wiring - KX 200 with Retrofit Adapter	2-43
L. Configuration Setup	2-80
M. Installation Mode	2-80
N. DME - Transfer Protocol	2-121
O. Post Installation Check	2-121
P. Error / Failure Indication	2-124
Q. Troubleshooting	2-125
SECTION 3	
OPERATION	3-1
A. General	3-1
B. Device Description	3-1
C. Controls and Indications	3-1
D. Start-Up	3-30
E. COM Operation	3-32
F. NAV Operation	3-71
G. Troubleshooting	3-100

EFFECTIVITY

ALL

34-24-61

Page TC-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)

LIST OF FIGURES

Figure	Description	Page
INTRO-1	Geometric Tolerance Symbols.....	INTRO-2
INTRO-2	Weld Symbols.....	INTRO-4
INTRO-3	Symbols.....	INTRO-5
1-1	KX 200 without Mounting Equipment.....	1-3
1-2	KX 200 with Retrofit Adapter.....	1-4
1-3	HMI Illumination.....	1-6
2-1	Type Plate (Example).....	2-3
2-2	KX 200 - Preparation for Retrofit Adapter Installation.....	2-8
2-3	KX 200 - Retrofit Adapter Installation.....	2-10
2-4	Removing Guide Pins.....	2-12
2-5	Guide Pins Removed.....	2-13
2-6	M3x5 Screws Installed.....	2-14
2-7	Reposition NAV and GS coax.....	2-16
2-8	Reposition COM coax.....	2-18
2-9	Install Retrofit Adapter.....	2-20
2-10	Secure SMA Connectors to NAV and GS.....	2-22
2-11	Connect and Lock the COM Antenna Connector.....	2-24
2-12	KX 200 - Locking Mechanism.....	2-25
2-13	Dimensions KX 200 with Retrofit Adapter.....	2-27
2-14	Dimensions - Retrofit Adapter.....	2-29
2-15	KX 200 - Connector Layout (Rear).....	2-31
2-16	KX 200 with Retrofit Adapter - Connector Layout (Rear).....	2-36
2-17	Grounding Bolt.....	2-42
2-18	KX 200 with Retrofit Adapter - Connector Layout (Rear).....	2-44
2-19	Wiring KX 200 with Retrofit Adapter - Aircraft Installation (Example).....	2-46
2-20	Wiring KX 200 and Retrofit Adapter - Power Supply.....	2-48
2-21	Wiring KX 200 and 14 V Retrofit Adapter - Power Supply.....	2-50
2-22	Wiring KX 200 and Retrofit Adapter - Antennas.....	2-52
2-23	Wiring KX 200 and Retrofit Adapter - Single Headphones, Balanced.....	2-54
2-24	Wiring KX 200 and Retrofit Adapter - Two Headphones, Balanced.....	2-55
2-25	Wiring KX 200 and Retrofit Adapter - Single Headphones, Unbalanced.....	2-57
2-26	Wiring KX 200 and Retrofit Adapter - Two Headphones, Unbalanced.....	2-58
2-27	Wiring KX 200 and Retrofit Adapter - Standard Microphone.....	2-60

EFFECTIVITY

ALL

34-24-61

Page TC-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)

LIST OF FIGURES (Cont)

Figure	Description	Page
2-28	Wiring KX 200 and Retrofit Adapter - NAV Audio Output, Balanced.....	2-62
2-29	Wiring KX 200 and Retrofit Adapter - NAV Audio Output, Unbalanced.....	2-63
2-30	Wiring KX 200 and Retrofit Adapter - VOR/LOC/Glide Slope Interface.....	2-65
2-31	Diagram - DME Tuning (Waveform).....	2-67
2-32	Wiring KX 200 and Retrofit Adapter - DME Tuning.....	2-69
2-33	Wiring KX 200 and Retrofit Adapter - PTT.....	2-71
2-34	Wiring KX 200 and Retrofit Adapter - Intercom Control.....	2-73
2-35	Wiring KX 200 and Retrofit Adapter - Manual Intercom Operation.....	2-75
2-36	Wiring KX 200 and Retrofit Adapter - Frequency Exchange.....	2-77
2-37	Wiring KX 200 and 14 V Retrofit Adapter - Frequency Exchange.....	2-79
2-38	"PASSWORD".....	2-83
2-39	Installation Mode - Main and Menu Screen (CH).....	2-85
2-40	Installation Mode - Main and Menu Screen (CH).....	2-87
2-41	Installation Mode - Main and Menu Screen (CH).....	2-89
2-42	Software Identification - Control Head.....	2-91
2-43	Example CH Subsystem Software Info.....	2-93
2-44	Example CH Software Info.....	2-95
2-45	Brightness Control (Dimming Input).....	2-97
2-46	Change Brightness Level.....	2-99
2-47	Dimming Curve for Display.....	2-101
2-48	Dimming Curve Parameter.....	2-103
2-49	Clear NV-Memory Error.....	2-106
2-50	Clear NV-Memory Error.....	2-120
3-1	KX 200 User Interface.....	3-2
3-2	KX 200 - COM Main View.....	3-5
3-3	KX 200 - COM Menu View.....	3-7
3-4	KX 200 - COM Recent Frequency View.....	3-9
3-5	KX 200 - COM User Frequency View.....	3-11
3-6	KX 200 - COM Error View.....	3-13
3-7	KX 200 - COM Warning View.....	3-15
3-8	KX 200 - COM Incorrect Parameter View.....	3-17
3-9	KX 200 - NAV Main View.....	3-19
3-10	KX 200 - NAV Menu View.....	3-21

EFFECTIVITY

ALL

34-24-61

Page TC-4
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)
LIST OF FIGURES (Cont)

Figure	Description	Page
3-11	KX 200 - NAV Recent Frequency View.....	3-23
3-12	KX 200 - NAV User Frequency View.....	3-25
3-13	KX 200 - NAV Error View.....	3-27
3-14	KX 200 - NAV Warning View.....	3-29
3-15	KX 200 - Ready for Operation (Example).....	3-31
3-16	KX 200 - COM Mode Active (Example).....	3-33
3-17	Receive Mode.....	3-35
3-18	Transmit Mode.....	3-37
3-19	Select a Standby Frequency.....	3-40
3-20	Select an Active Frequency.....	3-42
3-21	Recent Frequency List.....	3-44
3-22	User Frequency List.....	3-46
3-23	User Frequency List.....	3-48
3-24	Confirm the Selection.....	3-50
3-25	Edit Station ID.....	3-52
3-26	Edit Frequency.....	3-54
3-27	Delete List Entry.....	3-56
3-28	Squelch ON.....	3-58
3-29	Intercom Active.....	3-61
3-30	Intercom Inactive.....	3-63
3-31	Speaker Active.....	3-65
3-32	KX 200 - COM Menu View.....	3-67
3-33	KX 200 - COM Error View.....	3-69
3-34	KX 200 - COM Warning View.....	3-70
3-35	KX 200 - NAV Mode Active (Example).....	3-72
3-36	Localizer Channel Selected.....	3-74
3-37	Audio Mode Control.....	3-76
3-38	Standby Frequency Frame.....	3-78
3-39	Change Active and Standby Frequency.....	3-80
3-40	Recent Frequency List.....	3-82
3-41	User Frequency List.....	3-84
3-42	User Frequency List.....	3-86
3-43	Confirm Selection.....	3-88

EFFECTIVITY

ALL

34-24-61

 Page TC-5
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)
LIST OF FIGURES (Cont)

Figure	Description	Page
3-44	Edit Station ID.....	3-90
3-45	Edit Frequency.....	3-92
3-46	Delete List Entry.....	3-94
3-47	KX 200 - NAV Menu View.....	3-96
3-48	KX 200 - NAV Error View.....	3-98
3-49	KX 200 - NAV Warning View.....	3-99

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

TABLE OF CONTENTS (Cont)
LIST OF TABLES

Table	Description	Page
INTRO-1	List of Acronyms and Abbreviations	INTRO-6
INTRO-2	Service Information Documents	INTRO-9
2-1	Summary of Installation Mode Default Settings	2-80
3-1	Error List	3-100

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

INTRODUCTION

1. How to Use This Manual

A. General

- (1) This publication describes the equipment shown on the Title page.
- (2) The type plate on your device shows the part number for identification purposes. Refer to Figure 2-1 for nameplate identification data.
- (3) Standard maintenance procedures that technicians must know are not given in this manual.
- (4) This publication is written in agreement with the ATA Specification.
- (5) Warnings, cautions, and notes in this manual give the data that follows:
 - A WARNING gives a condition or tells personnel what part of an operation or maintenance procedure, which if not complied with, can cause injury or death.
 - A CAUTION gives a condition or tells personnel what part of an operation or maintenance procedure, which if not complied with, can cause damage to the equipment.
 - A NOTE gives data, not commands. The NOTE helps personnel when they do the related instruction.
 - DANGER indicates a hazardous situation which, if not prevented, will result in death or serious injury.
 - SAFETY INSTRUCTIONS (or equivalent) signs indicate specific safety-related instructions or procedures.
- (6) Warnings and cautions go before the applicable paragraph or step. Notes follow the applicable paragraph or step.

B. Symbols

- (1) The symbols and special characters are in agreement with IEEE Publication 260 and IEC Publication 27. Special characters in text are spelled out.
- (2) The signal mnemonics, unit control designators, and test designators are shown in capital letters.
- (3) The signal names followed by an "*" show an active low signal.
- (4) Some figures in this manual incorporate standard geometric characteristic symbols. Refer to Figure INTRO-1 for the geometric characteristic symbols.



INSTALLATION AND OPERATION MANUAL

89000002-120

CHARACTERISTIC SYMBOLS

	FLATNESS		PERPENDICULARITY
	STRAIGHTNESS		PARALLELISM
	CIRCULARITY		ANGULARITY
	CYLINDRICITY		CIRCULAR RUN OUT
	PROFILE OF A SURFACE		POSITION
	PROFILE OF A LINE		SYMMETRY
	CONCENTRICITY		


MODIFYING SYMBOLS

- (M) MAXIMUM MATERIAL CONDITION (MMC)
- (S) REGARDLESS OF FEATURE SIZE (RFS)
- (P) PROJECTED TOLERANCE ZONE

OTHER SYMBOLS

- DIAMETER
- NEGATIVE NOTATION

FEATURE CONTROL FRAME



EXCEPT WHEN THE DATUM(S) OR CONTROLLED FEATURE IS A PLANE SURFACE, A MODIFIER IS REQUIRED PER GENERAL RULE 1 OR MAY BE USED TO ALTER GENERAL RULE 2

ICN-HNYWL-0000233099-001-99

Figure INTRO-1. (Sheet 1 of 2) Geometric Tolerance Symbols

EFFECTIVITY

ALL

34-24-61

Page INTRO-2
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

GENERAL RULES

1. POSITION (Φ) TOLERANCES AND THEIR RELATED DATUMS APPLY AT MMC OR RFS AS SPECIFIED IN THE FEATURE CONTROL FRAME.
2. EXCEPT FOR POSITION (Φ), ALL TOLERANCES AND THEIR RELATED DATUMS APPLY RFS UNLESS OTHERWISE SPECIFIED.
3. ALL GEOMETRIC TOLERANCES ARE SPECIFIED AS TOTAL VALUES (TOTAL DIAMETER, TOTAL THICKNESS, TOTAL WIDTH, OR TOTAL ON RADIUS).
4. WHEN TWO DATUM FEATURES ARE REFERENCED IN HYPHENATED FORM, $\boxed{A-B}$, A SINGLE DATUM IS ESTABLISHED BY THE TWO FEATURES.
5. WHEN TWO OR THREE DATUMS ARE REFERENCED IN SUCCEEDING FRAMES, $\boxed{A} \boxed{B} \boxed{C}$, THE ORDER OF PRECEDENCE IS LEFT TO RIGHT.

SAMPLE INTERPRETATIONS

$\boxed{-A-}$ THIS IS DATUM FEATURE A WHICH IS USED TO CREATE DATUM A IN THE PROCESSING EQUIPMENT.

$\boxed{\parallel} \boxed{0.010 (0.25)}$ THIS SURFACE MUST BE FLAT WITHIN 0.010 IN. (0.25 MM) TOTAL (MEETING EITHER SYSTEM WILL ACCEPT THE PART).

$\boxed{\parallel} \boxed{0.010 (0.25)} \boxed{B}$ THIS IS DATUM FEATURE C AND, RFS MUST BE PARALLEL TO DATUM B, RFS, WITHIN 0.010 IN. (0.25 MM) TOTAL.

$\boxed{-C-}$

$\boxed{\nearrow} \boxed{0.0005 (0.013)} \boxed{A-B}$ EACH CIRCULAR ELEMENT OF THIS FEATURE, RFS, MUST NOT RUN OUT MORE THAN 0.0005 IN. (0.013 MM) FIM, WITH RESPECT TO THE DATUM ESTABLISHED BY FEATURES A AND B, BOTH RFS.

$\boxed{\Phi} \boxed{\varnothing 0.010 (0.25)} \boxed{(M)} \boxed{A} \boxed{B} \boxed{(M)} \boxed{C} \boxed{(M)}$ THE AXIS OF THIS FEATURE, WHEN THIS FEATURE IS AT MMC, MUST BE LOCATED WITHIN 0.010 IN. (0.25 MM) DIAMETER OF THE TRUE (BASIC) LOCATION ESTABLISHED IN RELATION TO THE PRIMARY SURFACE DATUM A, SECONDARY DATUM B AT MMC, AND TERTIARY DATUM C AT MMC.

$\boxed{\perp} \boxed{\varnothing 0.010 (0.25)} \boxed{(M)} \boxed{A}$ THE AXIS OF THIS FEATURE, WHEN THIS FEATURE IS AT MMC, MUST BE PERPENDICULAR TO DATUM A, RFS, WITHIN A 0.010 IN. (0.25 MM) DIAMETER TOLERANCE ZONE PROJECTED 0.500 IN. (12.7 MM) ABOVE THE SURFACE.

$\boxed{0.500 (12.7)} \boxed{(P)}$

$\boxed{\angle} \boxed{\parallel}$ THE ANGULAR ORIENTATION OF THIS FEATURE NEED NOT BE CONTROLLED WITH RESPECT TO ANY OTHER FEATURE.

ICN-HNYWL-0000233100-001-99

Figure INTRO-1. (Sheet 2 of 2) Geometric Tolerance Symbols

- (5) Some figures in this manual incorporate standard weld symbols. Refer to Figure INTRO-2 for the weld symbols.

EFFECTIVITY

ALL

34-24-61

Page INTRO-3
13 Aug 2025




INSTALLATION AND OPERATION MANUAL
89000002-120

BASIC WELD SYMBOLS AND THEIR LOCATION SIGNIFICANCE								
LOCATION SIGNIFICANCE	FILLET	PLUG OR SLOT	SPOT OR PROJECTION	SEAM	BACK OR BACKING	SURFACING	FLANGE	
							EDGE	CORNER
ARROW SIDE								
OTHER SIDE								
BOTH SIDES		NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED
NO ARROW SIDE OR OTHER SIDE SIGNIFICANCE	NOT USED	NOT USED			NOT USED		NOT USED	NOT USED

BASIC WELD SYMBOLS AND THEIR LOCATION SIGNIFICANCE							
LOCATION SIGNIFICANCE	GROOVE (FLASH OR UPSET)						
	SQUARE	V	BEVEL	U	J	FLARE V	FLARE BEVEL
ARROW SIDE							
OTHER SIDE							
BOTH SIDES							
NO ARROW SIDE OR OTHER SIDE SIGNIFICANCE	NOT USED EXCEPT FOR FLASH OR UPSET WELDS	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED	NOT USED

SUPPLEMENTARY SYMBOLS					
WELD ALL AROUND	FIELD WELD	MELT-THRU	CONTOUR		
			FLUSH	CONVEX	CONCAVE



ICN-HNYWL-0000112401-001-99

Figure INTRO-2. Weld Symbols

(6) The symbols in Figure INTRO-3 show ESDS and moisture sensitive devices.


UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ESDS



MOISTURE SENSITIVE

ICN-HNYWL-0000233101-001-99

Figure INTRO-3. Symbols

C. Disposal

CAUTION: THE PACKAGING MATERIAL IS INFLAMMABLE, BY BURNING, TOXIC FUMES MAY DEVELOP.

- (1) This product contains materials that fall under the special disposal regulation. We recommend the disposal of such materials in accordance with the current environmental laws.
 - (a) Dispose circuit boards by a technical waste dump which is approved to take on e.g. electrolytic aluminum capacitors. Do under no circumstances dump the circuit boards with normal waste dump.

D. Warranty Conditions

CAUTION: THE DEVICE(S) MAY BE INSTALLED ON AN AIRCRAFT ONLY BY AN APPROVED AERONAUTICAL COMPANY (E.G. PART 145) WHICH SHALL ALSO EXAMINE THE INSTALLATION.

- (1) Any change made by the user excludes any liability on our part (excluding the work described in this manual).
 - (a) The device must not be opened.
 - (b) Do not make any modifications to the device, except for those described in the manual.
 - (c) Make connections to the inputs, outputs and interfaces only in the manner described in the manual.
 - (d) Install the devices related to the instructions. We cannot give any guarantee for other methods.

E. Conditions of Utilization

- (1) With this device you bought a product which was manufactured and tested before delivery with the utmost care.
- (2) Please take your time to read the instructions which you ought to follow closely during installation and operation.
- (3) Otherwise all claims under the warranty will become void and a decreased service life or even damages must be expected.

EFFECTIVITY _____

ALL

34-24-61

Page INTRO-5
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

CAUTION: THE USER IS RESPONSIBLE FOR PROTECTIVE COVERS AND/OR ADDITIONAL SAFETY MEASURES IN ORDER TO PREVENT DAMAGES TO PERSONS AND ELECTRIC ACCIDENTS.

F. Additional Conditions of Utilization

- (1) Please refer to Section 1, Paragraph G.

G. Non-Warranty Clause

- (1) We checked the contents of this publication for compliance with the associated hard and software. We can, however, not exclude discrepancies and do thus not accept any liability for the exact compliance. The information in this publication is regularly checked, necessary corrections will be part of the subsequent publications.

2. Customer Support

A. Honeywell Aerospace Contact Team

- (1) The Honeywell Aerospace Contact Team is available 24/7 to support customers around the world.

Contact Us: <https://aerospace.honeywell.com/us/en/support-and-resources/contact-us>

B. Warranty Registration, Technical Support and Sales Support

- (1) Tech Support - techsupport@bendixking.com or call 1-505-903-6148 and Press 2.
(2) Warranty Registration -

<https://aerospace.honeywell.com/us/en/support-and-resources/contact-us/forms/bendixking/bk-warranty-registration>.

- (3) Warranty Claims, Repairs and Exchanges are required to go through an authorized Honeywell General Aviation (aka BendixKing) Dealer. If the end customer goes straight to Honeywell, it will cause delays and you will be referred to an Authorized Dealer.
(4) To locate a Honeywell GA Dealer, go to <https://www.bendixking.com/en/buy/locate-dealer>.
(5) Honeywell Sales Representative - <https://www.bendixking.com/en/buy/sales-team>
(6) For information about any Honeywell General Aviation products or legacy BendixKing products - <https://www.bendixking.com/en/buy/locate-dealer>.

3. Acronyms and Abbreviations

A. General

- (1) The abbreviations are used in agreement with ASME Y14.38.
(2) Acronyms and non-standard abbreviations used in this publication are as follows:

Table INTRO-1. List of Acronyms and Abbreviations

Term	Full Term
A	Ampere
AlMg	Aluminum-Magnesium Alloy
ASME	American Society of Mechanical Engineers
ATA	Air Transport Association

EFFECTIVITY

ALL

34-24-61

Page INTRO-6
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table INTRO-1. List of Acronyms and Abbreviations (Cont)

Term	Full Term
AWG	American Wire Gauge
BNC	Bayonet Neill Concelman
CH	Channel, Control Head
COM	Communication area (display), Communication port
EASA	European Union Aviation Safety Agency
ESDS	Electrostatic Discharge Sensitive
ETSO	European Technical Standard Order
EUROCAE	European Organization for Civil Aviation Equipment
FAA	Federal Aviation Administration
FCC	Federal Communications Commission
FREQ	Frequency
GS	Glide Slope
HMI	Human Machine Interface
HW	Hardware
Hz	Hertz
IC	Intercom
ID	Identifier
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
ILS	Instrument Landing System
IOM	installation and operation manual
LOC	Localizer
MHz	Megahertz
N/A	Not Applicable
NAV	Navigation, Navigation area (display), Navigation port
Nm	Newton Meter
No.	number
PBIT	Power-On Built-In Test
PN	Part Number
PTT	Push-To-Talk
PWR	Power
RCENT	Recent
RX	Receive, Receiver

EFFECTIVITY

ALL

34-24-61

Page INTRO-7
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

Table INTRO-1. List of Acronyms and Abbreviations (Cont)

Term	Full Term
SIL	Service Information Letter
SQ	Squelch
STB	Standby (frequency)
SW	Software
TR	temporary revision
TSO	Technical Standard Order
TX	Transmit, Transmission, Transmitter, Transceiver
V	Volt
VDC	Voltage Direct Current
VHF	Very High Frequency
VOL	Volume
VOR	VHF Omnidirectional Radio Range Localizer
VOX	Voice Operated Switch
VSWR	Voltage Standing Wave Ratio
W	Watt
cd/m ²	Candela Per Square Meter
dB	Decibel
dBm	Power Ratio in Decibel referenced to 1 mW
in-lb	Inch-Pound
kHz	Kilohertz
kg	Kilogram
km	kilometer
lb	Pound
mA	Milliampere
mV	Millivolt
mW	Milliwatt
mm	Millimeter
°C	Degree Celsius
°F	Degree Fahrenheit
Ω	Resistance in Ohm

EFFECTIVITY

ALL

34-24-61

Page INTRO-8
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

4. Service Information Documents

A. **Applicable Service Information Documents**

- (1) Refer to Table INTRO-2 for other applicable service information documents not listed in the Service Bulletin List.

Table INTRO-2. Service Information Documents

Document Type	Document Number/ Revision Number	Title	Date Put In Manual
SIL	D202504004738	Incorrect KX 200 Nav/Com Radio and Retrofit Adapter part numbers on some labels attached to units.	13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

SECTION 1 – GENERAL DESCRIPTION

A. General

- (1) This manual describes the components of the KX 200 NAV/COM transceiver. The type plate on your device shows the part number for identification purposes. (Refer to Figure 2-1).
- (2) Before starting operation of the device(s) please read this manual carefully, with particular attention to the description referring to your device(s).
- (3) Components of the KX 200 NAV/COM Transceiver.⁽¹⁾

NOTES:

(1) Some figures in this manual are for basic understanding and can be different to the design.

B. Purpose of Equipment

- (1) The KX 200 series is a modern family of navigation and communication equipment.
- (2) The KX 200 is a single block device with control panel and combines a navigation receiver (NAV) and a VHF communication transceiver (COM) in one device.
 - (a) The NAV subsystem and the COM subsystem work independently each other.
 - (b) The control head with modern HMI design works as interface between the pilot and the NAV/COM subsystems.
 - (c) All control elements and indicators are on the front panel.
 - (d) The devices(s) are made for cockpit installation in fixed wing or rotary wing aircraft.
 - (e) The devices(s) are compatible with 14 and 28 V systems.
- (3) Features COM subsystem:
 - (a) The devices are for voice communication between aircraft or between aircraft and ground. The devices use the VHF-band between 118.000 - 136.9916 MHz respectively 136.9750 MHz with a selectable channel spacing of 8.33 or 25 kHz.
 - (b) The sensitive receiver complies with the requirements of ED-23C.
 - 1 It includes the ability to work in the offset-carrier (climax) operation in 25 kHz and 8.33 kHz channel spacing.
 - (c) The receiver includes a monitoring mode (dual watch). This is for monitoring two different VHF frequency channels at the same time while the communication on the active frequency.
 - (d) Squelch function.
 - (e) The intercom function is for voice communication between aircraft crew (pilot and copilot) and passengers.
 - (f) The extended built-in intercom can work as:
 - 1 4-way intercom with isolation mode - passengers could continue conversation or listen to the music from a MP3 player at the same time while pilots talk through intercom or communicate with the tower.
 - (g) The device has a non-volatile memory for the storage of:
 - 1 50 channels for storage of VHF frequencies with customized labels.

EFFECTIVITY

ALL

34-24-61

Page 1-1
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

- 2 10 recently selected VHF frequencies (LAST).
- (4) Features NAV subsystem:
 - (a) The NAV subsystem includes the VHF omnidirectional receiver (VOR), localizer (LOC) and glide slope (GS).
 - 1 The VOR receiver tunes frequencies between 108.00 - 117.95 MHz.
 - a The VOR receiver provides a demodulated composite signal. It can be connected to the external converter or directly to the analog indicator with embedded composite signal converter.
 - 2 The localizer receiver provides a demodulated composite signal. It can be connected to the external converter or directly to the analog indicator with embedded composite signal converter.
 - 3 The glide slope receiver tunes frequencies between 329.15 - 335.00 MHz.
 - a The receiver includes an internal converter to change the composite signals to digital and analog signals up, down and flag.
 - 4 The device has a serial interface to tune the external DME equipment.
 - 5 The device has a non-volatile memory for the storage of:
 - a 50 channels for storage of NAV frequencies.
 - b 10 recently selected NAV frequencies (LAST).

C. General Notices

- (1) The word "frequency" is also used in the sense of "channel name", as defined in EUROCAE, document ED 23C chapter 1.3.2, Volume II.
- (2) In this document the word "memory channel" or "channel" is also used in the sense of a memory position identified by a channel number, where a frequency is stored for later use.


D. Variants Overview

- (1) Device for panel installation.

NOTE: Install Kit and Tray for panel installation will be offered in future release.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092219-001-01

Figure 1-1. KX 200 without Mounting Equipment

EFFECTIVITY


ALL

34-24-61

Page 1-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092220-001-01

Figure 1-2. KX 200 with Retrofit Adapter

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(2) Software Status

(a) Refer to Section 2, Paragraph C., Step (7) for description.

E. Associated Devices

(1) These devices can operate with KX 200:

Device	Function
Headset	Aviation headsets (div. manufacturers)

(2) This manual describes the components of the KX 200 NAV/COM transceivers. For other devices please refer to the related manuals.

F. Scope of Functionality

(1) The KX 200 is a single block device with control panel. It combines a navigation receiver (NAV) and a VHF communication transceiver (COM) in one device.

(2) HMI Functionality

(a) The front panel with display is divided into a COM area and a NAV area with:

- 1 Display (LCD)
- 2 1 single rotary knob with pushbutton (VOL)
- 3 1 dual rotary knob with pushbutton (FREQ)
- 4 8 pushbuttons for dedicated operation:
 - a COM, RCNT, MON and CTR (COM transfer)
 - b NAV, RCT, ID and NTR (NAV transfer).
- 5 Ambient light sensor
- 6 MicroSD card slot (future functionality for prepared channel database)
- 7 Access to the locking mechanism.

(b) HMI & Illumination

- 1 The front panel has illuminated and non-illuminated inscriptions.
- 2 The display and front panel illumination are dimmable.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092222-001-01

Figure 1-3. HMI Illumination

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(3) Operating Modes

(a) The device has different modes for settings and operation:

- 1 Pilot Mode - for operation during flight
- 2 Installation Mode - for configuration of the device parameters and read out of device and software identification data
- 3 Database Update Mode - for updating database with named channels for COM and NAV operation (future functionality)
- 4 Maintenance Mode - (factory only)
- 5 Software Update Mode - (factory only).

(4) COM Functionalities

(a) Audio Outputs

- 1 The transceivers have four configurable outputs:
 - a Headphone 1 output:
 - (1) Rated output power is 300 mW into 75 Ω .
 - b Headphone 2 output:
 - (1) Rated output power is 200 mW into 75 Ω .
 - c Speaker output:
 - (1) Rated output power is 4 W into 4 Ω .
 - d LINE-OUT output:
 - (1) For ground station use only.

(b) Mike Inputs

- 1 The transceivers have four microphone inputs:
 - a Standard microphone input 1 (STD_MIKE1)
 - b Standard microphone input 2 (STD_MIKE2)
 - c Standard microphone input 3 (STD_MIKE3)
 - d Dynamic microphone input (DYN_MIKE).
- 2 Each input can operate with one single microphone or with two microphones of the same type connected in parallel.

(c) AF Auxiliary Input

- 1 The AF auxiliary input is the interface to connect an external audio source (e.g. other radio services, music-player).
 - a The interconnection of multiple external audio sources on this port makes an additional external decoupling/isolation resistor necessary.
 - b The external audio is audible only when the transceiver is in receiving mode.

EFFECTIVITY

ALL

34-24-61

Page 1-7
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

- c The individual audio volume is set directly at the external equipment.
 - (d) PTT Management
 - 1 Stuck PTT detection.
 - a The transmission time is limited to avoid uninterrupted transmission because of a stuck PTT and to prevent damage because of overheating.
 - b A message "STUCK PTT" (transmission was interrupted) is shown on the display.
 - (e) Sidetone
 - 1 The sidetone is available on the headphone output during transmission.
 - 2 The sidetone volume depends on to the intercom volume adjustment.
 - (f) Squelch Operation
 - 1 The squelch (muting) circuit suppresses signals with strong signal noise.
 - 2 There are two kinds of squelch methods implemented, carrier- and noise-squelch.
 - a The carrier-squelch depends on the signal strength and is adjustable in configuration setup.
 - b The noise-squelch depends on the noise level and is adjustable in the user menu.
 - (g) Frequency Monitoring
 - 1 The frequency monitoring is a dual watch function.
 - a The device monitors frequencies on two different channels, active & standby frequency at the same time.
 - b The signal of the active frequency is always audible it has priority at all times.
 - (h) Intercom Operation
 - 1 The built-in intercom circuit is for internal communication between pilots and passengers with connected headsets.
 - 2 The COM subsystem has two intercom circuits:
 - a "Front row" and "Back row".
 - b You can connect a maximum of four headsets, e.g. the pilot & copilot headsets to the first circuit and two passenger headsets to the second circuit.
 - (i) Memory Channels (NAV/COM)
 - 1 The device can store 50+10 frequencies each for the COM and NAV subsystem.
 - a The user can give a defined text label to each stored frequency.
 - 2 The last 10 (active) frequencies selected are automatically stored as "Recent" channels.



INSTALLATION AND OPERATION MANUAL

89000002-120

(5) NAV Functionalities

(a) VOR/LOC/GS

- 1 The NAV subsystem has one or two receivers (optional):
 - a VOR/LOC receiver: frequency range 108 - 117.95 MHz
 - b GS (Glide Slope) receiver frequency range 329.15 - 335.00 MHz.
- 2 The VOR/LOC system, on the base of the VOR/LOC antenna signal, supplies:
 - a Horizontal deviation from the pilot's selected course or deviation from the localizer path
 - b Validity of the shown horizontal deviation
 - c If an aircraft is flying toward or away from an omnirange station.
- 3 The GS system, on the base of the GS antenna signal, supplies:
 - a Vertical deviation from the selected glide path
 - b Validity of the shown vertical deviation.

(b) ILS Energize

- 1 ILS energize output - active when ILS frequency is selected on KX 200 NAV/COM transceiver.

(c) DME Channel Line

- 1 The device has a serial interface to tune the external DME equipment.
- 2 Example: When the pilot changes the radio channel on the device front panel, the DME equipment change automatically to the related DME channel.
- 3 The NAV subsystem supports DME transponder channel control with use of DME channel lines.
 - DME_CLOCK_OUT
 - DME_DATA_OUT
 - DME_COMM_IN
 - RNAV_MODE_IN
 - RNAV_CHREQ_IN

(d) NAV Audio Interface

- 1 NAV volume regulation
- 2 NAV audio mode functions selectable as "Voice Only", "Ident Only" and "Voice and Ident".

(6) Self-Tests (NAV/COM)

(a) The tests monitor most of the internal circuits against failures.

- 1 PBIT (Power-ON Built-In Test):
 - a Self-test upon power-on.

EFFECTIVITY

ALL

34-24-61

Page 1-9
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

2 CBIT (Continuous Built-In Test):a Self-test runs continuously in the background.

(7) Replacement of KX155

- (a) The KX 200 NAV/COM transceiver with related retrofit adapter is compatible with:
- KX155.

(8) Configuration Setup - Installation Mode (NAV/COM)

- (a) The password-protected configuration setup is for the configuration of installation and device parameters such as mike sensitivity, mike type selection, speaker enable/disable and other parameters.

(9) Software Update Mode and Maintenance Mode (NAV/COM)

- (a) The software update mode and maintenance mode are special modes.
- (b) These modes are for use by authorized maintenance organizations only.

G. Safety-Conscious Utilization

CAUTION: THE DEVICE(S) MUST BE INSTALLED ON AN AIRCRAFT ONLY BY AN APPROVED AERONAUTICAL COMPANY (EXAMPLE PART 145) WHICH MUST ALSO EXAMINE THE INSTALLATION.

- Safety Instructions**
- Use the product only in the specified conditions, refer to Section 1, Paragraph J.
 - Power supply:
 - Do not connect the device to AC sources.
 - Make sure that the device is connected to the mandatory DC source, refer to Paragraph J.
 - Do not connect the device with reversed polarity to the DC source.
 - Circuit breaker:
 - Use the recommended fuses in the power supply line for the protection of the application, refer to Paragraph J.

NOTE : Excessive pulses on the DC bus of the aircraft can cause damage on electrical circuits of any installed instrument.

NOTE : Do not turn on the device during engine start or shutdown.



INSTALLATION AND OPERATION MANUAL

89000002-120

H. Cleaning and Disinfection of Devices**(1) Cleaning:**

- (a) Within the framework of officially prescribed or recommended protective measures, it makes sense that devices and systems that are directly accessible to people, are disinfected as required. This particularly applies to the controls on avionics devices.

NOTE: Not all commercially available cleaning agents/disinfectants are suitable for use on the surfaces of our devices. Many of the agents contain solvents or greasing components that can cause undesired effects on the controls and the display.

Example:

- Do not use aggressive cleaning agents e.g. Acetone.
- These cleaning agents can cause damages.

(2) Procedure:

NOTE: Do not clean/disinfect the device(s) during operation.

(a) Device body and the controls:

- 1 Clean the device body and the controls with a clean, soft, lint free cloth moistened with clean water.

(3) Disinfection:**(a) To reduce the risk of infection:**

- 1 As a disinfectant, we recommend diluted monohydric alcohols such as Isopropanol or Ethanol.
- a Wear suitable protective gloves that are disinfected.
 - b Moisten a clean, soft, lint free cloth with the related liquid to clean all controls.
 - c Please comply with the usual protective measures when using monohydric alcohols for cleaning purposes.
- 2 Do not use spray bottles or evaporators to apply disinfectants or cleaning liquids to the Honeywell devices. Liquids could penetrate the devices and can result in damage.
- (b) LCD screen:**
- 1 Clean the LCD screen with a clean, soft, lint free cloth moistened with clean water and take care not to scratch the surface.
- 2 Cleaning agents suitable for cleaning TFT screens and LCD displays can also be used. Comply with the related instructions from manufacturer.

I. Restriction for Use

Safety Instructions The product is to be used inside the declared limits.

EFFECTIVITY

ALL

34-24-61

Page 1-11
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

J. Technical Data**(1) General Characteristics**

KX 200	Specification (General)
Nominal supply voltage	11.0 - 30.2 V
Emergency operation	min. 9.0 V
Current consumption	≤ 600 mA @ 14 VDC RX stand-by mode, no external equipment supplied from the device
	≤ 500 mA @ 28 VDC RX stand-by mode, no external equipment supplied from the device
	≤ 2000 mA @ 14 VDC RX stand-by mode, max. audio level on speaker output, 500 mA consumed by an external equipment supplied from the device
	≤ 1500 mA @ 28 VDC RX stand-by mode, max. audio level on speaker output, 500 mA consumed by an external equipment supplied from the device
	≤ 3500 mA @ 14 VDC TX mode (VSWR = 1.5:1 max., m ≥70%, 1 kHz), 500 mA consumed by an external equipment supplied from the device
	≤ 3000 mA @ 28 VDC TX mode (VSWR = 1.5:1 max., m ≥70%, 1 kHz), 500 mA consumed by an external equipment supplied from the device
	≤ 5500 mA @ 14 VDC TX mode (VSWR = 3:1 max., m ≥70%, 1 kHz), 500 mA consumed by an external equipment supplied from the device
	≤ 4500 mA @ 28 VDC TX mode (VSWR = 3:1 max., m ≥70%, 1 kHz), 500 mA consumed by an external equipment supplied from the device
Dimming control	0 - 5 V, 0 - 14 V or 0 - 28 V
Operating temperature	-4 to 131°F (-20 to 55°C)
Storage temperature	-22 to 158°F (-30 to 70°C)
Recommended external fuse protection in the application	10 A

(a) Display

KX 200	Specification (Display)
Display size	2 x 2.0 inch (51 X 51 mm) TFT LCD screen

EFFECTIVITY

ALL

34-24-61Page 1-12
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

KX 200	Specification (Display)	
Brightness	> 600 cd/m ²	
Contrast ratio	800:1	
Viewing angle	right/left	80°
	upper	80°
	lower	80°

(b) Speaker

KX 200	Specification (Speaker)
Usage	Speaker output
Type	Analog
Load impedance	4 Ω
Output power @4 Ω	4 W

(c) Dimensions & Weight

KX 200	Specification (Dimensions & Weight)	
Dimensions KX 200 HxWxD	2.1 x 6.3 x 10.5 inch (52.1 x 158.8 x 268 mm)	
Installation depth	8.8 inch (224 mm)	
Dimensions KX 200 with Retrofit Adapter HxWxD	2.1 x 6.3 x 11.1 inch (52.1 x 158.8 x 282.9 mm)	
Installation depth	9.4 inch (239.1 mm)	
Weight	KX 200:	3.2 $\pm$ 0.2 lb (1.45 $\pm$ 0.1 kg)
	Retrofit Adapter:	0.5 $\pm$ 0.04 lb (0.23 $\pm$ 0.02 kg)
Installation method	Panel mount 6.3 inch (160 mm), lock mechanism	
Case material	AlMg	

(d) Device Connectors - KX 200

KX 200	Specification (Device Connectors - KX 200)
COM P1	D-SUB 25 male
COM J1	D-SUB 25 female
NAV P1	D-SUB 25 male
COM antenna	BNC jack
NAV antenna	SMA jack
GS antenna	SMA jack
GND	M4 stud

(e) Device Connectors - KX 200 with Retrofit Adapter

EFFECTIVITY

ALL

34-24-61

Page 1-13
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

KX 200 with Retrofit Adapter	Specification (Device Connectors - KX 200 with Retrofit Adapter)
J401	Edge connector male 2x15 pin
J901	Edge connector male 2x18 pin
COM antenna (J801)	BNC jack w/o bayonet
NAV antenna (J301)	BNC jack w/o bayonet
GS antenna (J902)	BNC jack w/o bayonet

(2) COM Subsystem

KX 200	Specification (General)
Number of channel memory	50 + 10 Last
Channel labeling	Yes
Number of channels	8.33/25 kHz: 2280/760

(a) Receiver Data (COM)

KX 200	Specification (Receiver Data - COM)
Frequency range	118.000-136.991666 MHz
Channel spacing	8.33 / 25 kHz
Modulation	AM, A3E
Audio frequency response	350 - 2500 Hz @ 8.33 kHz channel spacing 350 - 3000 Hz (typically 300 - 3400 Hz) @ 25 kHz channel spacing
Sensitivity	≤ -93 dBm (typically -101 dBm) for AM 30%, 1000 Hz
Spurious response	≥ -33 dBm
Dual watch (MON)	YES
Climax operation	YES, Class H2 receiver
Frequency change notification	YES
Squelch threshold	6 - 26 dB
Single / multicarrier distortions	≤ 25% (typically ≤ 15%) for AM 85%

(b) Transmitter Data (COM)

KX 200	Specification (Transmitter Data - COM)
Transmitting power	≥ 8 W @ 14 VDC, ≥ 10 W @ 28 VDC
Modulation capability	≥ 70%, ≤ 95%
Frequency stability better than	± 5 ppm
Modulated audio distortion	≤ 15%

EFFECTIVITY

ALL

34-24-61

Page 1-14
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

KX 200	Specification (Transmitter Data - COM)
Modulated audio response	350 - 2500 Hz
Stuck PTT	35 s

(c) Audio In-/Outputs (COM)

KX 200	Specification (Audio In-/Outputs - COM)
Number of headset outputs	2 (capable for 2 headsets in parallel)
Headset output power	100 mW @ 600 Ω
Number of speaker outputs	1
Speaker output power	≥ 4 W @ 4 Ω @ 14 V
Standard mike inputs	3
Dynamic mike inputs	1
Auxiliary audio inputs	1
Simple intercom	Number of audio paths: 2 Isolation mode: Yes

(d) Antenna (COM)

KX 200	Specification (Antenna - COM)
Direction	Bidirectional
Type	RF signal
Nominal impedance	50 Ω
Operating frequency	118 - 137 MHz

(3) NAV Subsystem

(a) Receiver Data (NAV)

KX 200	Specification (Receiver Data - NAV)
Number of channel memory	50 + 10 Last
Frequency range	VOR/LOC: 108 - 117.95 MHz
	GS: 329.15 - 335.00 MHz
Sensitivity	-93 dBm, -107 dBm (typically)
VOR/LOC output	Composite signal for external VOR/LOC converter and indicator
Auxiliary power supply output	up 500 mA
ILS energize output	Open collector to ground discrete output
DME channeling	Serial DME channeling provided for KN 62A, KN 63, KN 64

EFFECTIVITY

ALL

34-24-61

Page 1-15
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

KX 200	Specification (Receiver Data - NAV)
Audio output power	$\geq 100 \text{ mW @ } 500 \Omega, \geq 100 \text{ mW @ } 600 \Omega$
Audio output mode	VOICE/IDENT/AUDIO

(b) Antennas (NAV)

KX 200	Specification (Antennas - NAV)
Direction	Input
Type	RF signal
Nominal impedance	50Ω
Operating frequency	VOR/LOC: 108 - 117.95 MHz GS: 329.15 - 335.00 MHz

(4) Software

- (a) The design and development processes used for device software follow the rules given in EUROCAE/RTCA Document ED-12C/DO-178C; "Software Considerations in Airborne System and Equipment Certification".

COM subsystem: Design Assurance Level (DAL) "C"

NAV subsystem: Design Assurance Level (DAL) "B"

Control Head: Design Assurance Level (DAL) "B"

(5) Hardware

- (a) The devices do not contain Complex Electronic Hardware (CEH).

(6) Continued Airworthiness

- (a) A regular maintenance of the devices is not necessary:

1 The maintenance is specified as "on condition" only.

2 It is recommended to make a test of the frequency accuracy of the airborne transceiver after 7 years.

(7) Environmental Conditions KX 200

- (a) The tests were done in accordance with EUROCAE/RTCA ED-14G/DO-160G under consideration of the recorded environmental categories and conditions:

Environmental Condition	Section	Cat.	Remarks
Temperature / Altitude	4	C4	-
Ground Survival Low Temperature	4.5.1	C4	-67°F (-55°C)
Short-Time Operating Low Temperature	4.5.1	C4	-4°F (-20°C)
Operating Low Temperature	4.5.2	C4	-4°F (-20°C)
Ground Survival High Temperature	4.5.3	C4	185°F (85°C)

EFFECTIVITY

ALL

34-24-61

Page 1-16
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

Environmental Condition	Section	Cat.	Remarks
Short-Time Operating High Temperature	4.5.3	C4	158°F (70°C)
Operating High Temperature	4.5.4	C4	131°F (55°C)
In-Flight Loss of Cooling	4.5.5	X	No forced cooling required
Altitude	4.6.1	C4	35000 ft (11 km)
Decompression	4.6.2	C4	-
Overpressure	4.6.3	C4	N/A
Temperature Variation	5	B	41°F (5°C) per minute
Humidity	6	A	standard
Shock & Crash Safety	7	B	Fixed-wing and helicopter, standard
Vibration	8	S+U	Curve M for fixed wing aircraft Curve G for helicopter or U2 (F&F1)
Explosion Atmosphere	9	X	-
Waterproofness	10	X	-
Fluids Susceptibilities	11	X	-
Sand and Dust	12	X	-
Fungus Resistance	13	X	-
Salt Fog	14	X	-
Magnetic Effect	15	Z	≤ 1° deflection at 0.3 m
Power Input	16	B	DC installations with battery of significant capacity
Voltage Spike	17	A	High degree of protections against voltage spikes
Audio Freq. Conducted Susceptibility	18	B	DC installations with battery of significant capacity
Induced Signal Susceptibility	19	AC	Primary power DC
Radio Frequency Susceptibility	20	TT	High intensity radiated fields for systems with moderate criticality
Emission of Radio Frequency Energy	21	B	Equipment where interference should be controlled to a tolerable level
Lightning Induced Transients Susceptibility	22	A1E3X	Pin test waveform A, level 1 Cable bundle test waveform E, level 3
Lightning Direct Effects	23	X	-
Icing	24	X	-

EFFECTIVITY

ALL

34-24-61

Page 1-17
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

Environmental Condition	Section	Cat.	Remarks
Electrostatic Discharge (ESD)	25	A	Equipment operated in an aerospace environment
Fire, Flammability	26	C	-

(8) Certifications

Device	Specification
KX 200	EASA.210.10086103, in accordance with Commission Regulation (EU) No. 748/2012, Part 21, Section A, Subpart O and ETSO 2C128, 2C169A, 2C34f, 2C36f, 2C40c.
Retrofit Adapter 28 V	
Retrofit Adapter 14 V	

(9) FCC Approval

(a) Radiofrequency radiation exposure information:

- 1 The approved equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance of 20 inch (51 cm) between the radiator and your body.
- 2 This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

NOTE: The approved equipment has been tested and found to comply with the limits for a 'Licensed Non- Broadcast Station Transmitter' (VHF-Transceiver), pursuant to Part 87 of the FCC Rules. It is designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

NOTE: This device complies with Part 87 of the FCC rules. The antenna(s) used for this transmitter must be fixed-mounted on outdoor permanent structures.

3 Operation is subject to the two conditions that follow:

- a This device may not cause harmful interference, and
- b This device must accept any interference received, including interference that may cause undesired operation.

NOTE: Changes or modifications made to the approved equipment not expressly approved by Honeywell may void the FCC authorization to operate this equipment.

EFFECTIVITY

ALL

34-24-61

Page 1-18
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

SECTION 2 – INSTALLATION

A. General

- (1) This manual must be available during performance of all tasks.
- (2) The installation of the device(s) depends on the type of aircraft and its equipment and thus only general information can be given in this section.
- (3) Any deviations from the instructions in this document are the installer's responsibility.

B. Packaging, Transport, Storage

- (1) Visually inspect the package contents for signs of transport damage.

CAUTION: THE PACKAGING MATERIAL IS INFLAMMABLE, BY BURNING, TOXIC FUMES CAN DEVELOP.

- (2) Keep the packaging material and use it in the case of a return shipment. Improper or faulty packaging can lead to transport damages.
- (3) Make sure to transport the device always in a safe manner and with the aid of suitable lifting equipment if necessary. Never use electrical connections for lifting. Before the transport, a clean, level surface must be prepared to put the device on. The electrical connections must not be damaged when placing the device.
- (4) First Device Checkup
 - (a) Do a check for signs of transport damages.
 - (b) Please make sure that the indications on the type plate agree with your purchase order.
 - (c) Make sure that the equipment is complete (Refer to Section 2, Paragraph C., Step (2)).
- (5) Storage
 - (a) If you do not install the device immediately, make sure to store it in a dry and clean environment. Make sure that the device is not stored near strong heat sources and that no metal chippings can get into the device.

C. Device Assignment

- (1) This manual is valid for the devices:
 - (a) KX 200 and applicable retrofit adapter.
- (2) Scope of Delivery
 - (a) Manuals
 - 1 Operating Instructions.
 - (b) For KX 200:
 - 1 Device in accordance with your order
 - 2 Authorized Release Certificate (EASA Form 1).

EFFECTIVITY

ALL

34-24-61

Page 2-1
13 Aug 2025




INSTALLATION AND OPERATION MANUAL

89000002-120


- (3) State of Delivery
 - (a) The device is delivered with a default configuration.
- (4) Additional Required Equipment
 - (a) Connectors + cables
 - (b) Antennas for NAV and COM
 - (c) Headset
 - (d) Power supply
- (5) Registration of the Device
 - (a) Comply with the national requirements for the operation of radio equipment.
- (6) Type Plate
 - (a) The device type is specified by the type plate (on the housing):
 - 1 Example:




INSTALLATION AND OPERATION MANUAL
89000002-120



Name Plates used for the KX 200.



Name Plate used for the Retrofit Adapter 28V



Name Plate used for the Retrofit Adapter 14V

NOTE:

THE DATA PLATE EXAMPLES ABOVE ARE A CROSS REFERENCE BETWEEN THE HONEYWELL HARDWARE (HW) PART NUMBER (P/N) AND THE BECKER AVIONICS HW P/N.

ICN-55939-1000092223-002-01

Figure 2-1. Type Plate (Example)

EFFECTIVITY

ALL

34-24-61

Page 2-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

(7) Software

- (a) The software version is available in the configuration setup, installation mode→ "Software Identification - Control Head (CH), COM, NAV". Refer to Section 2, Paragraph N., Step (6).
- (b) The software versions are subject to change without notice.

D. Default Configuration

- (1) The device is delivered with a default configuration.
- (2) The default configuration guarantees an easy first start-up of the device without detailed configuration effort.
- (3) Before any changes are made to any default configuration settings, it is highly recommended to take pictures of the applicable KX 200 screens for easy reference to default settings.

E. Installation Requirements

- (1) The installation of the device(s) depends on the type of aircraft and its equipment and thus only general information can be given in this section.

Safety Instructions

- The installation of the components into an aircraft must always comply to the applicable regulations.
 - The device(s) must not be opened.
 - Keep enough distance around the equipment to ensure free circulation of cooling air and cables exit.
 - Keep enough distance to devices with integrated ventilator fans to ensure free circulation of cooling air.
 - The installation area must have a minimum distance of 12 inch (30 cm) from the magnetic aircraft compass, to prevent any interference to the magnetic compass.
 - Forced cooling is not required.



INSTALLATION AND OPERATION MANUAL

89000002-120

**Safety
Instructions**

- The devices are for installations in general aviation and rotary wing aircraft. The devices are made for installation in cockpit environment.
- These limitations apply for the installation:
 - The device must be installed with mounting tray to comply with the conditions for certification.
 - The installation must be in accordance with the local aviation authority approved guidelines.
 - The installation must be in accordance with the ETSO/TSO standards applicable for the specific type or class of aircraft.
 - The conditions and tests for ETSO/TSO approval of this article are minimum performance standards.
 - The COM transceiver must be connected to a VHF antenna in order to satisfy FAA TSO-C169a.
 - The equipment is not qualified for installation in areas with fluid contamination.
 - Changes or modifications made to this equipment not expressly approved in written form by Honeywell may void the authorization to operate this equipment.

**Safety
Instructions**

- Use only cables which are qualified for aircraft use (self-extinguishing).
- Fit sleeves over the solder joints on the equipment connector.
- Use AWG 18 (0.75 mm^2) for power supply and speaker and AWG 22/24 ($0.25 - 0.34 \text{ mm}^2$) for other cables.
- Use 2-core twisted and shielded cables for interface lines TX and RX.
- Each single cable harness of a device connector must have separate shielding.
- Connect each cable shield individually to the related ground signal (prevent series connections).
 - Wire cross-section min. 0.0004 inch^2 (0.25 mm^2), wire length $\leq 3 \text{ inch}$ (75 mm).
- HF cable should not be included in the cable harnesses.
- Use the recommended fuses in the power supply line for the protection of the application, Refer to Section 1, Paragraph J.

EFFECTIVITY

ALL

34-24-61Page 2-5
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

**Safety
Instructions**

- Antennas:
 - Comply with the antenna manufacturer's recommendations for antenna installation.
- Antenna cable/connections:
 - Use RF coaxial cables (impedance 50 Ω) for antenna connections.
 - The use of low-attenuation cables is recommended.
 - Do not route antenna cables near to interference sources, e.g. RF transmitters, ignition cables, etc.
 - Make antenna connections as short as practical but prevent sharp bends of antenna cables.

CAUTION: RADIATION RISK: A SAFE DISTANCE TO THE INSTALLED ANTENNA MUST BE ENSURED BY CORRESPONDING INSTALLATION MEASURES AROUND HUMAN BODY DAMAGE (E.G. AT THE EYES) AND/OR PREVENT THE INFLAMMATION OF COMBUSTIBLE MATERIALS BY RADIATED ENERGY.

CAUTION: CHECK THE WIRING CAREFULLY BEFORE POWER UP THE DEVICE(S) AND CHECK PARTICULARLY CORRECT CONNECTION OF THE POWER SUPPLY LINES.

(2) Prevent Hearing Damage

CAUTION: LISTENING AT HIGH VOLUMES THROUGH HEADPHONES, HEADSETS OR IN CLOSE DISTANCE TO A LOUDSPEAKER CAN CAUSE HEARING DAMAGE.

CAUTION: THE LONGER YOU ARE EXPOSED TO A HIGH ACOUSTIC SOUND LEVEL, THE MORE QUICKLY YOUR HEARING CAN BE DAMAGED.

**Safety
Instructions**

- Comply with the operating instruction of the used equipment.
- Do not increase the volume to suppress ambient noise.
- Recommendation: Use noise-canceling headphones (reduces ambient noise, volume can be turned down to minimum).
- Slowly increase the volume until you can hear the sound clearly and without distortion.

(3) Display - Viewing Angle and Readability

- (a) The readability of the display depends on the viewing angle.
- (b) During installation, make sure that the viewing angle on the display is as straight as possible.
- (c) We recommend the installation in the pilot's direct field of view and the smallest possible distance between the view to the outside and the view to the display.

NOTE: Polarizing sunglasses can reduce the readability of the display.

EFFECTIVITY

ALL

34-24-61

Page 2-6
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

(4) Cockpit Panel Installation

(a) KX 200 with Retrofit Adapter

- 1 The KX 200 with retrofit adapter is made for cockpit panel installation.
- 2 Install the retrofit adapter to the KX 200 (Refer to Figure 2-2 and Figure 2-3).
- 3 Deinstallation of KX155 from the Aircraft:
 - a Locate the lock down screw access at the bottom center of the faceplate and using a 3/32" Allen wrench, turn the lock-down screw counter-clockwise until the unit disengages from the mounting rack. Pull the unit out of the mounting rack by pulling the metal tabs located behind the front panel on each side of the rack.
 - b Take care to prevent damage to the existing wiring and mounting tray.
- 4 Use the existing mounting tray of the previously installed device for the new device installation.
- 5 Move the device with retrofit adapter straight and flush to bottom and rear side into the mounting tray.
- 6 Use an Allen wrench (3/32") to tighten the device to its final position (access to the locking mechanism on the front panel).
- 7 For more information please refer to Section 2, Paragraph F., Step (1) and Section 2, Paragraph F., Step (2).

EFFECTIVITY

ALL


34-24-61

Page 2-7
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120



KX 200 REAR VIEW

NOTE:

1. REPLACE 6x LATCH PINS WITH 6x PAN HEAD SCREWS ISO14583-M3x5-A2 TF.

ICN-55939-1000092224-001-01

Figure 2-2. KX 200 - Preparation for Retrofit Adapter Installation

EFFECTIVITY

ALL

34-24-61

Page 2-8
13 Aug 2025




INSTALLATION AND OPERATION MANUAL
89000002-120

- 8 Installation Retrofit Adapter - KX 200
- a Tool: Hexagon socket wrench M4.5
- Max. torque: 9 in-lb (1 Nm).

CAUTION: WHEN INSTALLING THE RETROFIT ADAPTER, APPLYING EXCESSIVE FORCE DURING ATTACHMENT CAN CAUSE STRUCTURAL DAMAGE TO THE KX 200 RADIO OR THE RETROFIT ADAPTER. ENSURE PROPER ALIGNMENT BEFORE TIGHTENING THE ADAPTER TO THE RADIO.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092225-001-01

Figure 2-3. KX 200 - Retrofit Adapter Installation

EFFECTIVITY

ALL

34-24-61

Page 2-10
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

9 Tools: Open-end wrench M8, Torx screwdriver T10

- a If guide pins are installed as shown in Figure 2-4, remove (6) six guide pins and verify completion compared to Figure 2-5. Reinstall (6) supplied M3x5 screws using an M4.5 hex socket wrench. Torque screws to 9 in-lb (1 Nm). Verify completion compared to Figure 2-6.

NOTE: The guide pins were originally installed in the earlier production batches. However, they were removed and replaced with screws in later production batches. If screws are already installed as shown in Figure 2-6 (instead of guide pins), no action required and go to next step.

EFFECTIVITY

ALL

34-24-61Page 2-11
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103560-001-01

Figure 2-4. Removing Guide Pins

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103561-001-01

Figure 2-5. Guide Pins Removed

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103562-001-01

Figure 2-6. M3x5 Screws Installed

EFFECTIVITY

ALL

34-24-61

Page 2-14
13 Aug 2025




INSTALLATION AND OPERATION MANUAL
89000002-120

I

- b Reposition NAV and GS coaxes inside retrofit adapter to prevent interference with KX 200 as shown in Figure 2-7.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103563-001-01

Figure 2-7. Reposition NAV and GS coax

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

I

- c Reposition COM coax inside retrofit adapter to prevent interference with KX 200 as shown in Figure 2-8.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103564-001-01

Figure 2-8. Reposition COM coax

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- d Install retrofit adapter onto the back of the KX 200 and secure with supplied screws using a Torx T10 screwdriver. Torque screws to 9 in-lb (1 Nm) as shown in Figure 2-9.

EFFECTIVITY


ALL

34-24-61

Page 2-19
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103568-001-01

Figure 2-9. Install Retrofit Adapter

EFFECTIVITY

ALL

34-24-61

Page 2-20
13 Aug 2025




INSTALLATION AND OPERATION MANUAL
89000002-120

I

- e Secure SMA connectors to NAV and GS antenna connectors on the KX 200 as shown in Figure 2-10.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103566-001-01

Figure 2-10. Secure SMA Connectors to NAV and GS

UP843765

EFFECTIVITY
ALL

34-24-61

Page 2-22
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

- f Connect and lock the COM antenna connector to the connector on the KX 200 as shown in Figure 2-11.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000103567-001-01

Figure 2-11. Connect and Lock the COM Antenna Connector

EFFECTIVITY


ALL

34-24-61

Page 2-24
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092226-001-01

Figure 2-12. KX 200 - Locking Mechanism

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120


(1) Tool: Allen wrench 3/32".

F. Dimensions

(1) KX 200 with Retrofit Adapter



INSTALLATION AND OPERATION MANUAL
89000002-120



NOTES:

1. "CENTER OF GRAVITY" FOR KX 200 WITH RETROFIT ADAPTER.
2. TOLERANCE: ± 0.2 IN. (± 5 MM).

ICN-55939-1000092228-001-01

Figure 2-13. Dimensions KX 200 with Retrofit Adapter

EFFECTIVITY

ALL

34-24-61

Page 2-27
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Dimensional Limits for Figure 2-13

Permitted deviation for dimensions without tolerances: DIN ISO 2768 T1 C (dimensions in inch (mm))		
≤0.2 (±0.01) (≤ 6 (±0.3))	>1.2 - 4.7 (±0.03) (> 30 - 120 (±0.8))	>16 - 39 (±0.08) (> 400 - 1000 (±2.0))
>0.2 - 1.2 (±0.02) (> 6 - 30 (±0.5))	>4.7 - 16 (±0.05) (> 120 - 400 (±1.2))	>39 - 79 (±0.12) (> 1000 - 2000 (±3.0))

(2) Retrofit Adapter


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092229-001-01

Figure 2-14. Dimensions - Retrofit Adapter

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

Dimensional Limits for Figure 2-14

Permitted deviation for dimensions without tolerances: DIN ISO 2768 T1 C (dimensions in inch (mm))		
≤0.2 (±0.01) (≤ 6 (±0.3))	>1.2 - 4.7 (±0.03) (> 30 - 120 (±0.8))	>16 - 39 (±0.08) (> 400 - 1000 (±2.0))
>0.2 - 1.2 (±0.02) (> 6 - 30 (±0.5))	>4.7 - 16 (±0.05) (> 120 - 400 (±1.2))	>39 - 79 (±0.12) (> 1000 - 2000 (±3.0))

G. Connector Pin Assignments - KX 200


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



- COM P1: Device connector
- NAV P1: Device connector
- COM J1: Device connector
- COM ANT: COM antenna connector
- GS ANT: GS antenna connector
- NAV ANT: NAV antenna connector
- GND: Grounding bolt

ICN-55939-1000092230-001-01

Figure 2-15. KX 200 - Connector Layout (Rear)

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

- Safety Instructions**
- Use only cables which are qualified for aircraft use (self-extinguishing).
 - Fit sleeves over the solder joints on the equipment connector.
 - Use AWG 18 (0.75 mm²) for power supply and speaker and AWG 22/24 (0.25 - 0.34 mm²) for other cables.
 - Use 2-core twisted and shielded cables for interface lines TX and RX.
 - Each single cable harness of a device connector must have separate shielding.
 - Connect each cable shield individually to the related ground signal (prevent series connections).
 - Wire cross-section min. 0.0004 inch² (0.25 mm²), wire length ≤ 3 inch (75 mm).
 - HF cable should not be included in the cable harnesses.
 - Use the recommended fuses in the power supply line for the protection of the application, refer to Section 1, Paragraph J.

- Safety Instructions**
- Antennas:
 - Comply with the antenna manufacturer's recommendations for antenna installation.
 - Antenna cable/connections:
 - Use RF coaxial cables (impedance 50 Ω) for antenna connections.
 - The use of low-attenuation cables is recommended.
 - Do not route antenna cables near to interference sources, e.g. RF transmitters, ignition cables, etc.
 - Make antenna connections as short as practical but prevent sharp bends of antenna cables.

(1) COM Connector P1

(a) Type: 25pin D-Sub male connector with slide-in fastener.

COM P1, Pin	Signal Name	Function (Details)
1	COMM_SPKR_HI	Speaker output signal
2	COMM_HDPH1_A	Symmetrical output for headphone(s). (Use with COMM_HDPH1_B)
3	COMM_HDPH1_B	Symmetrical output for headphone(s). (Use with COMM_HDPH1_A)
4	COMM_AUXIN_HI	Auxiliary audio input. (Use with COMM_AUXIN_LO)
5	COMM_DYNMIKE_A	Symmetrical input for dynamic microphone(s)
6	COMM_DYNMIKE_B	Symmetrical input for dynamic microphone(s)
7	COMM_IC_IN	Intercom key input

EFFECTIVITY

ALL

34-24-61

Page 2-32
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

COM P1, Pin	Signal Name	Function (Details)
8	COMM_STDMIKE_LO	Standard microphone return. (Common for STD1MIKE, STD2MIKE, STD3MIKE)
9	COMM_STD2MIKE_HI	Standard microphone 2 input. (Use with COMM_STDMIKE_LO)
10	COMM_ILLUM_LO	Illumination input ground NOTE : This is input pin. Connect the pin to ground potential.
11	COMM_PSUPP	Power supply
12	COMM_PSUPP	Power supply
13	COMM_PGND	Power supply return
14	COMM_SPKR_LO	Speaker output return
15	COMM_AUXOUT_HI	Auxiliary audio output
16	COMM_TEST_OUT	Reserved, do not connect
17	COMM_PTT1_IN	Push-To-Talk key input
18	COMM_STD1MIKE_HI	Standard microphone 1 input. (Use with COMM_STDMIKE_LO)
19	COMM_STD3MIKE_HI	Standard microphone 3 input. (Use with COMM_STDMIKE_LO)
20	COMM_HDPH2_A	Floating BTL output together with. (COMM_HDPH2_B) Do not connect to any GND
21	COMM_AUXIN_LO	Auxiliary audio return. (Use with COMM_AUXIN_HI)
22	COMM_HDPH2_B	Floating BTL output together with. (COMM_HDPH2_A) Do not connect to any GND
23	COMM_ILLUM_IN	Illumination input
24	COMM_PWR_STATUS	Reserved, do not connect
25	COMM_PGND	Power supply return

(2) COM Connector J1

(a) Type: 25pin D-Sub female connector with slide-in fastener.

COM J1, Pin	Signal Name	Function (Details)
1	--	Reserved, do not connect
2	COMM_COM2_TXP	Reserved, do not connect
3	COMM_COM2_RXP	Reserved, do not connect
4	COMM_RX_STATUS	Reserved, do not connect
5	COMM_PTT2_IN	Push-To-Talk key input

EFFECTIVITY

ALL

34-24-61

Page 2-33
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM J1, Pin	Signal Name	Function (Details)
6	COMM_DGND	Reserved, do not connect
7	COMM_COM1_TXP	Reserved, do not connect
8	COMM_COM1_RXP	Reserved, do not connect
9	COMM_COM2_TXN	Reserved, do not connect
10	COMM_COM2_RXN	Reserved, do not connect
11	COMM_DGND	Reserved, do not connect
12	COMM_EXCH_IN	External COMM "Exchange" key
13	COMM_SRVEN_IN	Reserved, do not connect
14	COMM_COM1_TXN	Reserved, do not connect
15	COMM_COM1_RXN	Reserved, do not connect
16	COMM_CHUP_IN	Reserved, do not connect
17	COMM_SQLSW_IN	Squelch Force-OFF input
18	--	Reserved, do not connect
19	--	Reserved, do not connect
20	COMM_ISOLSW_IN	ISOL input
21	COMM_DGND	Discrete lines ground
22	COMM_DGND	Discrete lines ground
23	COMM_DGND	Discrete lines ground
24	COMM_MIKESW_IN	Intercom configuration selector input
25	COMM_PON_IN	Reserved, do not connect

(3) NAV Connector P1

(a) Type: 25pin D-Sub male connector with slide-in fastener.

NAV P1, Pin	Signal Name	Function (Details)
1	NAV_VLCOMP_OUT	Composite output for an external VOR/LOC converter
2	NAV_GND	Aircraft ground
3	NAV_AFOUT_LO	Symmetrical audio output. (Use with NAV_AFOUT_HI)
4	NAV_AFOUT_HI	Symmetrical audio output. (Use with NAV_AFOUT_LO)
5	NAV_ILLUM_IN	Illumination input
6	NAV_BOOT_IN	Reserved, do not connect
7	NAV_RNAV_CHREQ_IN	RNAV channel request input
8	NAV_DME_COMM_IN	Gating input for DME interface
9	NAV_RNAV_MODE_IN	RNAV mode input
10	NAV_EXCH_IN	External NAV "Exchange" key
11	NAV_PON_IN	Reserved, do not connect

EFFECTIVITY

ALL

34-24-61

Page 2-34
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

NAV P1, Pin	Signal Name	Function (Details)
12	NAV_AUXSUPP_OUT	Auxiliary power supply output
13	NAV_PGND	Power supply return (ground)
14	NAV_GS_DOWN_OUT	GS deviation DOWN output. (Use together with NAV_GS_UP_OUT)
15	NAV_GS_UP_OUT	GS deviation UP output. (Use together with NAV_GS_DOWN_OUT)
16	NAV_GS_NFLAG_OUT	GS flag negative output. (Use together with NAV_GS_PFLAG_OUT)
17	NAV_GS_PFLAG_OUT	GS flag positive output. (Use together with NAV_GS_NFLAG_OUT)
18	NAV_ILSEN_OUT	ILS ENERGETIZE output
19	NAV_DME_CLOCK_OUT	Clock line for DME channeling
20	NAV_DME_DATA_OUT	Data line for DME channeling
21	NAV_COM1_422TXP	Reserved, do not connect
22	NAV_COM1_422TXN	Reserved, do not connect
23	NAV_COM1_422RXN	Reserved, do not connect
24	NAV_COM1_422RXP	Reserved, do not connect
25	NAV_PSUPP	Power supply

H. Connector Pin Assignments - KX 200 with Retrofit Adapter

EFFECTIVITY


ALL

34-24-61

Page 2-35
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092231-001-01

Figure 2-16. KX 200 with Retrofit Adapter - Connector Layout (Rear)

UP843765

EFFECTIVITY

ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- Safety Instructions**
- Use only cables which are qualified for aircraft use (self-extinguishing).
 - Fit sleeves over the solder joints on the equipment connector.
 - Use AWG 18 (0.75 mm²) for power supply and speaker and AWG 22/24 (0.25 - 0.34 mm²) for other cables.
 - Use 2-core twisted and shielded cables for interface lines TX and RX.
 - Each single cable harness of a device connector must have separate shielding.
 - Connect each cable shield individually to the related ground signal (prevent series connections).
 - Wire cross-section min. 0.0004 inch² (0.25 mm²), wire length ≤ 3 inch (75 mm).
 - HF cable should not be included in the cable harnesses.
 - Use the recommended fuses in the power supply line for the protection of the application, refer to Section 1, Paragraph J.

- Safety Instructions**
- Antennas:
 - Comply with the antenna manufacturer's recommendations for antenna installation.
 - Antenna cable/connections:
 - Use RF coaxial cables (impedance 50 Ω) for antenna connections.
 - The use of low-attenuation cables is recommended.
 - Do not route antenna cables near to interference sources, e.g. RF transmitters, ignition cables, etc.
 - Make antenna connections as short as practical but prevent sharp bends of antenna cables.

(1) Connector J401 - Retrofit Adapter

(a) Type: 2x15pin edge connector male.

J401, Pin	Signal Name	Function (Details)
1	COMM_PON_IN	Reserved, do not connect
2	COMM MIC AUDIO	Standard microphone 1 Input
3	CLOCK BUS	Clock Line for DME channeling
4	COMM_IC_IN	COMM Intercom activation input
5	DATA BUS	Data Line for DME channeling
6	COMM MIC KEY	Push-To-Talk line (transmission activation) COMM
7	COMM_SRVEN_IN	Reserved, do not connect
8	ILS ENTERGIZE	LOC/NAV status

EFFECTIVITY

ALL

34-24-61

Page 2-37
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

J401, Pin	Signal Name	Function (Details)
9	COMM AUDIO HI	Symmetrical output for headphone(s) Use with COMM AUDIO LO
10	NAV AUDIO HI	Symmetrical audio output Use with NAV AUDIO LO
11	-	Reserved, do not connect
12	SWITCHED POWER OUT	Auxiliary power supply output
13	+27.5VDC POWER IN	Power supply
14	NAV REMOTE TRANSFER	External NAV "Exchange" key
15	A/C GROUND	Power supply return (ground)
A	RNAV MODE	RNAV Mode input
B	INTERCOM MIC	Standard microphone 1 input
C	N/C	Reserved, do not connect
D	DME COMMON	Gating input for DME interface
E	N/C	Reserved, do not connect
F	RNAV/CHAN REQUEST	RNAV channel request input
H	VOR/LOC COMPOSITE OUT	Composite output for an external VOR/LOC converter
J	COMM_CHUP_IN	Reserved, do not connect
K	COMM AUDIO LO	Symmetrical output for headphone(s) Use with COMM AUDIO HI
L	NAV AUDIO LO	Symmetrical audio output Use with NAV_AUDIO_HI
M	SWITCHED POWER IN	Reserved, do not connect
N	SWITCHED POWER OUT	Auxiliary power supply output
P	+27.5VDC POWER IN	Power supply
R	COMM REMOTE TRANSFER	External COMM "Exchange" key
S	A/C GROUND	Power supply return (ground)

(2) Connector J401 - 14 V Retrofit Adapter

(a) Refer to Step (1) and comply with the listed differences:

J401, Pin	Signal Name	Function (Details)
14	+13.75VDC POWER IN	Power supply
R	+13.75VDC POWER IN	Power supply
P	COMM REMOTE TRANSFER	External COMM "Exchange" key
13	NAV REMOTE TRANSFER	External NAV "Exchange" key

EFFECTIVITY

ALL

34-24-61

Page 2-38
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

(3) Connector J901 - Retrofit Adapter

(a) Type: 2x18pin edge connector male.

J901, Pin	Signal Name	Function (Details)
1	--	Reserved, do not connect
2	COMM_COM1_422RXP	Reserved, do not connect
3	COMM_COM1_422TXP	Reserved, do not connect
4	COMM_COM2_422RXP	Reserved, do not connect
5	COMM_COM2_422TXP	Reserved, do not connect
6	NAV_COM1_422TXN	Reserved, do not connect
7	NAV_COM1_422RXN	Reserved, do not connect
8	-	Reserved, do not connect
9	N/C	Reserved, do not connect
10	N/C	Reserved, do not connect
11	-	Reserved, do not connect
12	NAV_BOOT_IN	Reserved, do not connect
13	-	Reserved, do not connect
14	GS - FLAG	GS Flag output (used together with GS+FLAG)
15	GS + UP	GS deviation UP output
16	GS + DOWN	GS deviation DOWN output
17	GS + FLAG	GS Flag output (used together with GS-FLAG)
18	NCT_PON_IN	Reserved, do not connect
A	-	Reserved, do not connect
B	COMM_COM1_422RXN	Reserved, do not connect
C	COMM_COM1_422TXN	Reserved, do not connect
D	COMM_COM2_422RXN	Reserved, do not connect
E	COMM_COM2_422TXN	Reserved, do not connect
F	NAV_COM1_422TXP	Reserved, do not connect
H	NAV_COM1_422RXP	Reserved, do not connect
J	-	Reserved, do not connect
K	N/C	Reserved, do not connect
L	N/C	Reserved, do not connect
M	N/C	Reserved, do not connect
N	-	Reserved, do not connect
P	-	Reserved, do not connect

EFFECTIVITY

ALL

34-24-61

Page 2-39
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

J901, Pin	Signal Name	Function (Details)
R	GS - FLAG	GS Flag output (used together with GS+FLAG)
S	GS + UP	GS deviation UP output
T	GS + DOWN	GS deviation DOWN output
U	GS + FLAG	GS Flag output (used together with GS-FLAG)
V	N/C	Reserved, do not connect

(4) Connector J901 - 14 V Retrofit Adapter

(a) Refer to Step (3).

I. Antenna Connectors

CAUTION: RADIATION RISK: A SAFE DISTANCE TO THE INSTALLED ANTENNA MUST BE ENSURED BY CORRESPONDING INSTALLATION MEASURES AROUND HUMAN BODY DAMAGE (E.G. AT THE EYES) AND/OR PREVENT THE INFLAMMATION OF COMBUSTIBLE MATERIALS BY RADIATED ENERGY.

Safety Instructions

Antenna cable/connections:

- Use RF coaxial cables (impedance 50 Ω) for antenna connections.
 - Do not route antenna cables near to interference sources, e.g. RF transmitters, ignition cables, etc.
 - The use of low-attenuation cables is recommended.
 - Make antenna connections as short as practical but prevent sharp bends of antenna cables.

(1) COM Antenna

- (a) The antenna connector on the rear of the KX 200 is a BNC type.
- (b) The antenna connector on the rear of the Retrofit Adapter is a BNC type w/o bayonet.
- (c) The antenna port is made for operating with a nominal impedance of 50 Ω .

(2) VOR/LOC Antenna

- (a) The antenna connector on the rear of the KX 200 is a SMA type.
- (b) The antenna connector on the rear of the Retrofit Adapter is a BNC type w/o bayonet.
- (c) The antenna port is made for operating with a nominal impedance of 50 Ω .

(3) GS Antenna

- (a) The antenna connector on the rear of the KX 200 is a SMA type.
- (b) The antenna connector on the rear of the Retrofit Adapter is a BNC type w/o bayonet.

EFFECTIVITY

ALL

34-24-61

Page 2-40
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120


(c) The antenna port is made for operating with a nominal impedance of 50 Ω.

J. Grounding Bolt

Safety Instructions	Make sure that the grounding contact area is sufficient and that the connection has low resistance and low inductance. Never use a grounding point on paint-coated surfaces.
----------------------------	--



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092232-001-01

Figure 2-17. Grounding Bolt

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (1) The KX 200 has a grounding stud at the connector side (rear) of the housing.
- (a) Use this point as grounding contact for low impedance grounding of the device to the airframe.
- 1 Wire cross section: min. 0.01 inch² (4 mm²)
 - 2 Length: as short as possible
 - 3 Type: Screw thread M4
 - 4 Max. torque for grounding bolt: 14 in-lb (1.5 Nm).

K. Aircraft Wiring - KX 200 with Retrofit Adapter

Safety Instructions The installation of the device(s) depends on the type of aircraft and its equipment and thus only general information can be given in this section.

NOTE: For the related connector and pin numbers please see connector tables at Section 2, Paragraph H.

EFFECTIVITY


ALL

34-24-61

Page 2-43
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092263-001-01

Figure 2-18. KX 200 with Retrofit Adapter - Connector Layout (Rear)

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- Safety Instructions**
- Use only cables which are qualified for aircraft use (self-extinguishing).
 - Use AWG 18 (0.75 mm^2) for power supply and speaker and AWG 22/24 ($0.25 - 0.34 \text{ mm}^2$) for other cables.
 - Refer to Section 2, Paragraph E. for details.
 - Use the recommended fuses in the power supply line for the protection of the application, refer to Section 1, Paragraph J.

(1) Electrical Bonding and Grounding

- Safety Instructions**
- Make sure that the device is correctly connected to aircraft ground (structure).
 - Make sure that the electrical bonding area is protected in order to prevent corrosion.
 - Make sure that you do not exceed the resistance of $10 \text{ m}\Omega$ between the chassis and the reference ground platform.
 - Refer to Section 2, Paragraph J. and Section 2, Paragraph E., Step (4).

NOTE: There are differences in the wiring of devices with Retrofit Adapter, 14 V Retrofit Adapter

- For detailed differences, refer to related information Section 2, Paragraph H.

(2) Block Diagram - Aircraft Installation KX 200 with Retrofit Adapter

(a) Example of equipment installation for a two-seat aircraft with:

- 1 Headphones and hand microphones with PTTs for pilot and copilot
- 2 External VOR/LOC converter and VOR/LOC/glideslope indicator
- 3 DME interrogator.

(b) Aircraft Installation KX 200 with Retrofit Adapter

EFFECTIVITY

ALL


34-24-61

Page 2-45
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120



ICN-55939-100092264-001-01

Figure 2-19. Wiring KX 200 with Retrofit Adapter - Aircraft Installation (Example)

EFFECTIVITY

ALL

34-24-61

Page 2-46
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

- (c) Aircraft Installation KX 200 with 14 V Retrofit Adapter

1 Differences with 14 V Retrofit Adapter

KX 200 with 14 V Retrofit Adapter	Pin J401 14 V Retrofit Adapter
+13.75VDC POWER IN	J401-14
+13.75VDC POWER IN	J401-R

- 2 For detailed differences between 14 V Retrofit Adapter and 28 V Retrofit Adapter, refer to Section 2, Paragraph H.

(3) Dimming

- (a) The backlight of the display is controlled by the integrated light sensor (front panel).
- (b) The control method is selected during installation (installation mode).
- (c) The brightness can be controlled through the pilots menu for COM and NAV subsystems (depends on the configuration setting).
- (d) Refer to Section 2, Paragraph N., Step (7) for installation mode details.

(4) Power Supply

- (a) Each pin must be connected to the power supply with a separate cable.

EFFECTIVITY


ALL

34-24-61

Page 2-47
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092265-001-01

Figure 2-20. Wiring KX 200 and Retrofit Adapter - Power Supply

UP843765

EFFECTIVITY _____
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-13	+27.5VDC POWER IN	Supply	IN	Power supply (+)
J401-P	+27.5VDC POWER IN	Supply	IN	Power supply (+)
J401-15	A/C GROUND	Ground	-	Power supply return (-)
J401-S	A/C GROUND	Ground	-	Power supply return (-)



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092266-001-01

Figure 2-21. Wiring KX 200 and 14 V Retrofit Adapter - Power Supply

UP843765

EFFECTIVITY
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

14 V Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-14	+13.75VDC POWER IN	Supply	IN	Power supply (+)
J401-R	+13.75VDC POWER IN	Supply	IN	Power supply (+)
J401-15	A/C GROUND	Ground	-	Power supply return (-)
J401-S	A/C GROUND	Ground	-	Power supply return (-)

- (5) Antennas
 - (a) For antennas connections use an RF coaxial cable with 50 Ω impedance. For details refer to Section 2, Paragraph I.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092267-001-01

Figure 2-22. Wiring KX 200 and Retrofit Adapter - Antennas

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J801-IN	COMRF	RF	IN/OUT	VHF transceiver antenna port
J801-OUT	GND	Ground	-	
J902-IN	GSRF	RF	IN	Glide slope receiver antenna port
J902-OUT	GND	Ground	-	
J301-IN	NAVRF	RF	IN	NAV receiver antenna port
J301-OUT	GND	Ground	-	

(6) Headphones

(a) The headphones port supplies a balanced signal with transformer separation.

1 The headphones port supports balanced and unbalanced operation.

2 The headphones port supports connection of:

a Single headphones with impedance of min. 75 Ω or

b Two headphones with impedance of min. 150 Ω each.


Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-9	COMM AUDIO HI	Analog	OUT	Symmetrical headphones output
J401-K	COMM AUDIO LO	Analog	OUT	Symmetrical headphones output

(b) Headphones, Balanced

NOTE: It is recommended to install headphones generally isolated from aircraft ground. This helps to prevent ground loops and ensures a good audio quality.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092268-001-01

Figure 2-23. Wiring KX 200 and Retrofit Adapter - Single Headphones, Balanced


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092269-001-01

Figure 2-24. Wiring KX 200 and Retrofit Adapter - Two Headphones, Balanced

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL


89000002-120

(c) Headphones, Unbalanced

NOTE: If a single shielded cable is used to connect headphones, it is possible to ground one end of the connection to simplify installation, but this can result in decreased audio quality.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092270-001-01

Figure 2-25. Wiring KX 200 and Retrofit Adapter - Single Headphones, Unbalanced


EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092271-001-01

Figure 2-26. Wiring KX 200 and Retrofit Adapter - Two Headphones, Unbalanced

UP843765

EFFECTIVITY _____
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

- (7) Standard Microphone
- (a) Standard microphone signals are single-ended signals with reference to a dedicated return signal and supply excitation voltage for standard microphone operation.
- 1 The port supports the connection of one or two standard microphones with impedance of min. 120 Ohm each.
 - 2 If two microphones are connected to the same microphone port, it is recommended to use microphones of the same type/impedance.
 - 3 The sensitivity level is adjustable in the configuration setup for each of the microphones, refer to Section 2, Paragraph M.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-2	COMM MIC AUDIO	Analog	IN	Standard microphone input
J401-B	INTERCOM MIC			



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092272-001-01

Figure 2-27. Wiring KX 200 and Retrofit Adapter - Standard Microphone

UP843765

EFFECTIVITY
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

- (8) NAV Audio Output
 - (a) The NAV audio output signal is a balanced signal with transformer separation.
 - 1 The NAV audio output supports balanced and unbalanced operation.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-10	NA AUDIO HI	Analog	OUT	Symmetrical NAV audio output
J401-L	NAV AUDIO LO	Analog	OUT	Symmetrical NAV audio output



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092273-001-01

Figure 2-28. Wiring KX 200 and Retrofit Adapter - NAV Audio Output, Balanced


UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092274-001-01

Figure 2-29. Wiring KX 200 and Retrofit Adapter - NAV Audio Output, Unbalanced

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

(9) VOR/LOC/Glide Slope Interface

- (a) The glide slope deviation and the glide slope flag are differential signals with reference to NAV ground.
- (b) The VOR/LOC composite signal is a single ended signal with reference to NAV ground.
- (c) The LOC/NAV status output shows the current operating mode of the NAV subsystem.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-12	SWITCHED POWER OUT	Supply	OUT	VOR/LOC converter supply output
J401-N	SWITCHED POWER OUT			
J401-H	VOR/LOC COMPOSITE OUT	Analog	OUT	VOR/LOC composite output
J401-8	ILS ENERGIZE	Discrete	OUT	LOC/NAV status
J901-16	GS + DOWN	Analog	OUT	Glide slope deviation output A
J901-T	GS + DOWN			
J901-15	GS + UP	Analog	OUT	Glide slope deviation output B
J901-S	GS + UP			
J901-17	GS + FLAG	Analog	OUT	Glide slope flag output A
J901-U	GS + FLAG			
J901-14	GS - FLAG	Analog	OUT	Glide slope flag output B
J901-R	GS - FLAG			

EFFECTIVITY


ALL

34-24-61

Page 2-64
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092275-001-01

Figure 2-30. Wiring KX 200 and Retrofit Adapter - VOR/LOC/Glide Slope Interface

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

(10) DME Tuning

- (a) The external DME equipment can get information about the currently selected NAV frequency. This frequency is used by a DME interrogator to tune to the operating frequency of DME ground station co-located with VOR (VOR-DME).
- (b) To initiate frequency data transfer, the external equipment must:
- 1 Set DME COMMON signal to active state (CLOSED, logic LOW).
 - 2 Set RNAV MODE signal to inactive state (OPEN, logic HIGH).
 - 3 Supply a HIGH pulse on RNAV/CHAN REQUEST signal. Pulse time (tf) min. 48 ms.
- (c) The device then outputs the transmission at the CLOCK BUS signal and the transmission data at the DATA BUS signal.
- (d) Supplied data:

Bit(s)	Description
9	Set it to 0
8 - 5	BCD value of 1 MHz digit of current NAV frequency
4 - 1	BCD value of 0.1 MHz digit of current NAV frequency
0	0 if the value of 0.01 MHz digit is 0
	1 if the value of 0.01 MHz digit is 5
Example 1: If the current NAV frequency is 108.15, the binary data value is 0100000011. Example 2: If the current NAV frequency is 112.40, the binary data value is 0001001000.	

EFFECTIVITY _____


ALL

34-24-61

 Page 2-66
 13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092276-001-01

Figure 2-31. Diagram - DME Tuning (Waveform)

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-D	DME COMMON	-	IN	DME mode
J401-A	RNAV MODE	-	IN	RNAV mode
J401-F	RNAV/CHAN REQUEST	-	IN	DME data request
J401-3	CLOCK BUS	-	OUT	Clock for DME channeling
J401-5	DATA BUS	-	OUT	Data line for DME channeling


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092277-001-01

Figure 2-32. Wiring KX 200 and Retrofit Adapter - DME Tuning

EFFECTIVITY
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

(11) Discrete Inputs/Outputs


(a) Push-To-Talk (PTT)

- 1 There are two inputs for connection of PTT buttons.
 - a Each input can be connected to one or more pushbuttons.
 - b The activation of the pushbutton (PTT) starts the COM subsystem transmission mode.
 - (1) The transmission is automatically terminated if a time limit for continuous transmission is exceeded.
 - c The PTT button can be a stand-alone button or integrated into a microphone, etc.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-6	COMM MIC KEY	Switch NO	IN	PTT input



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092278-001-01

Figure 2-33. Wiring KX 200 and Retrofit Adapter - PTT

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

- (b) Intercom Control
- 1 The intercom operation is normally controlled through the VOX function (automatic intercom activation by monitoring audio level in microphones).
 - 2 The VOX function cannot operate in:
 - a Installations with high level of ambient noise.
 - b Operation when speaker is enabled.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-4	COMM_IC_IN	Switch	IN	Intercom mode activation


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092279-001-01

Figure 2-34. Wiring KX 200 and Retrofit Adapter - Intercom Control

EFFECTIVITY
ALL

34-24-61

UP843765




INSTALLATION AND OPERATION MANUAL

89000002-120

- 3 An external switch makes it possible to select the intercom operation manually.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092280-001-01

Figure 2-35. Wiring KX 200 and Retrofit Adapter - Manual Intercom Operation

EFFECTIVITY

ALL

34-24-61

Page 2-75
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

(c) Frequency Exchange

- 1 The active/standby frequency exchange for COM and NAV frequencies is normally controlled through the related pushbuttons on the front panel.
 - a External switches make it possible to do the exchange manually.

Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-R	COMM REMOTE TRANSFER	Switch NO	IN	COM active/standby frequency exchange
J401-14	NAV REMOTE TRANSFER	Switch NO	IN	NAV active/standby frequency exchange


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092281-001-01

Figure 2-36. Wiring KX 200 and Retrofit Adapter - Frequency Exchange

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

14 V Retrofit Adapter Pin	Signal Name	Type	I/O	Function
J401-P	COMM REMOTE TRANSFER	Switch NO	IN	COM active/standby frequency exchange
J401-13	NAV REMOTE TRANSFER	Switch NO	IN	NAV active/standby frequency exchange


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092282-001-01

Figure 2-37. Wiring KX 200 and 14 V Retrofit Adapter - Frequency Exchange

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

L. Configuration Setup

- (1) The configuration setup is for the configuration of installation and device parameters.

NOTE: It is not recommended to make changes during the flight.

- (2) The device has different modes for settings and operation:

- (a) Pilot Mode - for operation during flight
- (b) Installation Mode - for configuration of the device parameters and read out of device and software identification data (password protected)
- (c) Database Update Mode - for updating database with named channels for COM and NAV operation (future functionality)
- (d) Maintenance Mode - (factory only)
- (e) Software Update Mode - (factory only).

M. Installation Mode

- (1) In the installation mode it is possible to adjust device parameters and read out device and software identification data. The installation mode is divided in submenus to make the settings for the control head/display (CH), the COM and NAV subsystem.

NOTE: Some settings are not applicable for KX 200 with Retrofit Adapter.

NOTE: Before any changes are made to any default parameter settings, it is highly recommended to take pictures of the applicable KX 200 screens for easy reference to default settings.

NOTE: In the next several pages, there will be many settings listed. Table 2-1 is intended to be a quick reference summary of any settings that have a default value predefined. This is not a summary of all settings, only those settings with a default value.

Table 2-1. Summary of Installation Mode Default Settings

Reference	Installation Mode Setting	KX 200 with Retrofit Adapter
Section M. (7)	Control Head - Brightness Control (Dimming Input)	Set it to PILOT in all installations
Section M. (9)	Control Head - Dimming Curve for Display	Applicable to this/these device(s).
Section M. (10)	Control Head - Dimming Curve for Rotary Knob	Control Head - Dimming Curve for Rotary knobs is not applicable to this/these device(s).
Section M. (11)	Control Head - Dimming Curve for System Buttons	Control Head - Dimming Curve for System Buttons is not applicable to this/these device(s).
Section M. (12)	Control Head - Dimming Curve for Function Buttons	Control Head - Dimming Curve for Function Buttons is not applicable to this/these device(s).
Section M. (13)	Control Head - Dimming Curve for Transfer Buttons	Control Head - Dimming Curve for Transfer Buttons is not applicable to this/these device(s).

EFFECTIVITY _____

ALL

34-24-61

Page 2-80
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table 2-1. Summary of Installation Mode Default Settings (Cont)

Reference	Installation Mode Setting	KX 200 with Retrofit Adapter
Section M. (15)	COM - Auxiliary Audio Input Enable	Set it to OFF in all installations.
Section M. (16)	COM - Automatic Muting of Auxiliary Audio Input	Set it to OFF in all installations.
Section M. (17)	COM - Automatic Isolation during Transmission	Set it to OFF in all installations.
Section M. (20)	COM - Swap Mike IC	Set it to OFF in all installations.
Section M. (21)(b)	COM - Microphone Path 1 Selection	Set it to STD1 in all installations.
Section M. (21)(c)	COM - Microphone Path 2 Selection	Set it to NONE in all installations.
Section M. (21)(d)	COM - Microphone Activation	Set it to OFF in all installations.
Section M. (21)(e)	COM - Output 1 Selection	Set it to HDPH1 in all installations.
Section M. (21)(f)	COM - Output 2 Selection	Set it to NONE in all installations.
Section M. (22)(b)	COM (Cfg2) - Microphone Path 1 Selection	Set it to NONE in all installations.
Section M. (22)(c)	COM (Cfg2) - Microphone Path 2 Selection	Set it to NONE in all installations.
Section M. (22)(d)	COM - Microphone Activation	Set it to OFF in all installations.
Section M. (22)(e)	COM - Output 1 Selection	Set it to NONE in all installations.
Section M. (22)(f)	COM - Output 2 Selection	Set it to NONE in all installations.
Section M. (24)	COM - Standard Microphone 2 Sensitivity	Applicable to this/these device(s).
Section M. (25)	COM - Standard Microphone 3 Sensitivity	Applicable to this/these device(s).
Section M. (26)	COM - Dynamic Microphone Sensitivity	Applicable to this/these device(s).
Section M. (27)	COM - Auxiliary Audio Input Sensitivity	Applicable to this/these device(s).
Section M. (28)	COM - Automatic Attenuation of Auxiliary Input	COM - Automatic Attenuation of Auxiliary Input is not applicable to this/these device(s).
Section M. (30)	COM - Scan Hold Time	Set it to 01 in all installations.
Section M. (32)	COM - Speaker Volume Source	Set it to PRIM in all installations.
Section M. (34)(a)	NAV - VOR Response Time	Set it to 2.0 in all installations.
Section M. (34)(b)	NAV - LOC Response Time	Set it to 0.6 in all installations.

(2) Start Installation Mode

(a) Control Elements / User Interface refer to Section 3, Paragraph C.

EFFECTIVITY _____

ALL

34-24-61

Page 2-81
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

	Start Installation Mode
 Push = power up  NAV Transfer Knob (right side)  Inner/ Outer Rotary Knob (Right side)	To start installation mode push and hold the "NAV transfer" pushbutton (right) during power up. - Push and hold the "NAV transfer" pushbutton (right). - Short push to rotary knob "HOLD PWR" (left side). Power up device: - Short push to the rotary knob (left) or power ON signal of the aircraft installation. • The installation mode starts. • The word "PASSWORD" is shown on the display (left). - Insert the 4-digit numerical code password "6435" by turning the right rotary knob. • Turn the inner rotary knob to change the value of the digit. • Turn the outer rotary knob to move between the digits. - Push (long push) to the right rotary knob to confirm the entry.


UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092286-001-01

Figure 2-38. "PASSWORD"




INSTALLATION AND OPERATION MANUAL
89000002-120

- The main screen of installation mode is shown on the display (left).
- The related menu screen of installation mode is shown on the display (right).



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092287-001-01

Figure 2-39. Installation Mode - Main and Menu Screen (CH)



INSTALLATION AND OPERATION MANUAL
89000002-120

NOTE : Refer to Figure 2-1 for a cross reference between the Honeywell hardware (HW) part number (P/N) and the Becker Avionics HW P/N which is displayed on the Installation Mode Screen.

(3) Navigation between (Sub-) Menus

	Menu Navigation
 Rotary knob (Right side)	- Use the right rotary knob for navigation in the submenu (CH, COM, NAV). - Push to the right rotary knob to confirm the selection. • The related menu is shown on the display (right).


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092289-001-01

Figure 2-40. Installation Mode - Main and Menu Screen (CH)




INSTALLATION AND OPERATION MANUAL
89000002-120

Go to previous menu:

- Select the top-level entry in the menu (right) e.g. <BACK, <CH, <COM.
- Push to the right rotary knob to confirm the selection.
 - The previous menu, submenu is shown.
- Select the top-level entry <BACK.
 - The navigation moves to the main menu (left).



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092290-001-01

Figure 2-41. Installation Mode - Main and Menu Screen (CH)




INSTALLATION AND OPERATION MANUAL
89000002-120

- (4) Store Settings
 - (a) The change of any parameter is stored immediately.
- (5) Leave the Installation Mode
 - (a) Turn "OFF" the device to leave this mode (long push > 2 s to the left rotary knob).
 - (b) All changes made up to this time are automatically stored.
- (6) Software Identification - Control Head (CH), COM, NAV



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092291-001-01

Figure 2-42. Software Identification - Control Head



INSTALLATION AND OPERATION MANUAL
89000002-120

Control Head, COM, NAV - Software Identification
Access: INSTALLATION MODE> - Device Info on display left. - Selection of the subsystem for data read out (display left). • Turn the right rotary knob to do the selection. • Push to the right rotary knob to confirm the selection.


UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092292-001-01

Figure 2-43. Example CH Subsystem Software Info




INSTALLATION AND OPERATION MANUAL
89000002-120

- The menu of the related selection is shown on the display (right).
- Select "Software Info" and confirm with push to the right rotary knob.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092293-001-01

Figure 2-44. Example CH Software Info




INSTALLATION AND OPERATION MANUAL
89000002-120

- The data of the related subsystem is shown on the display (right).
- Select <CH to go to the previous menu.

(7) Control Head - Brightness Control (Dimming Input)



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092294-001-01

Figure 2-45. Brightness Control (Dimming Input)



INSTALLATION AND OPERATION MANUAL
89000002-120

Control Head - Brightness Control

Access: INSTALLATION MODE>CH>Dimming Input

- Selection of the source for display and pushbutton backlighting.
 - Turn the right rotary knob to select the entry dimming input.
 - Push to the right rotary knob to confirm the selection.
 - Turn the right knob to scroll through the dimming input parameters.
 - Push to the right rotary knob to confirm the selected parameter and leave the selection mode.
- Settings:
 - SENSOR: The brightness is controlled through the light sensor.
 - PILOT: The brightness is set to a fixed level selected with configuration, refer to Control Head - Brightness Level.
 - 0-28V: The brightness is controlled through an external dimming bus with voltage range 0 - 28 V.
 - 0-14V: The brightness is controlled through an external dimming bus with voltage range 0 - 14 V.
 - 0-5V: The brightness is controlled through an external dimming bus with voltage range 0 - 5 V.

NOTE : KX 200 with Retrofit Adapter

- Set it to PILOT in all installations.

(8) Control Head - Brightness Level

EFFECTIVITY _____


ALL

34-24-61

Page 2-98
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092295-001-01

Figure 2-46. Change Brightness Level




INSTALLATION AND OPERATION MANUAL
89000002-120

Control Head - Brightness Level
Access: INSTALLATION MODE>CH>Brightness
- Selection of the brightness level when the brightness control is set to PILOT.
• Turn the right rotary knob to select the entry brightness.
• Push to the right rotary knob to confirm the selection.
• Turn the right knob to scroll through the brightness parameters.
• Push to the right rotary knob to confirm the selected parameter and leave the selection mode.
• Range: 0 - 100

(9) Control Head - Dimming Curve for Display



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092296-001-01

Figure 2-47. Dimming Curve for Display



INSTALLATION AND OPERATION MANUAL
89000002-120

Control Head - Dimming Curve for Display
Access: INSTALLATION MODE>CH>Dimming Curve>Display
- Used to adjust the brightness characteristics for the display backlight. • Turn the right rotary knob to select the entry dimming curve. • Push to the right rotary knob to confirm the selection.
- Select the parts to be configured e.g. Display, Knob, etc.,.

UP843765


EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

....



ICN-55939-1000092297-001-01

Figure 2-48. Dimming Curve Parameter



INSTALLATION AND OPERATION MANUAL

89000002-120

- Dimming curve parameter:
 - Before: Brightness level⁽¹⁾ when control voltage is < X1 value
 - Range: 25 - 100.
 - X1: Low-end value of control voltage in % of full-range voltage.⁽²⁾
 - Range: 0 - 20.
 - Y1: Brightness level⁽¹⁾ when control voltage is equal X1.
 - Range: 0 - 25.
 - X2: High-end value of control voltage in % of full-range voltage.⁽²⁾
 - Range: 70 - 100.
 - Y2: Brightness level⁽¹⁾ when control voltage is equal X2.
 - Range: 25 - 100.
 - After: Brightness level⁽¹⁾ when control voltage is > X2 value.
 - Range: 25 - 100.
 - If the control voltage is between X1 and X2, brightness level is interpolated using Y1 and Y2 values.
 - This setting is used when the brightness control source is set to light sensor or the external dimming bus.
 - This setting is not used if brightness control is set to PILOT.

NOTE : KX 200 and Retrofit Adapter

- Control Head - Dimming Curve for Display is not applicable to this/these device(s).

NOTES:

(1) Brightness level 0 = min. intensity; 100 = max. intensity.

(2) Full-range control voltage value depends on brightness control configuration, Control Head - Brightness Control.

(10) Control Head - Dimming Curve for Rotary Knobs

Control Head - Dimming Curve for Rotary Knob

Access: INSTALLATION MODE>CH>Dimming Curve>Knobs

- Used to adjust the brightness characteristics for the rotary knob backlight.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Dimming curve parameter:

- For details refer to Step (9).

NOTE : KX 200 and Retrofit Adapter

- Control Head - Dimming Curve for Rotary knobs is not applicable to this/these device(s).

(11) Control Head - Dimming Curve for System Buttons

EFFECTIVITY

ALL

34-24-61

Page 2-104
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

Control Head - Dimming Curve for Rotary Knob

Access: INSTALLATION MODE>CH>Dimming Curve>System Buttons

- Used to adjust the brightness characteristics for COM and NAV pushbuttons.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Dimming curve parameter:

- For details refer to Step (9).

NOTE : KX 200 and Retrofit Adapter

- Control Head - Dimming Curve for System Buttons is not applicable to this/these device(s).

(12) Control Head - Dimming Curve for Function Buttons

Control Head - Dimming Curve for Function Buttons

Access: INSTALLATION MODE>CH>Dimming Curve>Function Buttons

- Used to adjust the brightness characteristics for RCNT, MON and ID pushbuttons.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Dimming curve parameter:

- For details refer to Step (9).

NOTE : KX 200 and Retrofit Adapter

- Control Head - Dimming Curve for Function Buttons is not applicable to this/these device(s).

(13) Control Head - Dimming Curve for Transfer Buttons

Control Head - Dimming Curve for Transfer Buttons

Access: INSTALLATION MODE>CH>Dimming Curve>Transfer Buttons

- Used to adjust the brightness characteristics for the transfer pushbuttons.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Dimming curve parameter:

- For details refer to Step (9).

NOTE : KX 200 and Retrofit Adapter

- Control Head - Dimming Curve for Transfer Buttons is not applicable to this/these device(s).

(14) Control Head - Clear NV-Memory Error

EFFECTIVITY _____


ALL

34-24-61

Page 2-105
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092298-001-01

Figure 2-49. Clear NV-Memory Error

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

Control Head - Clear NV-Memory Error

Access: INSTALLATION MODE>CH>Clear NV-Memory Error

- Possibility to delete the related memory errors.
 - Turn the right rotary knob to select the entry NV memory error.
 - Push to the right rotary knob to confirm the selection.
 - The submenu shows "PRESS ENT TO CLEAR".
 - A short push to the right rotary knob deletes the related non-volatile memory errors and goes back to the previous menu.

(15) COM - Auxiliary Audio Input Enable

COM - Auxiliary Audio Input Enable

Access: INSTALLATION MODE>COM>Configuration>Aux Input

- Used to adjust the auxiliary audio input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF: Auxiliary audio input disabled.
- ON: Auxiliary audio input enabled.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(16) COM - Automatic Muting of Auxiliary Audio Input

COM - Automatic Muting of Auxiliary Audio Input

Access: INSTALLATION MODE>COM>Configuration>Aux Auto Mute

- Used to adjust the automatic muting of auxiliary audio input when the VHF receiver receives a signal.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF: Automatic muting disabled.
- ON: Automatic muting enabled.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(17) COM - Automatic Isolation during Transmission

EFFECTIVITY

ALL

34-24-61Page 2-107
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Automatic Isolation during Transmission

Access: INSTALLATION MODE>COM>Configuration>Auto Isol In TX

- Used to adjust the intercom isolation mode during transmission.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF: Automatic isolation disabled.
- ON: Automatic isolation of intercom audio paths when transmission is pending.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(18) COM - Scan Function Beep

COM - Scan Function Beep

Access: INSTALLATION MODE>COM>Configuration>Scan Beep

- Used to generate an acoustic signal when the monitoring function receives a signal on the standby frequency.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF: Audio signal disabled.
- ON: Audio signal enabled.

(19) COM - Active Frequency Change Beep

COM - Active Frequency Change Beep

Access: INSTALLATION MODE>COM>Configuration>Freq Change Beep

- Used to generate an acoustic signal when active frequency changes.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF: Audio signal disabled.
- ON: Audio signal enabled.

(20) COM - Swap Mike IC

EFFECTIVITY _____

ALL

34-24-61Page 2-108
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Swap Mike IC

Access: INSTALLATION MODE>COM>Configuration>Swap Mike IC

- Turn the right rotary knob to do the selection.
- Push to the right rotary knob to confirm the selection.

Settings:

- Set it to OFF in all installations.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(21) COM I/O Configuration 1

- (a) The COM I/O configuration 1 settings are active when COMM_MIKESW_IN input (configuration selector) is inactive or not connected.

(b) COM (Cfg1) - Microphone Path 1 Selection

COM - Microphone Path 1 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg1>Microphone 1

- Used to adjust the microphone port used as microphone path 1.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No microphone selected.
- STD1: Standard microphone 1 input selected.
- STD2: Standard microphone 2 input selected.
- STD3: Standard microphone 3 input selected.
- DYN: Dynamic microphone input selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to STD1 in all installations.

(c) COM (Cfg1) - Microphone Path 2 Selection

COM - Microphone Path 2 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg1>Microphone 2

- Used to adjust the microphone port used as microphone path 2.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

EFFECTIVITY _____

ALL

34-24-61

Page 2-109
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Microphone Path 2 Selection

Settings:

- NONE: No microphone selected.
- STD1: Standard microphone 1 input selected.
- STD2: Standard microphone 2 input selected.
- STD3: Standard microphone 3 input selected.
- DYN: Dynamic microphone input selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(d) COM (Cfg1) - Microphone Activation

COM - Microphone Activation

Access: INSTALLATION MODE>COM>In/Out Cfg1>Both Mikes Active

- Used to adjust the PTT ports.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF:
 - If the PTT 1 input is activated, the audio signal of microphone path 1 is transmitted.
 - If the PTT 2 input is activated, the audio signal of microphone path 2 is transmitted.
- ON:
 - If PTT 1 or PTT 2 input is activated, the audio signal is transmitted from both microphone path 1 and path 2.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(e) COM (Cfg1) - Output 1 Selection

COM - Output 1 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg1>Output 1

- Used to adjust the audio output for output path 1.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No audio output selected.
- HDPH1: Headphones 1 port selected.

EFFECTIVITY

ALL

34-24-61

Page 2-110
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Output 1 Selection

NOTE : KX 200 with Retrofit Adapter

- Set it to HDPH1 in all installations.

(f) COM (Cfg1) - Output 2 Selection

COM - Output 2 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg1>Output 2

- Used to adjust the audio output for output path 2.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No audio output selected.
- HDPH2: Headphones 2 port selected.
- SPKR: Speaker port selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(22) COM I/O Configuration 2

- (a) The COM I/O configuration 2 settings are active when COMM_MIKESW_IN input (configuration selector) is active.

(b) COM (Cfg2) - Microphone Path 1 Selection

COM (Cfg2) - Microphone Path 1 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg2>Microphone 1

- Used to adjust the microphone port used as microphone path 1.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No microphone selected.
- STD1: Standard microphone 1 input selected.
- STD2: Standard microphone 2 input selected.
- STD3: Standard microphone 3 input selected.
- DYN: Dynamic microphone input selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(c) COM (Cfg2) - Microphone Path 2 Selection

EFFECTIVITY _____

ALL

34-24-61

Page 2-111
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM (Cfg2) - Microphone Path 2 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg2>Microphone 2

- Used to adjust the microphone port used as microphone path 2.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No microphone selected.
- STD1: Standard microphone 1 input selected.
- STD2: Standard microphone 2 input selected.
- STD3: Standard microphone 3 input selected.
- DYN: Dynamic microphone input selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(d) COM (Cfg2) - Microphone Activation

COM - Microphone Activation

Access: INSTALLATION MODE>COM>In/Out Cfg2>Both Mikes Active

- Used to adjust the PTT ports.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- OFF:
 - If the PTT 1 input is activated, the audio signal of microphone path 1 is transmitted.
 - If the PTT 2 input is activated, the audio signal of microphone path 2 is transmitted.
- ON:
 - If PTT 1 or PTT 2 input is activated, the audio signal is transmitted from both microphone path 1 and path 2.

NOTE : KX 200 with Retrofit Adapter

- Set it to OFF in all installations.

(e) COM (Cfg2) - Output 1 Selection

EFFECTIVITY _____

ALL

34-24-61Page 2-112
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Output 1 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg2>Output 1

- Used to adjust the audio output for output path 1.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No audio output selected.
- HDPH1: Headphones 1 port selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(f) COM (Cfg2) - Output 2 Selection

COM - Output 2 Selection

Access: INSTALLATION MODE>COM>In/Out Cfg2>Output 2

- Used to adjust the audio output for output path 2.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- NONE: No audio output selected.
- HDPH2: Headphones 2 port selected.
- SPKR: Speaker port selected.

NOTE : KX 200 with Retrofit Adapter

- Set it to NONE in all installations.

(23) COM - Standard Microphone 1 Sensitivity

NOTE: Usage of microphones that require a microphone sensitivity of more than 30 dB for standard microphones is not allowed.

COM - Standard Microphone 1 Sensitivity

Access: INSTALLATION MODE>COM>Std1 Mike Sens

- Used to adjust the sensitivity of standard microphone 1 input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Setting depends on the connected microphone and ambient noise level.
 - Range: 0 - 30 dB

EFFECTIVITY

ALL

34-24-61
 Page 2-113
 13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

(24) COM - Standard Microphone 2 Sensitivity

COM - Standard Microphone 2 Sensitivity

Access: INSTALLATION MODE>COM>Std2 Mike Sens

- Used to adjust the sensitivity of standard microphone 2 input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Setting depends on the connected microphone and ambient noise level.
 - Range: 0 - 44 dB

NOTE : KX 200 with Retrofit Adapter

- COM - Standard Microphone 2 Sensitivity is not applicable to this/these device(s).

(25) COM - Standard Microphone 3 Sensitivity

COM - Standard Microphone 3 Sensitivity

Access: INSTALLATION MODE>COM>Std3 Mike Sens

- Used to adjust the sensitivity of standard microphone 3 input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Setting depends on the connected microphone and ambient noise level.
 - Range: 0 - 44 dB

NOTE : KX 200 with Retrofit Adapter

- COM - Standard Microphone 3 Sensitivity is not applicable to this/these device(s).

(26) COM - Dynamic Microphone Sensitivity

NOTE: Usage of microphones that require a microphone sensitivity of more than 28 dB for standard microphones is not allowed.

COM - Dynamic Microphone Sensitivity

Access: INSTALLATION MODE>COM>Dyn Mike Sens

- Used to adjust the sensitivity of dynamic microphone input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Setting depends on the connected microphone and ambient noise level.
 - Range: 0 - 28 dB

EFFECTIVITY

ALL

34-24-61

 Page 2-114
 13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

COM - Dynamic Microphone Sensitivity

NOTE : KX 200 with Retrofit Adapter

- COM - Dynamic Microphone Sensitivity is not applicable to this/these device(s).

(27) COM - Auxiliary Audio Input Sensitivity

COM - Auxiliary Audio Input Sensitivity

Access: INSTALLATION MODE>COM>AuxIn Sensitivity

- Used to adjust the sensitivity of auxiliary audio input.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Setting depends on the audio signal level at the auxiliary audio input.
 - Range: 0 - 44 dB

NOTE : KX 200 with Retrofit Adapter

- COM - Auxiliary Audio Input Sensitivity is not applicable to this/these device(s).

(28) COM - Automatic Attenuation of Auxiliary Input

COM - Automatic Attenuation of Auxiliary Input

Access: INSTALLATION MODE>COM>AutoAux Att [dB]

- Used to adjust the attenuation level for the auxiliary audio input when the intercom function is active (active via VOX or COMM_IC_IN).
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Range: 0 - 34 dB

NOTE : KX 200 with Retrofit Adapter

- COM - Automatic Attenuation of Auxiliary Input is not applicable to this/these device(s).

(29) COM - Squelch Threshold

EFFECTIVITY _____

ALL

34-24-61

Page 2-115
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

COM - Squelch Threshold

Access: INSTALLATION MODE>COM>Squelch Thr [dB]

- Used to adjust the squelch level required to accept an audio signal from the radio receiver.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Range: 6 - 26
- Minimum adjustment of 6:
 - Weak RF signals can trigger the squelch threshold but the audio signal might be low combined with a noisy background.
- Maximum adjustment of 26:
 - Only strong RF signals will trigger the squelch threshold. The audio signal is audible very clear with very low background noise.
 - Weak RF signals cannot trigger the squelch threshold, so the user cannot hear the audio.

(30) COM - Scan Hold Time

COM - Scan Hold Time

Access: INSTALLATION MODE>COM>Scan Hold Time [s]

- Used to adjust the scan function.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Set it to 01 in all installations.

(31) COM - Sidetone Attenuation

COM - Scan Hold Time

Access: INSTALLATION MODE>COM>Sidetone Att [dB]

- Used to adjust the attenuation level applied to sidetone signal intercom.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Range: 0 - 12 dB
- The attenuation relates to the intercom volume:
 - 0 dB: sidetone as loud as intercom signal.
 - 12 dB: sidetone lower than the intercom signal.

EFFECTIVITY

ALL

34-24-61Page 2-116
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

(32) COM - Speaker Volume Source

COM - Speaker Volume Source
Access: INSTALLATION MODE>COM>Speaker Vol Src
- Used to select the source of the speaker volume control. • Turn the right rotary knob to do the selection. • Push to the right rotary knob to confirm the selection.
Settings: - Set it to PRIM in all installations.

(33) NAV - Glide Slope Adjustment



INSTALLATION AND OPERATION MANUAL

89000002-120

NAV - Glide Slope Adjustment

Access: INSTALLATION MODE>NAV>GS Adjustment> -

- Used to select the calibration point for glide slope signal adjustment.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Cal. Point:

- OFF: No point selected. The device does not generate calibration conditions for the glide slope outputs.
- Scale Up: The device generates at glide slope deflection output voltage for full scale up condition.
- Center: The device generates at glide slope deflection output voltage for full center condition.
- Scale Down: The device generates at glide slope deflection output voltage for full scale down condition.
- Full Flag: The device generates at glide slope flag output voltage for full flag visible condition.
- Half Flag: The device generates at glide slope flag output voltage for half flag visible condition.
- No Flag: The device generates at glide slope flag output voltage for no flag visible condition.

Full Scale Up:

- The device generates at glide slope deflection output voltage for full scale up condition.
- Range: -128 - 127

Full Center:

- The device generates at glide slope deflection output voltage for full center condition.
- Range: -128 - 127

Full Scale Down:

- The device generates at glide slope deflection output voltage for full scale down condition.
- Range: -128 - 127

Full Flag Visible:

- The device generates at glide slope flag output voltage for full flag visible condition.
- Range: -128 - 127

Half Flag Visible:

- The device generates at glide slope flag output voltage for half flag visible condition.
- Range: -128 - 127

No Flag Visible:

- The device generates at glide slope flag output voltage for no flag visible condition.
- Range: -128 - 127

(34) NAV - VOR/LOC Adjustment

(a) NAV - VOR Response Time

EFFECTIVITY

ALL

34-24-61Page 2-118
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

NAV - VOR Response Time

Access: INSTALLATION MODE>NAV>VOR/LOC Adjustment>VOR Respond Tim [s]

- Used to adjust the VOR response time in seconds.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Set it to 2.0 in all installations.

(b) NAV - LOC Response Time

NAV - LOC Response Time

Access: INSTALLATION MODE>NAV>VOR/LOC Adjustment>LOC Respond Tim [s]

- Used to adjust the LOC response time in seconds.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Set it to 0.6 in all installations.

(c) NAV - VOR/LOC Composite Signal Output Level

NAV - VOR/LOC Composite Signal Output Level

Access: INSTALLATION MODE>NAV>VOR/LOC Adjustment>Comp Output Lev [mV]

- Used to adjust the VOR/LOC composite signal output level in mV.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.

Settings:

- Range: 300 - 500.

(d) NAV - Clear NV-Memory Error

EFFECTIVITY _____

ALL

34-24-61

Page 2-119
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092299-001-01

Figure 2-50. Clear NV-Memory Error

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

NAV - Clear NV-Memory Error

Access: INSTALLATION MODE>NAV>Clear NV-Memory Error

- Possibility to delete the related memory errors.
 - Turn the right rotary knob to do the selection.
 - Push to the right rotary knob to confirm the selection.
 - The submenu shows "PRESS ENT TO CLEAR".
 - A short push to the right rotary knob deletes the related non-volatile memory errors and goes back to the previous menu.

N. DME - Transfer Protocol

- (1) Refer to Section 2, Paragraph L., Step (10).

O. Post Installation Check

- (1) After the device/system is installed completely do a test to make sure the system is functioning. Make sure that the compliance with the authority required procedures is complied with. The description that follows gives guidance for such tests.
- (2) Mechanical Installation and Wiring Check
 - (a) Make sure that all cables are fixed securely and shields connected properly to related ground.
 - (b) Examine the movement of controls to make sure that there is no interference.
 - (c) Make sure that all screws are tight and the connectors on the rear side of the device are secured.
 - (d) Make sure that the device is correctly attached to the mounting tray.
- (3) Power Supply
 - (a) Examine the power supply lines and the correct polarity.
 - (b) Make sure that the power supply is in the specified limits, with and without a running engine.
- (4) Power-On Check
 - (a) Power-up the aircraft systems and accept normal operation of all functions of the components.
- (5) Test - Transmit and Receive via Transceivers (COMs)
 - (a) Comply with the safety instructions, refer to Section 2, Paragraph E., Step (2).
 - (b) Connect a headset.



INSTALLATION AND OPERATION MANUAL

89000002-120

- (c) Power up the device/system and tune it to a local station for a communication test.
 - 1 Make sure that the output supplies a clear and readable audio and ask the local station for proper readability for the transmit signal of the device.
 - 2 Make sure the quality of clear audio from the microphone when selected for transmission and PTT key is pushed.
- (d) Repeat this communication test with an airborne station in $\approx$ 20-40 NM (Nautical Miles) (37-74 km).
- (6) Test - Audio from RX Sources
 - (a) Comply with the safety instructions, refer to Section 2, Paragraph E., Step (2).
 - (b) Connect a headset.
 - 1 Make sure that you can hear/receive all the installed RX-devices (NAV/ADF/DME). Use test signal generators/transmitters when necessary.
 - 2 Make sure that you can hear all the installed alert source when they send an alert/message.
- (7) Test - Speaker Output (if installed)
 - (a) Comply with the safety instructions, refer to Section 2, Paragraph E., Step (2).
 - (b) Select the speaker output.
 - 1 Make sure that all messages are heard clearly.
- (8) Antenna Check
 - (a) Examine the VSWR (voltage standing wave ratio) over the complete frequency band.
 - (b) The VSWR ratio should be less than 2:1 and is not acceptable when exceeding 3:1.
- (9) Test - VOR/ILS System
 - (a) Select a VOR frequency in a 40 NM (74 km) range.
 - (b) Listen to the VOR audio and ensure that there is no electrical interference such as magneto noise.
 - (c) Check the tone identifier filter operation.
 - (d) Fly inbound and outbound on the selected VOR radial and check for correct LEFT-RIGHT and TO-FROM indications.
 - (e) Check the VOR accuracy.

NOTE: VOR ground station scalloping must be available.
- (10) Interference Check
 - (a) Check the device/system while engine is running and powered on all other avionics/ electrical systems on the aircraft, to make sure that no significant interference exists.



INSTALLATION AND OPERATION MANUAL

89000002-120

- (b) Check also that the device does not cause significant interference with other systems.
- (c) The installer's standard test procedure may be used for the interference check and the table that follows can be taken as a reference.
- (d) Depending on the individual avionic systems installed in the aircraft, it might be necessary to extend the checklist.

Aircraft System Checklist	Function	
	OK	NOT OK
DME		
Audio		
Generators / Inverters		
GPS System		
Compass 1		
ADF		
VHF / NAV1 all channels		
VHF / NAV 2 all channels		
Marker Receiver		
Motor(s)		
Engine Instruments		
Storm scope		
Transponder		
Air Data Computer		
Autopilot and Servos		

- (e) Power the GPS and make sure that not less than 5 satellites are tracked.
- (f) Check the interference between the VHF-COM and the GPS receiver (when activated in NAV mode).
- (g) Select the channels/frequencies as follows on the device and on each frequency stay in TX and RX mode for at least 30 seconds.
- (h) Make sure that the GPS integrity flag is always out of view.

Channel	Frequency (MHz)		Channel	Frequency (MHz)
121.140	121.1416		131.240	131.2416
121.150	121.1500		131.250	131.2500
121.155	121.1500		131.255	131.2500
121.160	121.1583		131.260	131.2583
121.165	121.1666		131.265	131.2666

EFFECTIVITY

ALL

34-24-61

Page 2-123
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

121.175	121.1750		131.275	131.2750
121.180	121.1750		131.280	131.2750
121.185	121.1833		131.285	131.2833
121.190	121.1916		131.290	131.2916
121.200	121.2000		131.300	131.3000
121.205	121.2000		131.305	131.3000
121.210	121.2083		131.310	131.3083

For the other avionic equipment repeat all interference tests during a flight and include all equipment not before examined on ground. A communication performance check in the low, mid and high frequency band of the device should be included.

- (i) Make sure that the receiver output supplies a clear and understandable audio output.
 - (j) Make sure that the transmitter supplies a report of reliable communications by contacting another station.
 - (k) Do a range test with a station at least 328 ft (100 m) from your own position.
 - (l) Examine the intercom function by talking in the microphone, while the engine is running at cruising speed. You should hear yourself and/or your co-pilot loud and clear.
 - (m) Turn "ON" the squelch and make sure that the normal radio noise, without a present carrier signal, it will be constantly suppressed. The threshold of the squelch can be set in the user menu.
- (11) Flight Test Check
- (a) It is recommended to do a flight test as final installation verification.
 - (b) The performance of the device may be examined by contacting a ground station at a range of at least 50 NM (93 km) while maintaining an appropriate altitude and over all normal flight attitudes.
 - (c) Examine the performance in the low, mid and high band frequencies.

P. Error / Failure Indication

- (1) It is possible to read out error codes.
- (2) For read out refer to:
 - (a) Section 3, Paragraph C., Step (3)(b) and Section 3, Paragraph E., Step (17).
 - (b) Section 3, Paragraph C., Step (4)(b) and Section 3, Paragraph F., Step (12).
- (3) Failure description refer to: Section 3, Paragraph H., Step (2).

EFFECTIVITY

ALL

34-24-61

 Page 2-124
 13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

Q. Troubleshooting

(1) General:

- (a) If you cannot correct the problem, stop the use of the device(s) and contact authorized maintenance shop for assistance, please.

(2) Details about operation while there is an error refer to:

- (a) Section 3, Paragraph C., Step (3)(d) and Step (4)(d).

EFFECTIVITY

ALL

34-24-61

Page 2-125
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Blank Page

UP843765

EFFECTIVITY —————
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

SECTION 3 – OPERATION

A. General

- (1) This chapter contains general information and instructions for safe operation of the device(s).
 - (a) All control and display elements are on the front side.

NOTE: Some functions and adjustments are only available in the password-protected configuration setup - installation mode⁽¹⁾

NOTE: Some functions are only available when they are enabled for the user in the password-protected configuration setup - installation mode.⁽¹⁾

NOTE:

(1) Refer to Section 2, Paragraph N.

- (2) Registration of the Device
 - (a) Comply with the national requirements for operation of radio equipment.

B. Device Description


- (1) The KX 200 is a single block device with control panel. It combines a navigation receiver (NAV) and a VHF communication transceiver (COM) in one device.
- (2) Device Assignment
 - (a) This manual is valid for the devices:
 - 1 Refer to Section 2, Paragraph C.
- (3) Packing, Transport, Storage
 - (a) Refer to Section 2, Paragraph B.
- (4) Scope of Delivery
 - (a) Refer to Section 2, Paragraph C., Step (2).
- (5) State of Delivery
 - (a) Refer to Section 2, Paragraph C., Step (3).
- (6) Type Plate
 - (a) Refer to Section 2, Paragraph C., Step (6).

C. Controls and Indications

- (1) The front panel with display is divided in a COM area and a NAV area.
- (2) User Interface



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092300-001-01

Figure 3-1. KX 200 User Interface

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

	Element	Description	Function
1		Rotary knob, left side Single rotary knob +push function	Power ON/OFF, volume, functions ON/OFF - Short push to power up the device. - Long push to turn off the device. - Rotate to adjust the COM and NAV volume level of received signals. During COM mode: - Short push starts/stops the COM squelch function. - The squelch function remains active when NAV mode is selected. During NAV mode: - Short push to toggles between ID, voice, audio mode (For details refer to description no. 8).
2	COM	Pushbutton	- Short push starts the COM mode. During COM mode: - Long push shows the list "MENU".
3	RCNT (COM)	Pushbutton, "Recent" (frequency)	During COM mode: - Short push to toggle and leave the lists "RCNT" and "USER". • "RCNT" list, with up to ten recently selected active COM frequencies. • "USER" list with up to 50 stored COM frequencies. During NAV mode: - Short push starts the COM mode and the list of recently selected active COM frequencies.
4	MON	Pushbutton, "Monitoring"	During COM and NAV mode: - Short push starts/stops the COM frequency monitoring function. - The monitoring function remains active when NAV mode is selected.
5	 (COM)	Pushbutton, "COM transfer"	During COM and NAV mode: - Short push toggles between active and standby frequency.
6	NAV	Pushbutton	- Short push starts the NAV mode. During NAV mode: - Long push shows the list "MENU".

EFFECTIVITY

ALL

34-24-61

Page 3-3
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

	Element	Description	Function
7	RCNT (NAV)	Pushbutton, "Recent" (frequency)	During NAV mode: - Short push to toggle and leave the lists "RCNT" and "USER". • "RCNT" list with the recently selected active NAV frequencies. • "USER" list with up to 50 stored NAV frequencies. During COM mode: - Short push starts the NAV mode and the list of recently selected active NAV frequencies.
8	ID	Pushbutton	During COM and NAV mode: - Short push to ID toggles between ID, voice, audio mode. • ID: To hear only the ident signal (morse-code identification of the station). • V (voice): To hear only voice (ID is cut from signal). • No icon (audio): To hear both voice and ident signal.
9	 (NAV)	Pushbutton, NAV transfer	During COM and NAV mode: - Short push toggles between active and standby frequency.
10	 inner rotary	Rotary knob, inner and outer rotary knob+push function	- Turn the rotary knob to change the selected parameters (frequency, -). - Push to the rotary knob to select the entry. - Push to the rotary knob to confirm the adjustment.
11		Light sensor	Light sensor for brightness control (depends on configuration).
12		SD card slot	Used to update the channel database with external prepared settings (future functionality and additional equipment necessary).

(a) HMI Operation

1 The device identifies a:

- "Long push": when you push and hold a key for > 2 seconds.
- "Short push": when you push and hold a key for < 2 seconds.

(3) Description - COM Display

NOTE: The view and colors of the elements depend on the system status.

(a) COM Main View

EFFECTIVITY


ALL

34-24-61

Page 3-4
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092307-001-01

Figure 3-2. KX 200 - COM Main View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-2

- | | |
|-------------------------------------|--|
| 1. COM MODE STATUS | 11. FRAME |
| 2. INTERCOM STATUS | 12. STANDBY FREQUENCY |
| 3. SPEAKER STATUS | 13. STATION IDENTIFIER OF STANDBY
FREQUENCY |
| 4. VOLUME | 14. MONITORING STATUS |
| 5. VOLUME LEVEL | 15. STANDBY FREQUENCY LABEL |
| 6. TRANSMIT MODE | 16. ACTIVE FREQUENCY |
| 7. RECEIVE MODE | 17. STATION IDENTIFIER OF ACTIVE
FREQUENCY |
| 8. ERROR (ER) OR WARNING (WR) | 18. SQUELCH STATUS |
| 9. SIGNAL DETECTION | 19. ACTIVE FREQUENCY LABEL |
| 10. RECEIVE FOR MONITORED FREQUENCY | |

(b) COM Menu Mode



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092308-001-01

Figure 3-3. KX 200 - COM Menu View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-3

- | | |
|---|----------------------|
| 1. ELEMENTS OF THE COM MAIN SCREEN,
REFER TO Step (3)(a) | 5. PARAMETER NAME |
| 2. SELECTED LIST ENTRY | 6. FRAME |
| 3. SCROLL BAR | 7. LIST LABEL "MENU" |
| 4. PARAMETER VALUE | |

(c) COM Recent and User Frequency Menu



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092309-001-01

Figure 3-4. KX 200 - COM Recent Frequency View




INSTALLATION AND OPERATION MANUAL
89000002-120

Key to Figure 3-4

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE COM MAIN SCREEN,
REFER TO Step (3)(a) | 5. STATION IDENTIFIER |
| 2. SELECTED LIST ENTRY | 6. FRAME |
| 3. SCROLL BAR | 7. LIST LABEL "RCENT", "USER" |
| 4. FREQUENCY VALUE | |
-



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092310-001-01

Figure 3-5. KX 200 - COM User Frequency View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-5

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE COM MAIN SCREEN,
REFER TO Step (3)(a) | 5. STATION IDENTIFIER |
| 2. SELECTED LIST ENTRY | 6. FRAME |
| 3. SCROLL BAR | 7. LIST LABEL "RCENT", "USER" |
| 4. FREQUENCY VALUE | |

(d) COM Error and Warning View



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092311-001-01

Figure 3-6. KX 200 - COM Error View




INSTALLATION AND OPERATION MANUAL
89000002-120

Key to Figure 3-6

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE COM MAIN SCREEN,
REFER TO Step (3)(a) | 4. SCROLL BAR |
| 2. SELECTED LIST ENTRY | 5. FRAME |
| 3. ERROR NAME, WARNING NAME | 6. LIST LABEL "ERROR", "WARN" |
-



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092312-001-01

Figure 3-7. KX 200 - COM Warning View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-7

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE COM MAIN SCREEN,
REFER TO Step (3)(a) | 4. SCROLL BAR |
| 2. SELECTED LIST ENTRY | 5. FRAME |
| 3. ERROR NAME, WARNING NAME | 6. LIST LABEL "ERROR", "WARN" |

(e) COM Incorrect Parameter (Example)



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092313-001-01

Figure 3-8. KX 200 - COM Incorrect Parameter View



INSTALLATION AND OPERATION MANUAL

89000002-120

Key to Figure 3-8

INCORRECT SETTINGS ARE CROSSED
OUT WITH A RED "X"


(4) Description - NAV Display

NOTE: The view and colors of the elements depend on the system status.

(a) NAV Main View



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092314-001-01

Figure 3-9. KX 200 - NAV Main View

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-9

- | | |
|--|---|
| 1. NAV MODE STATUS | 8. FRAME |
| 2. VOLUME | 9. STANDBY FREQUENCY LABEL |
| 3. VOLUME LEVEL | 10. ACTIVE FREQUENCY |
| 4. LOCALIZER MODE | 11. STATION IDENTIFIER OF ACTIVE FREQUENCY |
| 5. ERROR (ER) OR WARNING (WR) | 12. NAV AUDIO MODE STATUS (ID, V, EMPTY INDICATION) |
| 6. STANDBY FREQUENCY | 13. ACTIVE FREQUENCY LABEL |
| 7. STATION IDENTIFIER OF STANDBY FREQUENCY | |

(b) NAV Menu Mode



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092315-001-01

Figure 3-10. KX 200 - NAV Menu View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120


Key to Figure 3-10

- | | |
|---|----------------------|
| 1. ELEMENTS OF THE NAV MAIN SCREEN,
REFER TO Step (4)(a) | 5. FRAME |
| 2. SELECTED LIST ENTRY | 6. PARAMETER NAME |
| 3. PARAMETER VALUE | 7. LIST LABEL "MENU" |
| 4. SCROLL BAR | |

(c) NAV Recent and User Frequency Menu



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092316-001-01

Figure 3-11. KX 200 - NAV Recent Frequency View




INSTALLATION AND OPERATION MANUAL
89000002-120

Key to Figure 3-11

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE NAV MAIN SCREEN,
REFER TO Step (4)(a) | 5. STATION IDENTIFIER |
| 2. SELECTED LIST ENTRY | 6. FRAME |
| 3. SCROLL BAR | 7. LIST LABEL "RCENT", "USER" |
| 4. FREQUENCY VALUE | |
-



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092317-001-01

Figure 3-12. KX 200 - NAV User Frequency View

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

Key to Figure 3-12

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE NAV MAIN SCREEN,
REFER TO Step (4)(a) | 5. STATION IDENTIFIER |
| 2. SELECTED LIST ENTRY | 6. FRAME |
| 3. SCROLL BAR | 7. LIST LABEL "RCENT", "USER" |
| 4. FREQUENCY VALUE | |

(d) NAV Error and Warning View



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092318-001-01

Figure 3-13. KX 200 - NAV Error View

EFFECTIVITY _____
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

Key to Figure 3-13

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE NAV MAIN SCREEN,
REFER TO Step (4)(a) | 4. SCROLL BAR |
| 2. SELECTED LIST ENTRY | 5. FRAME |
| 3. ERROR NAME, WARNING NAME | 6. LIST LABEL "ERROR", "WARN" |
-



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092319-001-01

Figure 3-14. KX 200 - NAV Warning View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

Key to Figure 3-14

- | | |
|---|-------------------------------|
| 1. ELEMENTS OF THE NAV MAIN SCREEN,
REFER TO Step (4)(a) | 4. SCROLL BAR |
| 2. SELECTED LIST ENTRY | 5. FRAME |
| 3. ERROR NAME, WARNING NAME | 6. LIST LABEL "ERROR", "WARN" |
-

D. Start-Up

- Safety Instructions**
- Excessive pulses on the DC bus of the aircraft can cause damage on electrical circuits of any installed instrument.
 - Do not turn on the device during engine start or shutdown.

NOTE : Polarizing sunglasses can reduce the readability of the display.

- (1) Power up the device:
 - (a) Short push to the rotary knob (left) or power ON signal of the aircraft installation.
 - 1 The initialization and self-test (PBIT) start.
 - 2 The display shows the start screen with the company logo and the device/system name.
 - (b) After successful start-up the device is ready to use.

EFFECTIVITY

ALL

34-24-61

Page 3-30
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092320-001-01

Figure 3-15. KX 200 - Ready for Operation (Example)

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

NOTE: Some functions and adjustments are only available in the password-protected configuration setup - installation mode⁽¹⁾

NOTE: Some functions are only available when they are enabled for the user in the password-protected configuration setup - installation mode.⁽¹⁾

NOTE:

(1) Refer to Section 2, Paragraph N.

(2) Prevent Hearing Damage

CAUTION: LISTENING AT HIGH VOLUMES THROUGH HEADPHONES, HEADSETS OR IN CLOSE DISTANCE TO A LOUDSPEAKER CAN CAUSE HEARING DAMAGE.

CAUTION: THE LONGER YOU ARE EXPOSED TO A HIGH ACOUSTIC SOUND LEVEL, THE MORE QUICKLY YOUR HEARING CAN BE DAMAGED.

Safety Instructions

- Comply with the operating instruction of the used equipment.
- Do not increase the volume to suppress ambient noise.
- Recommendation: Use noise-canceling headphones (reduces ambient noise, volume can be turned down to minimum).
- Slowly increase the volume until you can hear the sound clearly and without distortion.

E. COM Operation

EFFECTIVITY

ALL

34-24-61

Page 3-32
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092321-001-01

Figure 3-16. KX 200 - COM Mode Active (Example)

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL 89000002-120

(1) Start COM Mode



COM
Pushbutton



Display Status
Icon

- Short push to COM pushbutton starts the COM mode.
- The backlight color of the pushbutton is green (intensity depends on the brightness settings).
- The COM mode status icon is highlighted in green.

(2) COM - Volume Adjustment

CAUTION: OBEY THE SAFETY INSTRUCTIONS. REFER TO PREVENT HEARING DAMAGE PREVENT HEARING DAMAGE.



Volume Control



Minimum Level

- Turn the left rotary knob to adjust the volume level.
- If the volume level is set to the minimum, the color of the volume elements changes to amber.

(3) COM - Receive Operation Mode



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092326-001-01

Figure 3-17. Receive Mode

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) If no PTT (Push To Talk) button is active, the transceiver stays in receive mode.
 - 1 The "RX" symbol shows that the device is in receive mode.
- (b) A mixed signal is supplied on the headphone(s) outputs (if enabled), it is mixed of the:
 - 1 Received signal from antenna.
 - 2 Intercom signal from intercom circuit one and two (depends on configuration).
 - 3 Signal from auxiliary input (depends on configuration).
- (c) A mixed signal is supplied on the speaker output (if enabled), it is mixed of the:
 - 1 Received signal from antenna.
 - 2 Signal from auxiliary input (depends on configuration).
- (4) COM - Transmit Operation Mode



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092327-001-01

Figure 3-18. Transmit Mode

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) If a PTT (Push To Talk) button is active (Push To Talk button is pushed) the transceiver is set to transmit mode.
- 1 The "TX" symbol shows that the device is in transmit mode.
 - 2 The PTT 1 input starts transmission from microphone path 1.
 - 3 The PTT 2 input starts transmission from microphone path 2.
 - 4 If "BOTH MIKES" is enabled in the configuration, each input (PTT 1 or 2) can start the transmission from both microphone paths at the same time.
- (b) The sidetone (demodulated audio of the emitted signal) is available on the headphone output.
- (c) The transmit mode automatically deactivates the speaker.
- (d) For transmission is always the active frequency (ACT) used, also if the monitored frequency is currently audible.
- (e) If TX on the standby frequency (STB) is required, push the COM transfer pushbutton to change active and standby frequency.



COM Transfer Pushbutton

NOTE: KX 200 with Retrofit Adapter

- Functions "PTT 2 on microphone path 2" and "BOTH MIKES" are not applicable to this/these device(s).

- NOTE:**
- In transmit mode some user actions are blocked which are normally permitted in receive mode.
 - Changes e.g. the standby frequency are possible during transmission.
 - In transmit mode the intercom operation behavior depends on configuration.
 - If the PTT1 input is started and ISOL is active the passenger intercom operation on second intercom circuit is still possible.
 - The transmit mode is automatically terminated (return to receive mode) after 35 seconds of continuous transmitting.
 - The display shows "PTT STUCK", refer to Section 3, Paragraph H., Step (2).
 - For the start of a new transmission first it is necessary to set the PTT line inactive.

(5) COM - Channel Spacing

- (a) The transceiver can operate in 25 kHz frequency channel spacing or in 8.33/25 kHz mixed mode.
- (b) The channel spacing for operation is adjustable, refer to Step (16).

EFFECTIVITY

ALL

34-24-61

Page 3-38
13 Aug 2025



INSTALLATION AND OPERATION MANUAL

89000002-120

- (6) COM - Select a Standby Frequency



COM Pushbutton

EFFECTIVITY

ALL

34-24-61

Page 3-39
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092328-001-01

Figure 3-19. Select a Standby Frequency

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(a) Condition: The COM area is selected. The standby frequency frame is in view.

1 Turn the right rotary knob (inner and outer) to adjust a standby frequency.



Inner/Outer Rotary Knob (Right side)

2 Turn the outer rotary knob clockwise/counterclockwise to change the values in one MHz steps.

a Range: MHz steps between 118 - 136 MHz.

3 Turn the inner rotary knob clockwise/counterclockwise to change the values in 25/8.33 kHz steps.

a Range: 25 kHz steps between 000 - 975 kHz.

b Range: 8.33 kHz steps between 000 - 990 kHz.

NOTE: Changes of the standby frequency is possible during transmission.

NOTE: If the selected frequency is available in the user frequency list, the related station ID is shown below the frequency.

NOTE: If more than one station IDs are assigned to the selected frequency, the first station ID from the list is shown.

(7) COM - Select an Active Frequency



COM Transfer Pushbutton

(a) During COM and NAV mode:

1 Push the COM transfer pushbutton to change active and standby frequency.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092329-001-01

Figure 3-20. Select an Active Frequency

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

2 For conditions and procedure, refer to COM - Select a Standby Frequency.

NOTE: It is not possible to toggle between the active and standby frequencies during transmission.

(8) COM - Select a Recent Frequency

EFFECTIVITY


ALL

34-24-61

Page 3-43
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092330-001-01

Figure 3-21. Recent Frequency List

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) During COM and NAV mode:
 - 1 Push on the COM "RCNT" pushbutton starts the recent frequency list.
 - 2 Turn the right rotary knob to scroll through the entries.
 - 3 A short push to the right rotary knob confirms the selection.
 - a The frequency with the related station identifier is set as the standby frequency.
- (b) Menu content:
 - 1 List of the recent 10 (active) frequencies.
- (c) Leave menu:
 - 1 A short push on the "COM" pushbutton leaves the menu.
 - a The COM main view is shown.
- (9) COM - Select a User Frequency

EFFECTIVITY

ALL

34-24-61Page 3-45
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092331-001-01

Figure 3-22. User Frequency List

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(a) During COM mode:

- 1 Push on the "RCNT" pushbutton starts the recent frequency list.
- 2 Push on the COM "RCNT" pushbutton:
 - a The user frequency list is shown.
- 3 Turn the right rotary knob to scroll through the entries.
- 4 A short push to the right rotary knob confirms the selection.
 - a The frequency with the related station identifier is set as the standby frequency.

(b) Menu content:

- 1 List with up to 50 stored user frequencies with an assigned station identifier.

(c) Leave menu:

- 1 A short push on the "COM" pushbutton leaves the menu.
 - a The COM main view is shown.



NOTE: If no frequencies are stored only the entry "Add New" is listed. To add, edit, delete and store user frequencies refer to Step (10) and Step (11).

(10) COM - Edit, Add, Store a User Frequency

EFFECTIVITY

ALL

34-24-61

 Page 3-47
 13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092333-001-01

Figure 3-23. User Frequency List

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) It is possible to store up to 50 user frequencies with related station identifier for each of them in the COM user frequency list.
- (b) During COM mode:
 - 1 Push on the "RCNT" pushbutton starts the recent frequency list.
 - 2 Push on the "RCNT" pushbutton again:
 - a The user frequency list is shown.
 - 3 Turn the right rotary knob to scroll through the entries and select one list entry to change it or select "Add New" to add one more.

EFFECTIVITY

ALL

34-24-61Page 3-49
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092334-001-01

Figure 3-24. Confirm the Selection

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- 4 A short push to the right rotary knob confirms the selection.
- a The user frequency edit mode is shown.
- b The digits of the station identifier are highlighted.



Inner/Outer Rotary Knob (Right side)

- 5 Turn the inner rotary knob to move between station ID and frequency and select the entry to edit.
- 6 A short push to the right rotary knob confirms the selection.
- a The adjustable value is shown inverted.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092335-001-01

Figure 3-25. Edit Station ID

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(c) Edit the station ID:

- 1 Turn the outer rotary knob to change the value of the digit.
 - a Max. 8 digits are possible for the station ID label.
 - b The possible values are: blank space, A - Z, 0 - 9, ., _, :, <, >, =.
- 2 Turn the inner rotary knob to move between the digits.
- 3 A short push to the right rotary knob confirms the completed setting.

EFFECTIVITY _____

ALL

34-24-61Page 3-53
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092336-001-01

Figure 3-26. Edit Frequency

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(d) Edit the frequency:

- 1 Turn the inner rotary knob to select the frequency.
- 2 A short push to the right rotary knob confirms the selection.
 - a The adjustable value is shown inverted.
- 3 Turn the outer rotary knob clockwise/counterclockwise to change the values in one MHz steps.
 - a Range: MHz steps between 118 - 136 MHz.
- 4 Turn the inner rotary knob clockwise/counterclockwise to change the values in 25/8.33 kHz steps.
 - a Range: 25 kHz steps between 000 - 975 kHz.
 - b Range: 8.33 kHz steps between 000 - 990 kHz.
- 5 A short push to the right rotary knob confirms the selection.

NOTE: The adjustable frequency range and the frequency steps depend on the set channel spacing.

(e) Leave the mode:

- 1 A long push to the right rotary knob leaves the edit mode.
 - a The user frequency list is shown.
 - b The new and/or the changed entries are available.

(11) COM - Delete a User Frequency

EFFECTIVITY

ALL

34-24-61

Page 3-55
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092337-001-01

Figure 3-27. Delete List Entry

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

During COM mode:

- 1 Push on the "RCNT" pushbutton starts the recent frequency list.
- 2 Push on the "RCNT" pushbutton again:
 - a The user frequency list is shown.
- 3 Turn the right rotary knob to scroll through the entries and select the list entry to delete.
- 4 A long push to the "RCNT" pushbutton deletes the selected list entry.


EFFECTIVITY

ALL

34-24-61Page 3-57
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092338-001-01

Figure 3-28. Squelch ON

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(12) COM - Squelch

(a) Condition: The COM area is selected.

1 Push the left rotary knob toggles between squelch ON/OFF.

a The "SQ" symbol shows that squelch is on.2 If the received signal is too weak, it is muted when squelch is on. This prevents interference noise.a The signal suppression depends on the set squelch threshold.**NOTE:** The squelch threshold is adjustable, refer to Step (16).

(13) COM - Frequency Monitoring



COM Monitoring Pushbutton

(a) The function enables monitoring of the COM standby frequency, while listening to the COM active frequency.

(b) Push the MON pushbutton toggles between monitoring ON/OFF.

1 The "MON" symbol shows that the device is in monitoring mode.



Monitoring ON

NOTE: It is possible to toggle between monitoring ON/OFF during the device is in NAV operation.

(c) Signal detected on the monitored frequency:

1 A symbol shows that a signal is detected on the standby frequency.

2 Conditions:a Monitoring function is ON.b A signal is detected on the active frequency and is heard through the speaker or headphone.c A signal is detected on the standby frequency.



INSTALLATION AND OPERATION MANUAL

89000002-120

(d) Receive mode of the monitored frequency:

- 1 A "RX" symbol shows that a signal is detected on the standby frequency.



- 2 Conditions:

- a Monitoring function is ON.
- b Squelch function is ON.
- c A signal is detected on the standby frequency and is heard through the speaker or headphone.

NOTE: If the active and standby frequency detects a signal at the same time, the active frequency has priority.

NOTE: For transmission the active frequency is always used, also if the monitored standby frequency is currently audible.

NOTE: If transmission on the standby frequency is required, push the COM transfer pushbutton to change active and standby frequency.



COM Transfer Pushbutton

(14) COM - Intercom (IC)

(a) The intercom operation depends on device intercom settings and wiring.

- 1 The intercom operation can be started automatically with VOX (with adjustable threshold) or externally with an intercom switch.

(b) The VOX function cannot operate in:

- 1 Installations with high level of ambient noise.
- 2 Operation when speaker is enabled.

(c) If installed:

- 1 An external switch makes it possible to select the intercom operation manually.

NOTE: NOTICE: The settings of VOX ON/OFF, IC volume and VOX threshold are adjustable, refer to COM - Menu Mode.

- 2 Condition: The COM area is selected.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092344-001-01

Figure 3-29. Intercom Active

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL
89000002-120

a The white "IC" symbol shows that intercom is active.

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092345-001-01

Figure 3-30. Intercom Inactive

EFFECTIVITY _____
ALL

34-24-61

UP843765



INSTALLATION AND OPERATION MANUAL

89000002-120

- b The amber "IC" symbol shows that intercom is inactive.
- c The automatic start through VOX is off.

(15) COM - Speaker

EFFECTIVITY

ALL

34-24-61

Page 3-64
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092347-001-01

Figure 3-31. Speaker Active

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) The speaker operation depends on configuration and wiring (one or more speakers).

- 1 The speaker symbol shows that the speaker is active.



Speaker Symbol

NOTE: KX 200 with Retrofit Adapter

- The operation with speaker is not applicable to this/these device(s).



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092348-001-01

Figure 3-32. KX 200 - COM Menu View

EFFECTIVITY

ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(16) COM - Menu Mode

(a) During COM mode:

- 1 A long push on the "COM" pushbutton starts the user menu.
- 2 Turn the right rotary knob to scroll through the entries.
- 3 A short push to the right rotary knob selects the highlighted entry or starts the related submenu.
 - a The adjustable value is shown inverted.
- 4 Turn the right rotary knob to adjust/select the function.
- 5 A short push to the right rotary knob confirms the setting.

(b) Menu content:

- 1 Intercom Menu: Submenu for intercom settings.
 - a IC volume, VOX on/off, VOX threshold.
- 2 Squelch Thr (dB): Squelch threshold level.⁽¹⁾

NOTE:

(1) SQ TRH:

- Minimum adjustment of 6:
 - Weak RF signals can trigger the squelch threshold but the audio signal might be low combined with a noisy background.
- Maximum adjustment of 26:
 - Only strong RF signals will trigger the squelch threshold. The audio signal is audible very clear with very low background noise.
 - Weak RF signals cannot trigger the squelch threshold, so the user cannot hear the audio.

- 3 SPACING: Channel spacing.
 - a 25 kHz only or 8.33 kHz (=25 +8.33 kHz).
- 4 Brightness: Display and pushbutton brightness (function depend on configuration).
- 5 SHOW ALERTS: List of COM errors and warnings, check if errors are active.

(c) Leave menu:

- 1 A short push on the "COM" pushbutton leaves the menu.
 - a The COM main view is shown.

(17) COM - Error and Warning Message

EFFECTIVITY

ALL

34-24-61Page 3-68
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092349-001-01


Figure 3-33. KX 200 - COM Error View

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092350-001-01

Figure 3-34. KX 200 - COM Warning View

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) The COM error or COM warning list comes into view if at least one COM error/warning is found.
 - 1 Error (ER) or Warning (WR) is shown on the COM display.
 - 2 Some messages can be reset manually.
- (b) Move through the list:
 - 1 Turn the right rotary knob to scroll through the entries.
 - 2 A short push to the right rotary knob selects the highlighted entry.
 - a The adjustable entry is shown inverted.
 - 3 A short push to the right rotary knob reset the message.
 - a Errors/warning messages are removed from the list if they are reset manually or are no longer active.
- (c) Leave view:
 - 1 All active acknowledgeable errors/warnings are confirmed.
 - 2 All active errors/warnings become inactive.
- (d) Possible content:
 - 1 For details refer to Section 3, Paragraph H.

F. NAV Operation

EFFECTIVITY

ALL

34-24-61Page 3-71
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092351-001-01

Figure 3-35. KX 200 - NAV Mode Active (Example)

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(1) Start NAV Mode

- (a) Short push to NAV pushbutton starts the NAV mode.



NAV Pushbutton

- 1 The backlight color of the pushbutton is green (intensity depends on the brightness settings).
- 2 The NAV mode status icon is highlighted in green.



Display Status Icon

(2) NAV - Volume Adjustment


CAUTION: OBEY THE SAFETY INSTRUCTIONS. REFER TO PREVENT HEARING DAMAGE.

- (a) Turn the left rotary knob to adjust the volume level.



Volume Control

- (b) If the volume level is set to the minimum, the color of the volume elements changes to amber.




Minimum Level

(3) NAV - VOR/LOC/GS Mode

- (a) The VOR/LOC/GS operation depends on configuration and the installed navigation equipment.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092354-001-01

Figure 3-36. Localizer Channel Selected

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (4) NAV - Audio Mode Control
 - (a) During COM and NAV mode:

EFFECTIVITY

ALL

34-24-61

Page 3-75
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092355-001-01

Figure 3-37. Audio Mode Control

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- 1 Short push to ID toggles between ID, voice, audio mode.
 - a ID: To hear only the ident signal (morse-code identification of the station).
 - b V (voice): To hear only voice (ID is cut from signal).
 - c No icon (audio): To hear both voice and ident signal.



- 2 During NAV mode:
 - a Short push to the left rotary knob or the ID pushbutton toggles between ID, voice, audio mode.

(5) NAV - Select a Standby Frequency

- (a) Condition: The NAV area is selected. The standby frequency frame is in view.



NAV Pushbutton

- 1 Turn the right rotary knob (inner and outer) to adjust a standby frequency.

EFFECTIVITY _____

ALL

34-24-61Page 3-77
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092356-001-01

Figure 3-38. Standby Frequency Frame

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- 2 Turn the outer rotary knob clockwise/counterclockwise to change the values in one MHz steps.

a Range: MHz steps between 108 - 117 MHz.

- 3 Turn the inner rotary knob clockwise/counterclockwise to change the values in 50 kHz steps.



Inner/Outer Rotary Knob (Right side)

a Range: kHz steps between 0 - 950 kHz.

NOTE: If the selected frequency is available in the user frequency list, the related station ID is shown below the frequency.

NOTE: If more than one station IDs are assigned to the selected frequency, the first station ID from the list is shown.

- (6) NAV - Select an Active Frequency



NAV Transfer Pushbutton

- (a) During COM and NAV mode:

- 1 Push the NAV transfer pushbutton to change active and standby frequency.

EFFECTIVITY

ALL

34-24-61

Page 3-79
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092357-001-01

Figure 3-39. Change Active and Standby Frequency

UP843765

EFFECTIVITY _____
ALL

34-24-61




INSTALLATION AND OPERATION MANUAL
89000002-120

2 For conditions and procedure refer to Step (5).

(7) NAV - Select a Recent Frequency



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092359-001-01

Figure 3-40. Recent Frequency List

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (a) During COM and NAV mode:
 - 1 Push on the NAV "RCNT" pushbutton starts the recent frequency list.
 - 2 Turn the right rotary knob to scroll through the entries.
 - 3 A short push to the right rotary knob confirms the selection.
 - a The frequency with the related station identifier is set as the standby frequency.
- (b) Menu content:
 - 1 List of the recent 10 (active) frequencies.
- (c) Leave menu:
 - 1 A short push on the "NAV" pushbutton leaves the menu.
 - a The NAV main view is shown.


EFFECTIVITY

ALL

34-24-61Page 3-83
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092360-001-01

Figure 3-41. User Frequency List

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(8) NAV - Select a User Frequency

(a) During NAV mode:

- 1 Push on the "RCNT" pushbutton starts the recent frequency list.
- 2 Push on the "RCNT" pushbutton again:
 - a The user frequency list is shown.
- 3 Turn the right rotary knob to scroll through the entries.
- 4 A short push to the right rotary knob confirms the selection.
 - a The frequency with the related station identifier is set as the standby frequency.

(b) Menu content:

- 1 List with up to 50 stored user frequencies with an assigned station identifier.

(c) Leave menu:

- 1 A short push on the "NAV" pushbutton leaves the menu.
 - a The NAV main view is shown.



NOTE: If no frequencies are stored only the entry "Add New" is listed. To add, edit, delete and store user frequencies refer to

- Step (9).
- Step (10).



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092361-001-01

Figure 3-42. User Frequency List

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- (9) NAV - Edit, Add, Store a User Frequency
- (a) It is possible to store up to 50 user frequencies with related station identifier for each of them in the NAV user frequency list.
 - (b) During NAV mode:
 - 1 Push on the "RCNT" pushbutton starts the recent frequency list.
 - 2 Push on the "RCNT" pushbutton again:
 - a The user frequency list is shown.
 - 3 Turn the right rotary knob to scroll through the entries and select one list entry to change it or select "Add New" to add one more.


EFFECTIVITY

ALL

34-24-61Page 3-87
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092362-001-01

Figure 3-43. Confirm Selection

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

- 4 A short push to the right rotary knob confirms the selection.
 - a The user frequency edit mode is shown.
 - b The digits of the station identifier are highlighted.



Inner/Outer Rotary Knob (Right side)

- 5 Turn the inner rotary knob to move between station ID and frequency and select the entry to edit.
- 6 A short push to the right rotary knob confirms the selection.
 - a The adjustable value is shown inverted.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092363-001-01

Figure 3-44. Edit Station ID

UP843765

EFFECTIVITY _____
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

(c) Edit the station ID:

- 1 Turn the outer rotary knob to change the value of the digit.
 - a Max. 8 digits are possible for the station ID label.
 - b The possible values are: blank space, A - Z, 0 - 9, ., _, :, <, >, =.
- 2 Turn the inner rotary knob to move between the digits.
- 3 A short push to the right rotary knob confirms the completed setting.

EFFECTIVITY _____


ALL

34-24-61

Page 3-91
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092364-001-01

Figure 3-45. Edit Frequency

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(d) Edit the frequency:

- 1 Turn the inner rotary knob to select the frequency.
- 2 A short push to the right rotary knob confirms the selection.
 - a The adjustable value is shown inverted.
- 3 Turn the outer rotary knob clockwise/counterclockwise to change the values in one MHz steps.
 - a Range: MHz steps between 108 - 117 MHz.
- 4 Turn the inner rotary knob clockwise/counterclockwise to change the values in 50 kHz steps.
 - a Range: kHz steps between 0 - 950 kHz.
- 5 A short push to the right rotary knob confirms the selection.

(e) Leave the mode:

- 1 A long push to the right rotary knob leaves the edit mode.
 - a The user frequency list is shown.
 - b The new and/or the changed entries are available.

(10) NAV - Delete a User Frequency

EFFECTIVITY

ALL

34-24-61Page 3-93
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092365-001-01

Figure 3-46. Delete List Entry

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120

During NAV mode:

- 1 Push on the "RCNT" pushbutton starts the recent frequency list.
- 2 Push on the "RCNT" pushbutton again:
 - a The user frequency list is shown.
- 3 Turn the right rotary knob to scroll through the entries and select the list entry to delete.
- 4 A long push to the "RCNT" pushbutton deletes the selected list entry.

EFFECTIVITY


ALL

34-24-61

Page 3-95
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092366-001-01

Figure 3-47. KX 200 - NAV Menu View

UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(11) NAV - Menu Mode

(a) During NAV mode:

- 1 A long push on the "NAV" pushbutton starts the user menu.
- 2 Turn the right rotary knob to scroll through the entries.
- 3 A short push to the right rotary knob selects the highlighted entry or starts the related submenu.
 - a The adjustable value is shown inverted.
- 4 Turn the right rotary knob to adjust/select the function.
- 5 A short push to the right rotary knob confirms the setting.

(b) Menu content:


- 1 AUDIO MODE: Selection of filters for the NAV audio output.
 - a ID: To hear only the ident signal (Morse-code identification of the station).
 - b V (voice): To hear only voice (ID is cut from signal).
 - c No icon (audio): To hear both voice and ident signal.
- 2 BRIGHTNESS: Display and pushbutton brightness (Function depend on configuration).
- 3 SHOW ALERTS: List of NAV errors and warnings, check if errors are active.

(c) Leave menu:

- 1 A short push on the "NAV" pushbutton leaves the menu.
 - a The NAV main view is shown.



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092367-001-01

Figure 3-48. KX 200 - NAV Error View


UP843765

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL
89000002-120



ICN-55939-1000092368-001-01

Figure 3-49. KX 200 - NAV Warning View

EFFECTIVITY
ALL

34-24-61



INSTALLATION AND OPERATION MANUAL

89000002-120

(12) NAV and Control Head - Error and Warning Messages

- (a) The NAV error or NAV warning list comes into view if at least one COM error/warning is found.
- (b) The failure messages from control head (CH) are also shown on the NAV display.
 - 1 Error (ER) or Warning (WR) is shown on the NAV display.
 - 2 Some messages can be reset manually.
- (c) Move through the list:
 - 1 Turn the right rotary knob to scroll through the entries.
 - 2 A short push to the right rotary knob selects the highlighted entry.
 - a The adjustable entry is shown inverted.
 - 3 A short push to the right rotary knob reset the message.
 - a Errors/warning messages are removed from the list if they are reset manually or are no longer active.
- (d) Leave view:
 - 1 All active acknowledgeable errors/warnings are confirmed.
 - 2 All active errors/warnings become inactive.
- (e) Possible content:
 - 1 For details refer to Section 3, Paragraph H., Step (2).

G. Troubleshooting

- (1) General:
 - (a) If you cannot correct the problem, stop the use of the device(s) and contact authorized maintenance shop for assistance, please.
- (2) Error List
 - (a) For details about operation while there is an error refer to:
 - 1 Section 3, Paragraph C., Step (3)(d) and Step (4)(d).

Table 3-1. Error List

Error/Warning List	Symptom / Action / Check
COM	
INTERNAL IC	Error: Acknowledgeable Problem communicating with internal circuits. Possible cause: - HW or SW failure inside the transceiver.

EFFECTIVITY

ALL

34-24-61Page 3-100
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table 3-1. Error List (Cont)

Error/Warning List	Symptom / Action / Check
RECEIVER	Error: Acknowledgeable The receiver test failed. During the test the receiver board input is disconnected from antenna. The internal loop is active. Possible cause: - HW failure inside the transceiver.
PWR SUPPLY	Error: Acknowledgeable The internal voltages are out of range. Possible cause: - HW failure inside the transceiver.
RXS LOCK	Error: Acknowledgeable The receiver's synthesizer failed to lock. Possible cause: - HW or SW failure inside the transceiver.
TXS LOCK	Error: Acknowledgeable The transmitter's synthesizer failed to lock. Possible cause: - HW or SW failure inside the transceiver.
TX POWER	Error: Acknowledgeable The power at the antenna output is too low. Possible cause: - The transmitter is damaged - The power detection circuit is damaged.
TX OVERLOAD	Error: Acknowledgeable The power at the antenna output is too high. TX overload protection procedure reduces signal power 50 times during single transmission. Possible cause: - The transmitter is damaged.
NV-MEMORY	Error: Acknowledgeable Factory setup and configuration data block missing. Possible cause: - Main board configuration data missing - Main board factory data missing - Transmitter board factory data missing - Receiver board factory data missing.
DATABASE (future functionality)	Error: Acknowledgeable COM channels base data block missing. Possible cause: - Error in non-volatile memory occurs during data block initialization.

EFFECTIVITY _____

ALL

34-24-61

Page 3-101
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table 3-1. Error List (Cont)

Error/Warning List	Symptom / Action / Check
CONTROL LINK	Error: Non- Acknowledgeable Communication error with COM subsystem. Possible cause: - Problem with the interwiring - No COM power supply
PTT STUCK	Warning: Acknowledgeable Possible cause: - Transmission continues more than 35 seconds. Frequent overriding can decrease the MTBF - PTT key is stuck - PTT line permanently grounded (short circuit in installation). NOTE : For the start of a new transmission it is necessary to set the /PTT line inactive (open).
TX HOT	Warning: Acknowledgeable Possible cause: - Very high environmental temperature, long transmissions times and airflow conditions are not sufficient.
NAV	
NO GS	Error: Acknowledgeable GS subsystem malfunction. Possible cause: - Problem with the interwiring - HW or SW failure.
NO VOR/LOC	Error: Acknowledgeable VOR/LOC subsystem malfunction. Possible cause: - Problem with the interwiring - HW or SW failure.
NV-MEMORY	Error: Acknowledgeable (not all) Operational memory error. Possible cause: - HW or SW failure.
DATABASE (future functionality)	Error: Acknowledgeable NAV channels base data block missing. Possible cause: - Error in non-volatile memory occurs during data block initialization.

EFFECTIVITY _____

ALL

34-24-61

Page 3-102
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table 3-1. Error List (Cont)

Error/Warning List	Symptom / Action / Check
CONTROL LINK	Error: Non- Acknowledgeable Communication error with NAV subsystem. Possible cause: - Problem with the interwiring - No NAV power supply.
NAV FAILURE	Error: Non- Acknowledgeable NAV subsystem malfunction. Possible cause: - HW or SW failure.
NV-MEMORY	Error: Non- Acknowledgeable (not all) Factory setup data block missing. Possible cause: - Main factory data missing.
CALIBRATION	Error: Non- Acknowledgeable The GS subsystem is in calibration mode; the analog output is not reliable. Possible cause: - SW failure.
NAV MAINTENANCE	Warning: Acknowledgeable Non-critical issue in the device. Possible cause: - Operation log section is incorrect - Temperature sensor malfunction - Defensive software restart error - Communication error with NAV subsystem.
CH (on NAV error screen)	
CH MAINTENANCE	Error: Acknowledgeable Non-critical issue in the device. Possible cause: - The internal voltages are out of range - Light sensor malfunction - Error in non-volatile memory.

EFFECTIVITY

ALL

34-24-61

Page 3-103
13 Aug 2025



INSTALLATION AND OPERATION MANUAL
89000002-120

Table 3-1. Error List (Cont)

Error/Warning List	Symptom / Action / Check
CH NV-MEMORY	Error: Acknowledgeable Communication error in non-volatile memory Possible cause: - HW or SW failure.
CH OVERHEAT	Warning: Acknowledgeable The head temperature has exceeded 100 degrees Possible cause: - Very high environmental temperature - HW failure.

UP843765

EFFECTIVITY _____
ALL

34-24-61