

HOW TO APPLY PREMIUM POLISH AND SEALANT

Rolite® recommends CCS White Foam Anti-Static Detailing Pad for use with this product.

- Wash and dry vehicle before applying.
- Pour onto clean damp pad. Apply to one section at a time using a firm circular motion.
- Allow to dry to a haze, then buff-off with a dry, clean, soft cloth.
- Not to be used on flat black paint or black textured trim.

Product Care:

- The surface to be polished should be thoroughly washed just prior to polishing.
- All applicators and polishing cloths must be absolutely clean. Imbedded dust or dirt will scratch metal or painted surfaces resulting in a poor polish job.
- Applicators, machine bonnets, and polishing cloths should be freshly laundered. To prevent contamination don't lay these items on a dirty surface during their use. If you drop them accidentally replace them with fresh new ones before you continue.
- After laundering and drying, place applicators, polishing cloths, and machine bonnets in sealed plastic bags for storage – or at least store them in a drawer or closed cardboard box where they are not likely to be exposed to dust.
- In between washings, applicators should only be used with the same product. If you are applying more than one product, keep applicators separate from one another in marked bags or containers.

~~~~~

Pacific Pilot Experience: We love this product and so will you. Your airplane or vehicle will glisten with little effort, and the shine lasts longer than other polishes.