

RAM CRADLE FOR IPOD TOUCH 4G FOAM PAD PREPERATION

ADHERE FOAM PADS AGAINST CRADLE, JUST ABOVE LOWER RIBS. USE SYMMETRICAL PLACEMENT. DO NOT ADHERE TO SIDES OF CRADLE.



BEFORE



AFTER

USE NUTS AND APPROPRIATE LENGTH SCREWS PROVIDED TO ATTACH TO ANY COMPATIBLE RAM-MOUNT.