



Start



Finish

Installation Procedure:

1. Completely retract the slide and install the Rivet Nut (finger tight) on the stud.
2. Place the stabilizing rod in the provided hole.
3. Insert the Rivet Nut into the drilled hold and tighten the slide screw to draw the slide up the ramp.
4. Typically, the slide will be completely closed when using (1/4 - 20) & 6 MM Rivet Nuts. When using smaller size test to see how far to draw the slide up the ramp. Usually 1/8" to 3/16" gap.
5. **USE 1/4" YELLOW WASHER FOR ALL SIZES.**

6 - 32

8 - 32

10 - 32

1/4 - 20

4MM

5MM

6MM

www.rivetnuttool.com