

**Step 1: Place rubber strap through top slot on strut clamp.
Ensure that the tongue of the metal clasp on the rubber strap faces away from the strut.**



Step 2: Loosely wrap the rubber strap around the strut.



Step 3: Thread the rubber strap through the bottom slot of the strut clamp.



Step 4: Thread the rubber strap through the metal clasp.



Step 5: Pull the rubber strap tight.



Step 6: Ensure the tongue of the metal clasp is secured into one of the holes in the rubber strap.





Step 7: Secure the excess portion of the rubber strap. The strap may be cut to length or folded and secured with a zip tie. If you decide to cut the strap to fit, make sure to leave at least 6" or 10cm of material.