






#### J. Nearest Airport. (From any page)

Should it be necessary to proceed to a nearest airport when not on a flight plan, the 25 nearest airports to your present position (that meet the criteria you selected on Aux Page 4, System Setup) are easily available. We are at the Wichita, Mid-Continent Airport, KICT, and wish to go direct to the Beech Factory airport, KBEC, which is about 10 miles east.

1. ROTATE Large FMS Knob fully clockwise to select NRST pages.
2. If necessary ROTATE Small FMS Knob to Page 1.
3. PRESS Small FMS Knob to activate cursor.
4. ROTATE either FMS Knob to highlight KBEC which is the identifier for the Beech Factory airport as shown to the right.
5. PRESS  then  twice to activate the operation.
- 6 PRESS Small FMS Knob to turn the cursor OFF.

NEAREST AIRPORTS			
70K	○	354°	6.9NM
KIAB	●	096°	8.1NM
KCEA	ⓘ	085°	8.7NM
SN65	Ⓜ	244°	9.3NM
 <b>KBEC</b>	Ⓜ	070°	10.7NM

#### NOTES

**NOTE:** When an airport is highlighted in Step #3, the Airport Information, Runways, Frequencies, and Approaches data is displayed below the Nearest Airports box. To access the other runways, frequencies or approaches, PRESS the **RNWX, FREQ, or APR**  Soft Key, then ROTATE either FMS Knob to highlight the desired field. With a frequency selected, PRESS  to load the frequency into the Standby window of COM 1. Besides having the bearing to and distance to shown in the box, a white dashed/dotted line is drawn on the map from the airplane to the airport. Once activated, the white line is shown with a magenta background.