

Mounting & Wiring

ALL WIRES AWG
18 - 22 Gauge (0.6 - 1.0 mm)

Screw Terminal
(On Case Back)



Sender Ground (E)



Sender Signal (D)



Output Alarm Signal
(5V, 10mA (max))
(Control signal for a ER-1A relay)

(A) Ground (-)



(B) +12-24VDC
(fuse at 1 amp)