

Landing Gear Assembly:

Beechcraft Landing Gear Assembly (Overhauled):

Part Number	Core Charge	Notes
101-810000-*	15,000.00	King Air 200: Book 101-590010-17E6, Book 101-590010-159
101-810002-*	15,000.00	King Air 200 Hi-Flot: Book 101-590010-17E6, Book 101-590010-159
101-810009-9	15,000.00	KingAir Hi-Flot
101-810010-11	15,000.00	King Air 200 Mains: Book 101-590010-159: BB158, BB1167, BB1193 & after
101-810082-1	15,000.00	KingAir 300 Mains: Book 101-590097-7: FA1 & after; 350 Book 130-590031-9: FL1 & after, FM1 & after
101-820020-*	20,000.00	King Air 200 Nose Gear: Book 101-590010-159; 300 Book 101-590097-7; 350 Book 130-590031-9
101-820029-*	20,000.00	King Air C90 & E90 Nose Gear Book 90-590012-17F7; F90: Book 109-590010-23E1
114-810000-*	15,000.00	Beechcraft 1900 Series Main Gear
114-820021-*	25,000.00	Beechcraft 1900 Series Nose Gear
115-810000-*	15,000.00	King Air F90 Standard mains: Book 109-590010-23E1; 100: Book 100-590027-3B6; 99: Book 99-590014F5
50-810304-*	15,000.00	King Air C90 & E90 Standard Mains: Book
50-810286-*	15,000.00	90-590012-17F7; 90, A90, B90: Book 65-590016-3F9
50-820196-*	20,000.00	King Air 90, A90, B90 Nose Gear: Book 65-590016-3F9; C90 & E90: Book 90-590012-17F7; 99: Book 99-590014F5; C99: Book 99-590031-1B5
90-810039-*	15,000.00	King Air C90 & E90 Main Gear: Book 90-590012-17F7
90-810039-*	15,000.00	King Air C90 & E90 Main Gear: Book 90-590012-17F7
97-820000-*	20,000.00	King Air F90 Nose Gear: Book 109-590010-23E1; C90 & E90 Book 90-590012-17F7; 100: Book 100-590027-3B6; 200: Book 101-590010-17E6, Book 101-590010-159