

Instructions for SwitchBox 20 12



Disclaimer: Use this SwitchBox at your own risk. This device contains electrical switches (Max Total Power 1800W), which activate and Power On/Off connected electrical devices. Text Messages control these connected devices, and sustain or interrupt continuous power to them. Improper operation can cause damage to the Device(s), SwitchBox or User(s). SwitchBox Control will not be held liable for any damage caused by this product.

NOTE: Your SwitchBox has come pre-installed with a SIM card that must be activated upon first use. Please contact us at support@switchboxcontrol.com and include your sim card # and a picture of your card for activation. We will email you the unique phone # for your Switchbox once activation is complete.

Switchbox Ultra SIM Card (T-Mobile)

All Switchbox Ultra SIM accounts have 500 texts available credit, over 12x more credit and much cheaper than AT&T. The maximum amount of texts include 500, which will reset back to 500 available on the beginning of each month. Monthly charge for Switchbox Ultra SIM service costs \$25 for 90 days of use and is available on our website under Switchbox Ultra SIM credit and service. You can choose auto-pay to continue service uninterrupted, or manage the account yourself manually. If the account does not have enough funds, Switchbox Ultra SIM will you give an additional 1-month grace period with a zero balance until the sim card is deactivated. If this occurs, visit our website to purchase a new Switchbox Ultra SIM card.

AT&T SIM Card

All text messages will cost 25 cents to send or receive. If you need to replenish the SIM card with more credit, visit your online account at <https://www.paygonline.com/> with login (your-phone-number) and password (Switchbox1). The minimum amount to add with AT&T is \$10, for 30 days of service, or \$25 for 90 days of service. If the account does not have enough funds, AT&T will you give an additional 1-month grace period with a low balance until they deactivate your account. If this occurs, visit our website to purchase a new AT&T SIM card. Do not reset your online account password or the system will text your Switchbox a new code, which you can not view without a display. If you do reset the account password inadvertently, you can always manage your account via phone support or send us your SIM card for a free reset.

Operating Directions

The preferred mode of operation is via the Free App. You can download the 'Switchbox Control' App on your Iphone, Ipad or Android device in the Apple or Google App Stores. Your default app password is 123456 and can be configured easily using the steps found here in our setup video <http://switchboxcontrol.com/iphone-app-free/>

For text message commands see below.

There are 2x outlets available that can be turned on/off via SMS text messages.

Outlet 1 is the far right plug when viewing the SwitchBox straight on, observe the Case Cover for direction.
Outlet 2 is the middle plug of the box, observe the Case Cover for direction.

To turn ON Outlet1 or Outlet2 via a text message, send the corresponding command below

#PWD123456#OUT1=ON or #PWD123456#OUT2=ON

You will receive the following confirmation that the Outlet has been turned ON

OUT1 ON OK or OUT2 ON OK

To turn OFF Outlet1 or Outlet2 via a text message, send the corresponding command below

#PWD123456#OUT1=OFF or #PWD123456#OUT2=OFF

You will receive the following confirmation that the Outlet has been turned OFF

OUT1 OFF OK or OUT2 OFF OK

Control Both Outlets -- Send the following commands to control both outlets at the same time

#PWD123456#OUT=11 ---- Both Outlets turn ON
#PWD123456#OUT=00 ---- Both Outlets turn OFF

Signal Strength – Monitor the signal strength at the current location with the following command

#PWD123456#CSQ?

You will receive the following confirmation of the Signal Strength from 1 (lowest) to 32 (highest)

CSQ is 32

Outlet Status – Check which relays are currently ON or OFF with the following command

#PWD123456#OUT?

You will receive the following confirmation of the Outlet status with responses either: OUT 00 (Both Outlets OFF), OUT 10 (Outlet1 ON and Outlet2 OFF), OUT 01 (Outlet1 OFF and Outlet2 ON), or OUT 11 (Both Outlets ON)

OUT 11

---- Both Outlets are ON

Password Change – Change the default password with the following command

#PWD123456#CAP121212#CAP121212

In this example, the default password has been changed to 121212

Wired Antenna – 10' Extension

Users that operate in poor reception areas and/or need added reach to the outside of their location can use the optional 10' wired antenna with magnetic base. Mount the wired antenna as high above the SwitchBox as possible, for best reception.

Contact Us

For further assistance and technical support, message us at support@switchboxcontrol.com. Visit our website at www.switchboxcontrol.com for the newest software updates, product videos and instruction manuals.

Switchbox Control // 245 East 11th St #5G, New York, NY 10003 // www.switchboxcontrol.com //