


RTX



REPAIR TOOLS (NON CERTIFIED)

| Item No. | Application | Item No. | Application | Item No. | Application |
|----------|--|----------|---|----------|---|
| 1-4 | Roller bearing 25x25x15, oil seal 30x52x7 | 32 | Fitting of piston pin circlips | 55 | For check of float chamber |
| 5 | Prop shaft version 2 | 33-34 | Fitting and removal of piston pin | 56 | For float level gauge |
| 6 | Prop shaft version 3 | 35 | Mono hook clips puller | 57 | Checking of hydraulic valve tappet and valve spring force |
| 7 | Roller bearing 25x52x15, oil seal 30x52x7, version 2 | 36 | Piston diameter 84 mm/3.3 in. | 58 | Checking plain bearing protrusion |
| 8 | Roller bearing 25x52x15, oil inlet flange version 3 | 36 | Piston diameter 79.5 mm/3.13 in. | 59-60 | Dial gauge |
| 9 | Roller bearing 25x52x15, oil seal 30x52x7 | 37-38 | Puller Magneto hub | 61 | Checking plain bearing position |
| 10-11 | Roller bearing 25x52x15, oil seal 30x52x7, oil inlet cover | 39 | Crankshaft magneto side | 62 | Dial gauge adapter for valve seat inspect |
| 12 | Crankshaft locking screw M8x50 | 40 | Adapter ring assy. for valve spring mounting device | 63 | For aligning cylinders |
| 13-14 | Gearbox | 40-42 | Installation/Removal of valve spring | 64 | Oil seal 6x11x3/ 4.5 of rev counter housing |
| 15-18 | Ball bearing 15x32x8, Oil inlet flange, oil inlet cover | 43 | Oil filter removal | 65 | To release the cable on electr. connectors |
| 19 | Needle bearing 22x28x12-vacuum pump | 44 | Waterpump impeller | 66 | For press in of worm gear, mech. rev counter |
| 20 | Ball bearing 15x32x8-vacuum pump | 45 | Rotary seal crankcase | 67 | See MM Line chapt. 05-50-00 |
| 21 | To compress dog gear | 46 | Oil Seal 12x30x7 water pump shaft | 70 | Slim edition for magneto hub |
| 22 | Ring wrench 10/13 | 47 | Spring type hose clip 28 | 71 | Engine support |
| 23 | Fixture for vacuum pump drive | 48 | Overload clutch | 72 | For engine fixation (912 with engine suspension frame on the gearbox/914) |
| 24 | Ball bearing 15x32x8, needle sleeve vacuum pump | 49 | Crankcase | 73 | For engine fixation (912/914) without engine suspension frame |
| 25 | Oil seal 22x32x7 vacuum pump | 50 | Thread bent socket | 74 | For magnetic drain plug (old version) |
| 26 | Oil seal 40x55x7 gear box cover | 51 | Oil filter | 75 | Hex. nut (WS 46), crankshaft magneto side |
| 27 | Stamp | 52 | For O-ring 3.2x1.8 idle mixture screw and idle jet 35 | 76 | 1" to 3/4", for socket wrench |
| 28 | Ball bearing 35-72-17, prop. shaft handle with part no. 876518 | 53 | Oil Seal 32x52x7 crankshaft magneto side (ms) | 77 | Measuring fuel pressure |
| 29-31 | Hex nut A/F 41 | 54 | Oil Seal 32x52x7 crankshaft ms | | |