

CESSNA PARTS

Aircraft Spruce and Specialty stocks a large inventory of Cessna replacement parts. Some of the most commonly required parts are listed on this page. If you require Cessna parts not listed here, please provide us with the Cessna part numbers and we will provide you with a prompt quotation. All of the parts listed here are authentic Cessna factory parts and all carry our low price guarantee. Please verify that the parts are correct for your Cessna model/year by referring to the applicable Cessna parts manual prior to ordering.

Call for Prices on Unlisted Cessna Parts

Part. No.	Description	Price
S1258-1	Sump	---
SK172-1F	Strut Kit	---
S1093-1	Flap Buttons	---
NAS75-3-009	Bushing	---
NAS77-3-23	Bushing	---
NAS77-8-88	Bushing	---
MS25171-1	Nipple	---
MS25171-2	Nipple	---
C156003-0101	Fuel Cap	---
C592001-0201	Static Wick Certified	---
11-10574	Static Wick Non Certified	---
B100142-1	Fuel Cap Gasket	---
S1991A1	Contacto	---
S2020-2	Drain Valve	---
S2106-4	Drain Valve	---
S2160-1	Switch	---
S2237-3	Seat Belt Bushing	---
S2416-1-31.0	Alt Belt	---
0400213-6	Compass Placards	---
0413613-1-279	Panel Nut	---
0511242-1	Seat Stop	---
1220114-1	Spacer	---
1243030-5	Shim	---
1243030-6	Shim	---
1243030-7	Shim	---
1250860-29214	Clamp	---
1298119-4	Exhaust Spring	---
06-03498	Fastener S2319-1	---
0711021-9	Door Spring for Window	---
1414104-54	Bushing	---
1513174-3	Grey Panel Nut	---
1513174-5	Black Panel Nut	---
0523919	Bushing	---
0523920	Roller	---
0523921	Roller	---
0541139	Plug	---
9910306-1	Westgate Gasket	---
0711001-59	Hinge Pin	---
0713348-1	Stall Horn	---
S2488-1	Stall Horn Reed	---
0756009-8	Gasket	---
0851559-1	Washer	---
0756010-6	Plunger	---
0756011-1	Standpipe	---
S1450-6B14-010	Washer	---
S1597-1-37.5	Belt V	---
B3-5-1	Filter Vac	---
S1921-1	Clamp	---
U10C062-262M	Clamp	---
S2870-1	Switch Press To Test	---
S2091-5	Resistor	---
S339-1	Clip	---
S339-3	Clip	---
111190-8	Ring Scraper	---
S11L-162C	Ring	---
B40012	Brush	---
A2748	Seal	---
A2749	Seal Wiper	---
MS25253-1	Switch	---
1234665-10	Tab	---
S1906-1	Switch	---
S1906-2	Switch	---
S1230-17	Control	---
S1230-19	Control	---
RD0015H1600JBL	Rheostat	---
0441139-6	Shim	---
0541111-2	Shim	---

Part. No.	Description	Price
0441157-2	Shim	---
0441157-1	Shim	---
1250405-1	Nut	---
MS29513-338	O-Ring	---
AN6235-2A	Filter Hyd	---
AN6235-3A	Element	---
1250922-200	Adapter	---
1250922-201	Adapter	---
0750142-1	Gasket	---
0756009-1	Fuel Filter	---
0741623-4	Tread	---
0441157-3	Shim	---
0556010-200	Adapter Ass'y.	---
1232040-5	Boot	---
79C1	Drain Valve	---
S2485-1	Drain Valve	---
P52-0016	Contacto	---
S1579A2	Contacto	---
S1580A1	Contacto	---
S1588-1	Gasket	---
S1588-2	Gasket	---
0750143-2	Deflector	---
0750143-3	Bracket	---
0851559-1	Washer	---
S1915-1	Capacitor	---
S1915-2	Capacitor	---
S1994-1-1	Switch	---
S2334-3	CHT Probe	---
S1258-1	Sump	---
S3010-1	Switch	---
S1104-3	Rod End	---
S1105-4	Rod End	---
C592001-0201	Wick	---
C592001-0203	Wick	---
S1704-1	Roller	---
1714000-22	Washer	---
16165	Wick	---
KM610-64	Latch	---
S11L-161C	Spring	---
S11L-174C	Spring	---
S11K-3A	Seal	---
S11K-4R	Seal	---
3009022	Washer	---
B3-11-1	Gasket	---
S1477-3	Nut	---
S1477-08	Nut Clip	---
NH1000897-30	Clamp	---
NH1000897-40	Clamp	---
NH1000897-50	Clamp	---
NH1000897-60	Coupling	---
DGR3	ACU	---
DGR6	Regulator	---
SK152-25A	Rudder Stop	---
P52-0016	Contacto	---
05-14700	O-Ring	---
390K4E	Alternator Belt	---
0422344	Tie Down Bolt	---
P264-5037-1	Oil Pressure Sender	---
05-22397	Oil Pressure Switch 83278	---
05-22149	R860025 Seal CM 2919-2.50	---
06-03306	Nose Strut Pressure Valve S1827-1	---
06-03307	Pulley S378-4	---
06-03308	Ammeter 53280-1	---
06-03309	Cross Arm 0713020-2	---
06-03310	Cowling Cover 075273-14	---
06-03313	Door Handle	---
06-03314	Switch S3443-1-1	---