

WHELEN STROBES

STROBE SYSTEM PARTS

Model No.	Description	Part No.	Price
A402R	Red Optic Lens	11-03254	---
A402W	White Optic Lens	11-03271	---
A402R/W	Split Red/White Optic Lens	11-03248	---
A406	Flash Tube Assembly	11-03687	---
A409	Clamp Ring Assembly	11-03688	---
A414A, HDH, CF	HDH,CF Power Supply	11-03632	---
A417-1	Interconnecting Cable	11-03658	---
A421-1	Warning Decal	11-03691	---
A425	Tail Strobe Lens Retainer	11-03692	---
A426	Wingtip Strobe Lens Retainer	11-03233	---
A427	Flash Tube Assembly	11-03219	---
A427-M	Flash Tube Assembly with Molex Connector	11-03272	---
A427-4	Rubber Pad Spacer	11-03693	---
A428	Wingtip Strobe Lens	11-03236	---
A428-C	Wingtip Strobe Radio Shielded Lens	11-03694	---
A428-D	Wingtip Strobe Radio Shielded Lens plus A426 Retainer Assembly	11-03290	---
A469A	Strobe Tube Assembly	11-03242	---
A430	Tail Strobe Head Assembly	11-03696	---
A435	Flash Tube Assembly	11-03697	---
A440	WRM-65 Mounting Adapter, for HR,DF & SA,DF	11-03699	---
A441	AMP Connector and 3 Pins	11-03211	---
A442	AMP Connector and 3 Sockets	11-03212	---
M441	Molex Connector and 3 Pins for Piper Installation	11-04215	---
M442	Molex Connector and 3 Sockets for Piper Installation	11-04216	---
A444	AMP Connector and 2 Pins	11-03700	---
M444	Molex Connector and 2 Pins for Piper Installation	11-04217	---
A446	AMP Connector and 2 Sockets	11-03702	---
A450	Strobe Head Assembly	11-03280	---
A455	Gasket	11-03703	---
A457A	Tail Light Lens for A500 and A555	11-03227	---
A457A-D	Radio Shielded Tail Light Lens Assembly for A500	11-03704	---
A466A-1	Radio Shielded Lens	11-03708	---
A467	Gasket for A470	11-03709	---
A469B	Flash Tube Assembly	11-03225	---

Model No.	Description	Part No.	Price
A470-D	Radio Shielded Remote Strobe Head Assembly, Specify Color	11-03291	---
A470-A-D-S	Strobe Head Assembly, Shielded Red/White	11-04976	---
A470-D-R-SU	Radio Shielded Remote Strobe	11-03714	---
A490 TC CF	14V Power Supply	11-02661	---
A500-V-D-M-14	Radio Shielded Tail Position & Strobe Light Head Assembly Vertical Mount with Molex Connector	11-03722	---
A500B-V-28	Tail Position & Strobe Light Head Assembly (Beech)	11-03716	---
A506	Flash Tube & Socket Assembly	11-03274	---
A506-B	Flash Tube & Socket Assembly	---	---
A508-14	Halogen Lamp for A500, A555, A600	11-03216	---
A508-28	Halogen Lamp for A500, A555, A600	11-03208	---
A509	Lamp Shield for A500 and A555	11-03727	---
A510-28	Lamp Assembly for A500 & A555	11-03266	---
A50828	Lamp for A500, A555, & A600	11-03208	---
A605	Base Plate Assembly	11-03733	---
A606	Retainer	11-03260	---
A610	Flash Tube Assembly	11-03213	---
A610-M	Flash Tube Assembly	11-03734	---
A612	Magnifying Lens	11-03222	---
A612-D	Radio Shielded Lens Retainer Assembly	11-03735	---
A615	Lens for A600 Tail Light	11-03230	---
A616	Gasket for A600 Tail Light	11-03261	---
A625	Tail Strobe Head	11-03228	---
A625-D	Radio Shielded Tail Strobe Head Assembly	11-03659	---
A626	Retainer Lens	11-03229	---
A626-D	Radio Shielded Lens Retainer Assembly	11-03736	---
A627	Flash Tube Assembly	11-03263	---
A628	Retainer Lens	11-03737	---
A629	Gasket	11-03660	---
A650	Wingtip Strobe Head Assembly	11-03215	---

EL