

Battery Capacity Analyzer

Field Calibration Procedure Manual



Battery Capacity Analyzer P/N: BC3100-0001
Manual ES1023 Revision C

Copyright © 2013 Lamar Technologies LLC.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Lamar Technologies LLC.

WARNING: IMPROPER OR UNAUTHORIZED APPLICATIONS OF THE INFORMATION CONTAINED IN THIS MANUAL MAY RESULT IN LOSSES OR DAMAGES TO THE USER.

The manuals and the equipment referenced are produced under contract solely for Teledyne Battery Products. The accuracy and applicability of this manual has not been verified for any assembly, component or part not manufactured or designed by Lamar Technologies. Any use of this manual for other than its intended purpose or for performing any installation, maintenance, replacement, adjustment, inspection or overhaul of any assembly, component or part not manufactured by Lamar Technologies LLC is not approved, endorsed, or sanctioned by Lamar Technologies LLC.

No liability will be assumed by Lamar Technologies LLC for actual, consequential or other types of damages directly or indirectly resulting from the unauthorized use of this manual for other than its stated purposes.

All reasonable attempts were made to make this manual as complete and accurate as possible. If you have any questions, comments, corrections or require clarification of any information contained herein, please write or call, Teledyne Battery Products, Inc. using the contact information on the back page of the manual.

BC3100-0001

Field Calibration Procedures

Introduction	1-30-01
Scope	1-30-01
Test Equipment	1-30-01
Procedure	1-40-01
Connections	1-40-01
20.0 Volt Cutoff	1-40-01
10.0 Volt Cutoff	1-50-01
Frequency	1-50-01
Connections	1-60-01
24 Volt 10 Amp Setting	1-60-01
24 Volt 50 Amp Setting	1-70-01
12 Volt 10 Amp Setting	1-70-01
12 Volt 50 Amp Setting	1-80-01
Records	1-80-01
Calibration Record	1-90-01

This Page Intentionally Left Blank

BC3100-0001

Field Calibration Procedures

INTRODUCTION:

The BC3100-0001 Battery Capacity Analyzer has been designed to perform automatic capacity testing of 12 and 24 Volt lead-acid batteries. This unit is capable of accurately measuring the capacity of a fully charged battery with a rating between 10 and 59 amp-hours. It is self-contained and easy to operate.

SCOPE:

This document provides instructions on how to perform the annual calibration for the BC3100-0001. The calibration instruction has been broken down into the following categories:

- Calibrate Cutoff at 20.0 Volts
- Calibrate Cutoff at 10.0 Volts
- Calibrate Frequency
- Calibrate 24 Volt 10 Amp Setting
- Calibrate 24 Volt 50 Amp Setting
- Calibrate 12 Volt 10 Amp Setting
- Calibrate 12 Volt 50 Amp Setting



**Figure 1 – BC3100-0001
Battery Capacity Analyzer**

TEST EQUIPMENT:

- A. BC3100-0001 Battery Capacity Analyzer
Test Fixture: Lamar P/N 20758
Test Fixture (Pictured at right).
- B. Battery: 24 Volt, fully charged per manufacturers recommendation.



**Figure 2 – Lamar Technologies 20758
TEST FIXTURE**

- C. Battery: 12 Volt, fully charged per manufacturers recommendation.
- D. DC Power Supply: Capable of at least 24 volts and 20 amps with course and fine voltage adjustments.
- E. Battery Chargers: E.1. or E.2 (below).
 - 1. (1) 12 Volt Charger & (1) 24 Volt Charger.
 - 2. (1) At least one DC Power Supply capable of 28 volts or any other means for charging batteries to manufacturers recommendation.
- F. Calibrated FLUKE 87 or Equivalent Multi-meter with DC volts & millivolts ranges (DVM).
- G. Stop watch.
- H. Small thin blade screwdriver for adjusting P1 through P4 calibration pots.
- I. Miscellaneous hand tools for connecting Test Fixture to batteries and power supply.
- J. Photocopy of Page 9 showing Records Table with blank values in Measured Value, Pass & Fail columns.

PROCEDURE:

A. Connections:

1. Connect 20758 test fixture to 24 volt 20 amp power supply by connecting the red lead to positive terminal of power supply and the black lead to the negative terminal of power supply.
2. Plug the connector for the 20758 test fixture into the BC3100 connector.
3. Connect the DVM leads to the power supply leads.
4. Record the DVM calibration expiration date in the blank below the Records table.

B. 20.0 Volt Cutoff:

1. It may be necessary to repeat Procedure B (20.0 Volt Cutoff) & C (10.0 Volt Cutoff) until all values fall within range. When this is necessary there will be interim values that do not need to be recorded in the Records section. The “final” readings to be recorded are the readings in which no adjustment is required to complete Procedure C (10.0 Volt Cutoff).
2. Set the DVM to DC-Volts and a range capable of measuring up to 22 volts.
3. Turn Power Switch off.
4. Adjust power supply until DVM reads 21.0 volts.
5. Adjust the current limiting for the power supply to 20 amps or more.
6. Turn Power Switch on.
7. 24 VOLT LED illuminates.
8. READY LED illuminates.

9. RATING display should be flashing at 10.
10. Press the START button for 3 seconds.
11. READY LED extinguishes.
12. TESTING LED illuminates.
13. RATING LED should stop flashing and continue to read 10.
14. Wait until CAPACITY display reads 001 or higher.
15. Slowly decrease power supply voltage while monitoring the DVM.
16. TESTING LED should extinguish and the COMPLETE LED illuminate between 19.80 and 20.20 volts (as indicated by the DVM).
17. If that voltage falls below the 19.80 volts turn P4 CW, if that voltage is above 20.20 volts turn P4 CCW.
18. If P4 required adjustment repeat Procedure B (20.0 Volt Cutoff) until no adjustment is required.
19. Enter the final voltage reading in the “Measured Value” column in the “20.0 Volt Cutoff” row in the Records table.

C. 10.0 Volt Cutoff:

1. Turn Power Switch off.
2. Adjust power supply until DVM reads 11.0 volts.
3. Turn Power Switch on.
4. 12 VOLT LED illuminates.
5. READY LED illuminates.
6. RATING display should be flashing at 10.
7. Press the START button for 3 seconds.
8. READY LED extinguishes.
9. TESTING LED illuminates.
10. RATING LED should stop flashing and continue to read 10.
11. Wait until CAPACITY display reads 001 or higher.
12. Slowly decrease power supply voltage while monitoring the DVM.
13. TESTING LED should extinguish and the COMPLETE LED illuminate between 9.90 and 10.10 volts (as indicated by the DVM).
14. If that voltage falls below the 9.90 volts turn P4 CW, if that voltage is above 10.10 volts turn P4 CCW.
15. If P4 required adjustment repeat Procedures B (Volt Cutoff) & C (10.0 Volt Cutoff) until no adjustment is required.
16. Enter the final voltage reading in the “Measured Value” column in the “10.0 Volt Cutoff” row in the Records table.

D. Frequency:

1. It may be necessary to repeat Procedure D (Frequency) until all values fall within range. When this is necessary there will be interim values that do not need to be recorded in the Records section. The “final” readings to be recorded are the readings in which no adjustment is required when calibration finishes Procedure D (Frequency).
2. Turn Power Switch off.
3. Adjust power supply to 24 Volts.
4. Turn Power Switch on.

5. 24 VOLT LED illuminates.
6. READY LED illuminates.
7. RATING display should be flashing at 10.
8. Press the START button for 3 seconds.
9. READY LED extinguishes.
10. TESTING LED illuminates.
11. RATING LED should stop flashing and continue to read 10.
12. Wait until CAPACITY display reads 001 or higher.
13. With a stopwatch, measure the time interval for the CAPACITY display to increase by 10 units. For example, measure the amount of time from the instant the display changes to 003 until the instant it changes to 013.
14. The period of the interval should be 357 to 363 seconds.
15. If that time falls below the 357 seconds turn P1 CCW, if that time is above 363 seconds turn P1 CW.
16. If P1 has been adjusted repeat Procedure D (Frequency) until no adjustment is required.
17. Enter the final time in the “Measured Value” column in the “Frequency” row in the Records table.
18. Turn Power Switch off.

E. Connections:

1. Remove leads from power supply.
2. Plug the DVM leads into the 20758 test fixture terminal jacks. The positive lead in the red jack and the negative lead in the black jack.

F. 24 Volt 10 Amp Setting:

1. It may be necessary to repeat Procedure F (24 Volt 10 Amp Setting), G (24 Volt 50 Amp Setting), H (12 Volt 10 Amp Setting), and I (12 Volt 50 Amp Setting) until all values fall within range. When this is necessary there will be interim values that do not need to be recorded in the Records section. The “final” readings to be recorded are the readings in which no adjustment is required when calibration finishes Procedure I (12 Volt 50 Amp Setting).
2. Connect 20758 test fixture to a fully charged 24-volt battery by connecting the red lead to the positive terminal and the black lead to the negative terminal.
3. Set the DVM to DC-Volts and a range capable of measuring up to 20 mV.
4. Turn Power Switch on.
5. 24 VOLT LED illuminates.
6. READY LED illuminates.
7. RATING display should be flashing at 10.
8. Press the START button for 3 seconds.
9. READY LED extinguishes.
10. TESTING LED illuminates.
11. RATING LED should stop flashing and continue to read 10.
12. DVM should read 9.8 mV – 10.2 mV.
13. If it reads within range, record the final value read in the “Measured Value” column in the “24 Volt 10 Amp Setting” row in the Records table.

14. If the reading is below the 9.8 mV turn P3 CW until it reads 10.0 mV, if that voltage is above 10.2 mV turn P3 CCW until it reads 10.2 mV.
15. Turn Power Switch off.

G. 24 Volt 50 Amp Setting:

1. Set the DVM to DC-Volts and a range capable of measuring up to 100 mV.
2. Turn Power Switch on.
3. 24 VOLT LED illuminates.
4. READY LED illuminates.
5. RATING display should be flashing at 10.
6. Using left ^ to set 10's digit, set RATING display to 50.
7. Press the START button for 3 seconds.
8. READY LED extinguishes.
9. TESTING LED illuminates.
10. RATING LED should stop flashing and continue to read 50.
11. DVM should read 49.6 mV – 50.4 mV.
12. If it reads within range, record final value read in the “Measured Value” column in the “24 Volt 150 Amp Setting” row in the Records table.
13. If the reading is below 49.6 mV turn P2 CW until it is within range, if that voltage is above 50.4 mV turn P2 CCW until it is within range.
14. Turn Power Switch off.
15. If P2 has been adjusted go back and repeat Procedures F (24 Volt 10 Amp Setting) and G (24 Volt 50 Amp Setting) until no adjustment is required.

H. 12 Volt 10 Amp Setting:

1. Connect 20758 test fixture to a fully charged 12 volt battery by connecting the red lead to the positive terminal and the black lead to the negative terminal.
2. Set the DVM to DC-Volts and a range capable of measuring up to 20 mV.
3. Turn Power Switch on.
4. 12 VOLT LED illuminates.
5. READY LED illuminates.
6. RATING display should be flashing at 10.
7. Press the START button for 3 seconds.
8. READY LED extinguishes.
9. TESTING LED illuminates.
10. RATING display should stop flashing & continue to read 10.
11. DVM should read 9.8 mV – 10.2 mV.
12. If it reads within range, record final value read in the “Measured Value” column in the “12 Volt 10 Amp Setting” row in the Records table.
13. If the reading is below the 9.8 mV turn P3 CW until it is within range, if that voltage is above 10.2 mV turn P3 CCW until it is within range.
14. Turn Power Switch off.
15. If P3 has been adjusted go back and repeat Procedures F (24 Volt 10 Amp Setting), G (24 Volt 50 Amp Setting) and H (12 Volt 10 Amp Setting) until no adjustment is required.

I. 12 Volt 50 Amp Setting:

1. Set the DVM to DC-Volts and a range capable of measuring up to 100 mV.
2. Turn Power Switch on.
3. 12 VOLT LED illuminates.
4. READY LED illuminates.
5. RATING display should be flashing at 10.
6. Using left ^ to set 10's digit, set RATING display to 50.
7. Press the START button for 3 seconds.
8. READY LED extinguishes.
9. TESTING LED illuminates.
10. RATING display should stop flashing & continue to read 50.
11. DVM should read 49.6 mV – 50.4 mV.
12. If it reads within range, record final value read in the “Measured Value” column in the “12 Volt 50 Amp Setting” row in the Records table.
13. If the reading is below the 49.6 mV turn P2 CW until it is within range, if that voltage is above 50.4 mV turn P2 CCW until it is within range.
14. Turn Power Switch off.
15. If P2 has been adjusted repeat Procedures F (24 Volt 10 Amp Setting), G (24 Volt 50 Amp Setting), H (12 Volt 10 Amp Setting) and I (12 Volt 50 Amp Setting) until no adjustment is required.
16. Disconnect unit from test fixture.
17. Test is complete.

J. Records:

1. If all values input into the records section are within range, check the corresponding space in the “Pass” column.
2. If any value cannot be brought within range using this calibration procedure check the corresponding space in the “Fail” column.
3. If all value are checked as “Pass”, check the space in the “Pass” column in the BC3100-0001 Battery Capacity Analyzer.
4. Sign and date the bottom of the Records section.
5. Retain that sheet for your records.
6. If any values are checked as “Fail”, check the space in the “Fail” column in the BC3100-0001 Battery Capacity Analyzer.
7. Send the unit back to Teledyne Battery Products for repair or replacement.

Calibration Records – P/N: BC3100-0001; S/N: _____

Table 1 - BC3100-0001 Battery Capacity Analyzer				
Record Name	Measured Value	Specification	Pass	Fail
20.0 Volt Cutoff		20.20 – 19.80 Volts		
10.0 Volt Cutoff		10.10 – 9.90 Volts		
Frequency (Period for 10 Unit Increase)		357 sec. – 363 sec.		
24 Volt 10 Amp Setting		9.8 – 10.2 mV		
24 Volt 50 Amp Setting		49.6 – 50.4 mV		
12 Volt 10 Amp Setting		9.8 – 10.2 mV		
12 Volt 50 Amp Setting		49.6 – 50.4 mV		

Multi-meter Calibration Expiration Date: _____ BC3100-001 Pass____ Fail____

BC3100-0001 Calibration performed as specified by _____ Date _____

This Page Intentionally Left Blank

Technical Support and Warranty:

**Teledyne Battery Products
840 West Brockton Avenue,
Redlands CA 92374**

Phone: 909-793-3131

Fax: 909-793-5818

Mailing address:

P.O. Box 7950

Redlands, CA 92375